Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 951

Ariete 951 Combined Microwave Oven with Grill User Manual

Model: 951

Safety Instructions Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Ensure the appliance is properly grounded.
- Do not operate the oven if the door or door seals are damaged.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Only allow children to use the oven without supervision when adequate instructions have been given.
- Regularly clean the oven and remove any food deposits.
- Do not use corrosive chemicals or vapors in this appliance.
- Do not use this appliance for commercial purposes.

Setup and Installation

Unpacking

Carefully remove the microwave oven and all packaging materials. Check for any damage. If the oven is damaged, do not operate it and contact customer support.



Image: The Ariete 951 microwave oven with its door open, revealing the interior cavity, glass turntable, and turntable ring. This illustrates the components included for setup.

Placement

- Place the oven on a flat, stable surface capable of supporting its weight (approximately 10.1 kg).
- Ensure adequate ventilation: leave at least 20 cm of space above the oven, 10 cm at the rear, and 5 cm on each side.
- Do not block any ventilation openings.
- Keep the oven away from heat sources and water.

Electrical Connection

- Plug the oven into a grounded electrical outlet that matches the voltage specified on the rating label (230 Volts).
- Do not use extension cords or adapters.

Operating Instructions

Control Panel Overview



Image: A detailed view of the control panel on the Ariete 951 microwave oven, showing the upper power level dial and the lower timer/defrost dial.

The Ariete 951 features two main control dials:

- **Power Level Dial:** Located at the top, this dial selects the cooking power or function (Microwave, Grill, or Combined). There are 5 power levels for microwave cooking.
- **Timer Dial:** Located at the bottom, this dial sets the cooking time up to 35 minutes or selects the defrost function.

Microwave Cooking

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. Turn the **Power Level Dial** to the desired microwave power setting (e.g., High for fast heating).
4. Turn the **Timer Dial** to the desired cooking time (up to 35 minutes). The oven will start automatically.
5. When cooking is complete, the timer will sound, and the oven will turn off.

Grill Cooking

1. Place food on the grill rack (if provided) or a heat-resistant dish.
2. Close the oven door securely.
3. Turn the **Power Level Dial** to the Grill setting.
4. Turn the **Timer Dial** to the desired grilling time.
5. Monitor food closely to prevent burning.

Combined Cooking (Microwave + Grill)

This function combines microwave heating with grilling for faster cooking and a crispy finish.

1. Place food in a suitable dish for combined cooking.
2. Close the oven door securely.
3. Turn the **Power Level Dial** to one of the combined settings (e.g., G.COMBI 1, G.COMBI 2).
4. Turn the **Timer Dial** to the desired cooking time.

Defrosting

1. Place frozen food on the glass turntable.
2. Close the oven door securely.
3. Turn the **Timer Dial** to the Defrost setting and select the appropriate weight or time.
4. Turn food over periodically during defrosting for even results.



Image: The Ariete 951 microwave oven with a bowl of mixed vegetables placed on the turntable inside, demonstrating typical use for heating or cooking.

Care and Maintenance

Cleaning the Oven Interior

- Always unplug the oven before cleaning.
- Wipe the interior cavity with a damp cloth and mild detergent after each use.
- For stubborn stains, place a bowl of water with lemon juice inside and microwave for a few minutes to loosen residue.
- Clean the glass turntable and roller ring with warm, soapy water. They are typically dishwasher safe.

Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners or harsh chemicals.

Door and Seals

- Regularly inspect the door seals for any signs of damage or wear.
- Clean the door seals and adjacent parts with a damp cloth to ensure a proper seal.

Troubleshooting Guide

Problem	Possible Cause	Solution
Oven does not start	Not plugged in; door not closed properly; timer not set.	Ensure plug is securely in outlet; close door firmly; set timer.
Food not cooking evenly	Food not stirred or turned; incorrect power level or time.	Stir or turn food during cooking; adjust power level and time.
Light bulb not working	Bulb needs replacement.	Contact qualified service personnel for replacement.
Sparks or arcing inside oven	Metal in oven; food residue; damaged waveguide cover.	Remove metal objects; clean oven interior; contact service if waveguide cover is damaged.

If the problem persists after attempting these solutions, please contact customer support.

Product Specifications

Brand: Ariete

Model Number: 951

Capacity: 20 Liters

Power / Wattage: 700 watts

Voltage: 230 Volts

Product Dimensions (D x W x H): 44 x 36 x 26 cm

Item Weight: 10.1 Kilograms

Material: Metal

Special Features: Timer, Grill Function

Warranty and Support

For warranty information, please refer to the warranty card included with your purchase or visit the official Ariete website. Keep your proof of purchase for warranty claims.
For technical support, spare parts, or service inquiries, please contact Ariete customer service. Contact details can typically be found on the manufacturer's website or in the documentation provided with the product.
Ariete Official Website: www.ariete.net

© 2023 Ariete. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088L741Y7

More documents and user manuals: **https://manuals.plus/**