Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 CAHE8ER-R410A17, CAHWE12E-R410A, CAHWE12E-R410A10, CAHE25ER-R410A17, CAHE25ER-R410A18, CAHE25ER-R410A19, CAHWE12E-R410A1

Easytry123 Replacement Remote Control User Manual

For Crosley Window Room Air Conditioners

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Easytry123 replacement remote control. This remote is designed to be compatible with various Crosley window room air conditioner models. Please ensure your original remote matches the appearance of this replacement for full compatibility.

2. Setup and Battery Installation

Before using your new remote control, batteries must be installed correctly.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) CR2 batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Figure 2.1: Back view of the remote control, illustrating the battery compartment location.

Important: This replacement remote is designed to function similarly to your original remote. If your air conditioner model is not listed in the product title, or if your original remote differs significantly in appearance, some functions may not be fully compatible.

3. Operating Instructions

Point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the unit.



Figure 3.1: Front view of the remote control, displaying all operational buttons.



Figure 3.2: Angled view of the remote control.

Button Functions:

- **Power (①):** Turns the air conditioner ON or OFF.
- **TEMP/TIMER (▲ / ▼):** Adjusts the temperature setting or sets the timer.
- **FAN-** / **FAN+:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **COOL:** Activates the cooling mode.
- **ENERGY SAVER:** Engages the energy-saving mode, typically cycling the compressor to maintain temperature efficiently.
- **FAN ONLY:** Operates the unit as a fan without cooling.
- **SLEEP:** Activates sleep mode, which often adjusts temperature and fan speed for comfortable sleep and energy savings.
- **AUTO FAN:** Allows the air conditioner to automatically select the appropriate fan speed based on the room temperature.
- **TIMER:** Sets a specific time for the air conditioner to turn ON or OFF.

4. Maintenance

Proper maintenance ensures the longevity and reliable operation of your remote control.

- **Battery Replacement:** Replace batteries when the remote's range decreases or if the air conditioner does not respond to commands. Always replace both batteries simultaneously with new ones of the same type (CR2).
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or solvents, as these can damage the remote's surface or internal components.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are installed correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.
  - Confirm you are within the effective operating range of the air conditioner.
- **Limited Functionality:**
  - This is a replacement remote. While designed for broad compatibility, it may not replicate every single function of your original remote, especially if your original remote had unique features not present on this model.
  - Verify that your air conditioner model is among those listed as compatible.

6. Specifications

Brand	Easytry123
Compatible Devices	Crosley Window Room Air Conditioners
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Batteries Required	2 x CR2 (not included)
Compatible Models	CAHE8ER-R410A17, CAHWE12E-R410A, CAHWE12E-R410A10, CAHE25ER-R410A17, CAHE25ER-R410A18, CAHE25ER-R410A19, CAHWE12E-R410A11

7. Warranty and Support

This product is a replacement remote control. Specific warranty details are not provided with the product itself. For any questions, concerns, or troubleshooting assistance beyond the scope of this manual, please contact the seller directly through your purchase platform. It is recommended to retain your purchase receipt for any potential support inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088LT4WNY

More documents and user manuals: **https://manuals.plus/**