**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## RCA U832CHA

# RCA U832CHA USB-C 3.1 to HDMI Adapter User Manual

Model: U832CHA

### Introduction

The RCA U832CHA USB-C 3.1 to HDMI Adapter allows you to connect a USB-C enabled device, such as a laptop or smartphone, to an HDMI display, monitor, or projector. This adapter supports 2160p resolution, providing high-quality video output for an enhanced viewing experience.

Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

### Package Contents

- 1 x RCA U832CHA USB-C 3.1 to HDMI Adapter

### Setup Instructions

1. **Connect the USB-C End:** Insert the USB-C connector of the adapter into the USB-C port on your source device (e.g., laptop, tablet, smartphone). Ensure the connection is firm.

   This image shows the USB-C connector end of the RCA U832CHA adapter, which plugs into your source device.





2. **Connect the HDMI End:** Connect a standard HDMI cable (not included) to the HDMI port on the RCA U832CHA adapter.
3. **Connect to Display:** Connect the other end of the HDMI cable to the HDMI input port on your display device (e.g., TV, monitor, projector).

   This image displays the HDMI port on the RCA U832CHA adapter, where an HDMI cable connects to your display.



4. **Select Input:** On your display device, select the correct HDMI input source using its remote control or on-screen menu.
5. **Display Output:** Your source device's display should now be mirrored or extended to the connected HDMI display.

## Operating Instructions

Once connected, the RCA U832CHA adapter operates automatically. Your USB-C device should detect the external display and output video and audio signals through the HDMI connection.

- **Resolution Support:** The adapter supports video resolutions up to 2160p (4K), providing a clear and detailed picture on compatible displays.
- **Display Modes:** Depending on your source device's operating system, you can typically configure the display mode (e.g., mirror display, extend display) through your device's display settings.
- **Audio Output:** Audio is typically transmitted along with video through the HDMI connection. Ensure your display device's audio is properly configured.

## Care and Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Avoid using liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

- **Handling:** Avoid bending or twisting the cable excessively. Do not drop the adapter or subject it to strong impacts.
- **Moisture:** Keep the adapter away from water and high humidity to prevent damage.

## Troubleshooting

**No display on the monitor/TV:**

- Ensure all connections (USB-C, HDMI cable to adapter, HDMI cable to display) are secure.
- Verify that the display device is powered on and set to the correct HDMI input source.
- Check your source device's display settings to ensure it is configured to output to an external display.
- Try connecting the adapter to a different USB-C port on your source device, if available.
- Test with a different HDMI cable or display to rule out issues with those components.

**Poor video quality or flickering display:**

- Ensure your HDMI cable is of good quality and supports the desired resolution.
- Check your source device's display settings for resolution and refresh rate. Adjust if necessary.
- Ensure your display device supports the output resolution from your source device.

**No audio output:**

- Verify that your display device has built-in speakers or is connected to external audio.
- Check your source device's sound settings to ensure audio is directed to the HDMI output.
- Adjust the volume on both your source device and the display device.

## Product Specifications

| | |
|---|---|
| **Model Number** | U832CHA |
| **Brand** | RCA |
| **Connector Type** | USB-C (Input), HDMI (Output) |
| **Supported Resolution** | Up to 2160p (4K) |
| **Color** | White |
| **Item Dimensions (L x W x H)** | 8 x 1.77 x 0.59 inches |
| **Number of Ports** | 1 (HDMI) |
| **Compatible Devices** | Monitor, Projector, TV, Laptop, Desktop with USB-C output |

## Warranty Information

This RCA U832CHA USB-C 3.1 to HDMI Adapter is covered by a manufacturer's warranty. For specific details regarding warranty duration and terms, please refer to the documentation included with your purchase or contact RCA customer support.

## Customer Support

If you encounter any issues or have questions not covered in this manual, please contact RCA customer support for assistance.

You can also visit the official RCA store for more product information and support resources:

**Visit the RCA Store**

© 2023 RCA. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B088MFYSVX**

More documents and user manuals: **https://manuals.plus/**