Innsky 1.8L Electric Air Fryer

Innsky 1.8L Electric Air Fryer User Manual

Model: 1.8L Electric Air Fryer

Introduction

The Innsky 1.8L Electric Air Fryer utilizes 360° high-speed hot air circulation to cook food, allowing you to enjoy delicious fried dishes with up to 80% less fat. This appliance is designed for healthy cooking, preserving nutrients while delivering crispy results. Its compact size is ideal for 1-2 people, making it a convenient addition to any kitchen.



Image: The Innsky 1.8L Air Fryer shown with a variety of healthy, air-fried meals, demonstrating its versatility.

Safety Instructions

Please read all safety instructions carefully before using the appliance to prevent injury or damage. Keep this manual for future reference.

- This air fryer operates in a closed state, eliminating concerns about oil splatters and reducing fire risks associated with abnormal voltage due to overheat protection.
- The power automatically cuts off when the basket is removed and resumes when reinserted, allowing for safe seasoning or checking food during cooking.
- Do not immerse the main unit in water or any other liquid.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from flammable materials.
- Do not block the air inlet or outlet vents during operation.
- Always unplug the appliance when not in use and before cleaning.



Image: The air fryer highlighting its built-in safety mechanisms, including overheat protection.

Product Overview

The Innsky 1.8L Electric Air Fryer features an intuitive LED touch panel with an ergonomic tilted design for easy operation. The compact 1.8L capacity is suitable for 1-2 servings.

Components:

- Main Unit with LED Display
- Removable Non-Stick Basket
- Handle
- Air Inlet and Outlet Vents



Image: A clear view of the Innsky 1.8L Air Fryer, showcasing its sleek design and LED display.

Control Panel:

The LED touch panel provides easy access to various settings and presets.



Image: Detailed view of the LED touch panel, indicating temperature and time controls, along with icons for 7 cooking presets.

Setup

Follow these steps for initial setup:

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.

2. **Clean:** Wash the removable non-stick basket and pan with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides, and above the appliance for proper air circulation.
4. **Power:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

This section guides you through using your Innsky Air Fryer.

1. **Preheating:** The air fryer features a warm-up function. Once settings are applied, heating begins promptly.
2. **Loading Food:** Place ingredients into the non-stick basket. Do not overfill the basket to ensure even cooking.
3. **Selecting Settings:** Use the LED touch panel to select one of the 7 preset cooking functions (e.g., potato chips, steak, chicken, shrimp) or manually adjust the temperature (80°C to 200°C) and time (0 to 60 minutes) as needed.
4. **Cooking:** Press the start button to begin cooking. The appliance will automatically pause if the basket is removed and resume when reinserted, allowing for convenient checking or seasoning of food.
5. **Shaking/Tossing:** For optimal and even cooking, it is recommended to shake or toss ingredients halfway through the cooking process.
6. **Completion:** The air fryer will signal when the cooking cycle is complete. Carefully remove the basket using the handle and transfer the cooked food to a serving dish.



Image: Illustration of the 360° high-speed hot air circulation technology and 1230W power, ensuring efficient and even cooking.

Maintenance and Cleaning

Proper maintenance ensures the longevity and hygiene of your air fryer.

- **Cool Down:** Always allow the appliance to cool down completely before cleaning.

- **Basket and Pan:** The non-stick basket and pan are dishwasher-safe. Alternatively, they can be washed by hand with warm water, a mild dish soap, and a soft sponge. Avoid using abrasive cleaning tools or harsh chemicals that could damage the non-stick coating.
- **Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Interior:** Clean the interior of the appliance with a damp cloth. For stubborn residue, use a soft brush.
- **Storage:** Ensure all parts are dry before storing the air fryer in a cool, dry place.



Image: The removable non-stick basket being easily cleaned under running water, highlighting its user-friendly design.

Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet malfunction	Ensure the power cord is securely plugged into a working outlet.
Food not cooked evenly	Basket overloaded; Food not shaken	Do not overload the basket. Shake or toss ingredients halfway through cooking.
White smoke from appliance	Grease residue from previous use; Fatty ingredients	Clean the basket and pan thoroughly after each use. For fatty foods, drain excess oil.
LED touch screen unresponsive	Temporary electronic glitch	Unplug the unit from the power outlet, wait for a few minutes, then plug it back in.

If the issue persists after attempting these solutions, please contact customer support.

Specifications

Detailed technical specifications for the Innsky 1.8L Electric Air Fryer.

Feature	Detail
Brand	Innsky
Model	1.8L Electric Air Fryer
Capacity	1.8 Liters
Color	Black
Wattage	1230 W
Product Dimensions	30 cm (Depth) x 31.4 cm (Width) x 23.2 cm (Height)
Item Weight	2.67 kg
Package Dimensions	36.8 x 29.6 x 29.4 cm
Package Weight	3.86 kg
Battery Use	No
ASIN	B088P1NWLG



Image: A diagram illustrating the compact dimensions of the air fryer and its basket, suitable for small spaces.

Warranty and Support

Innsky is committed to providing high-quality products and customer satisfaction.

- **Warranty:** Your Innsky 1.8L Electric Air Fryer comes with an 18-month warranty. This warranty can be extended by an

additional 12 months upon product registration on our official website.

- **Customer Support:** For any product inquiries, technical assistance, or warranty claims, please contact our 24-hour customer support team.
- **Contact Information:** Please refer to the official Innsky website or your purchase documentation for the most up-to-date contact details.

© 2025 Innsky. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question