Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 50 CT LED Multicolored Mini Lights


Holiday Living 50 CT LED Multicolored Mini Lights Instruction Manual

Model: 50 CT LED Multicolored Mini Lights

Brand: Holiday Living

1. Introduction

This manual provides essential information for the safe and effective use of your Holiday Living 50 CT LED Multicolored Mini Lights. Please read all instructions carefully before installation and operation to ensure proper function and safety.





The product packaging highlights key features including the 50-count LED multicolored mini lights, suitability for indoor and outdoor use, an estimated burn time of 25,000 hours, a total length of 12.7 feet, and a 3-year limited warranty.

2. Important Safety Instructions

When using electrical products, basic precautions should always be followed, including the following:

- Read and follow all instructions provided with the product.
- Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- This product is not a toy. Keep out of reach of children.
- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or tacks.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper, or any material not part of the product when in use.
- This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit condition. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit condition may be present and the

product should be discarded.

- Read and follow all instructions that are on the product or provided with the product.

3. Setup and Installation

These LED mini lights are designed for both indoor and outdoor use. Proper installation ensures safety and longevity.

3.1 Outdoor Installation Considerations

- Ensure the power outlet used is a Ground Fault Circuit Interrupting (GFCI) type. If not, consult a qualified electrician for installation.
- Avoid placing lights in areas where they might be submerged in water or exposed to excessive moisture.
- Secure lights properly to prevent wind damage or accidental dislodgement.

3.2 Indoor Installation Considerations

- Keep lights away from heat sources such as heaters, fireplaces, or candles.
- Do not cover lights with flammable materials like cloth or paper.
- Ensure proper ventilation around the lights.

3.3 Connecting Multiple Strings

Refer to the product's specific labeling for the maximum number of light strings that can be safely connected end-to-end. Do not exceed the recommended limit to prevent electrical overload.

4. Operating Instructions

4.1 Powering On/Off

To operate the lights, simply plug the cord into a suitable electrical outlet. To turn off, unplug the cord from the outlet.

4.2 Estimated Burn Hours

These LED lights have an estimated burn life of 25,000 hours. This is an estimate and actual lifespan may vary based on usage conditions.

5. Maintenance and Storage

5.1 Cleaning

Before cleaning, always unplug the light string from the power source. Wipe the lights and cord with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

5.2 Fuse Replacement

This product is equipped with an overload protection fuse. If the lights stop working, a fuse replacement may be necessary.

1. Unplug the product from the power outlet.
2. Identify the fuse compartment, typically located in the plug.
3. Slide open the fuse access cover.
4. Carefully remove the old fuse.
5. Replace with a new fuse of the same type and rating (refer to product marking for specific fuse rating).
6. Close the fuse access cover.
7. Plug the product back into the outlet. If the new fuse blows, discontinue use and discard the product.

5.3 Storage

When not in use, store the light string in a cool, dry place, away from direct sunlight and extreme temperatures. Coil the string neatly to prevent tangling and damage to the wires or bulbs.

6. Troubleshooting

6.1 Common Issues and Solutions

- **Lights do not turn on:**
  - Check if the plug is securely inserted into the outlet.
  - Verify the power outlet is functional by testing with another device.
  - Inspect the fuse in the plug and replace if blown (refer to Maintenance section).
  - Check for any visible damage to the cord or bulbs.
- **Some lights are out:**
  - LED lights are generally designed so that if one bulb goes out, the rest of the string remains lit. However, check for any loose or damaged bulbs and ensure they are properly seated.
- **Lights flicker:**
  - Ensure all connections are secure.
  - Avoid connecting too many strings together, which can cause an overload.

If troubleshooting steps do not resolve the issue, contact customer support.

7. Specifications

7.1 Product Details

Feature	Detail
Brand	Holiday Living
Model	50 CT LED Multicolored Mini Lights
Number of Lights	50
Light Type	LED
Light Color	Multicolored
Total Length	12.7 ft (3.87 m)
Power Source	Corded Electric
Estimated Burn Hours	25,000
Usage	Indoor and Outdoor
ASIN	B088TXCZ5H
Manufacturer Model Number	0864730

8. Warranty Information

8.1 Limited Warranty

This Holiday Living product comes with a 3-year limited warranty. For specific terms and conditions, please refer to the

warranty card included with your purchase or contact customer support. The warranty covers defects in materials and workmanship under normal use.

9. Customer Support

9.1 Contact Information

For further assistance, technical support, or warranty claims, please contact Holiday Living customer service.
Please refer to your product packaging or the retailer's website for the most current contact details.

© 2023 Holiday Living. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088TXCZ5H

More documents and user manuals: **https://manuals.plus/**