Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

tectake 402923-NL

tectake Camping Cabinet (Model 402923-NL)

User Manual

Introduction

Thank you for choosing the tectake Camping Cabinet. This versatile and portable cabinet is designed to enhance your outdoor experience by providing organized storage and a stable workspace for cooking and food preparation. Its robust construction and thoughtful features make it an ideal companion for camping, caravanning, or any outdoor adventure.

Safety Instructions

- Always assemble the cabinet on a flat, stable surface to prevent tipping.
- Do not exceed the maximum load capacity of 30 kg for the work surface.
- Keep children and pets away during assembly to avoid injury.
- Ensure all locking mechanisms are securely engaged before use.
- Avoid placing hot items directly on the work surface without protection.
- Do not use the cabinet as a step stool or climbing aid.

Setup Instructions

The tectake Camping Cabinet features a simple click mechanism for quick and easy assembly. No tools are required.

1. **Unfold the Frame:** Carefully remove the cabinet from its transport bag. Unfold the aluminum frame until it locks into place.
2. **Attach the Fabric Body:** Drape the fabric body over the frame, ensuring it aligns correctly with the support poles.
3. **Insert Shelves:** Place the reinforced aluminum plates into the designated compartments to form the shelves. Ensure they sit firmly.
4. **Secure the Work Surface:** Position the robust MDF work surface on top of the frame, ensuring it is stable.
5. **Adjust Feet:** Adjust the height of the anti-slip plastic feet as needed to ensure perfect stability on uneven terrain. Turn the feet clockwise or counter-clockwise to raise or lower the cabinet.



Image: The fully assembled tectake camping cabinet, showcasing its spacious compartments and sturdy work surface.



Image: Detail of the simple click mechanism, highlighting the ease of assembly without tools.

Operating Instructions

This camping cabinet is designed for efficient organization and use in outdoor environments.

- **Storage:** Utilize the six spacious compartments with reinforced aluminum plates for storing dishes, food, cooking utensils, and other camping gear. The compartments feature zipper closures to keep contents secure and protected.
- **Work Surface:** The robust work surface provides a stable area for food preparation, cooking with a portable stove, or serving meals.
- **Side Pockets:** The exterior side pocket, divided into three spaces, is ideal for quick access to smaller items like cutlery, spices, or cleaning cloths.
- **Ventilation:** The mesh fabric back ensures optimal air circulation within the cabinet, helping to keep stored items fresh and prevent moisture buildup.



Image: The camping cabinet in an outdoor setting, demonstrating its use for storing food, dishes, and providing a cooking surface.

ALTIJD PERFECT

Uitgerust

De 6 afsluitbare vakken, waarvan de bodems versterkt zijn met aluminium platen, bieden veel opbergruimte voor servies, pannen, voedsel, enz.



Image: A detailed view of the practical side pockets, perfect for organizing smaller kitchen tools and accessories.

Maintenance

- **Cleaning:** Wipe the aluminum frame and MDF work surface with a damp cloth and mild detergent. For the fabric parts, spot clean with a gentle soap and water solution. Allow to air dry completely before folding and storing.
- **Storage:** When not in use, disassemble the cabinet and store it in its included transport bag in a dry, cool place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all frame connections and fabric for any signs of wear or damage. Replace any damaged parts immediately to ensure safety and stability.

Troubleshooting

- **Cabinet is unstable:** Ensure all frame connections are fully engaged. Check that the adjustable feet are properly extended and adjusted to compensate for uneven ground.
- **Difficulty folding/unfolding:** Ensure no fabric or items are obstructing the frame's folding mechanism. Apply gentle, even

pressure.

- **Zippers are stuck:** Do not force zippers. Try lubricating them with a zipper lubricant or a pencil lead. Ensure the fabric is not caught in the zipper teeth.

Specifications

Model Number	402923-NL
Color	Grey
Total Dimensions (unfolded)	97 x 47.5 x 78 cm (L x W x H)
Folded Dimensions	97 x 14 x 47.5 cm (L x W x H)
Work Surface Load Capacity	30 kg
Weight	Approx. 8.5 kg
Material	Aluminum frame, MDF work surface, 100% Polyester fabric
Compartment Opening	36 x 58 cm
Upper/Middle/Lower Compartment Dimensions	42.5 x 40.5 x 23 / 22 / 21 cm
Adjustable Feet Range	Up to 1.5 cm

All dimensions are approximate.



Image: Detailed product information and dimensions of the camping cabinet, including its folded state in a carry bag.

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact tectake customer service directly. Refer to your purchase documentation for specific warranty terms and contact details.

You can often find support information on the official tectake website or through the retailer where you purchased the product.

Online Resources: For additional information and FAQs, please visit the tectake brand page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088TXXZQJ

More documents and user manuals: **https://manuals.plus/**