EuropAce ERJ 7152V

EuropAce Low Carb Steam Rice Cooker ERJ 7152V Instruction Manual

Model: ERJ 7152V | Brand: EuropAce

Introduction

Thank you for purchasing the EuropAce Low Carb Steam Rice Cooker ERJ 7152V. This appliance is designed to cook rice efficiently while reducing carbohydrate content through its unique 3-stage cooking process: Cook, Drain, and Steam. Please read this manual thoroughly before operating the appliance to ensure safe and proper use. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- This appliance is for household use only.

Product Components

The EuropAce Low Carb Steam Rice Cooker ERJ 7152V comes with the following components:

- Main Rice Cooker Unit
- Inner Pot (for cooking rice)
- Low Carb Steaming Basket (perforated, for draining starch)
- Measuring Cup
- Rice Paddle
- Power Cord
- Steam Vent Cover



Image: All components of the EuropAce ERJ 7152V rice cooker laid out, showing the main unit, inner pot, low carb steaming basket, measuring cup, rice paddle, and power cord.

Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and accessories.
2. **Clean:** Wash the inner pot, low carb steaming basket, measuring cup, and rice paddle with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, level, heat-resistant surface, away from direct sunlight and heat

sources. Ensure adequate ventilation around the appliance.

4. **Power Connection:** Ensure the voltage of your power supply matches the rating label on the appliance (220 Volts). Plug the power cord into the rice cooker, then into a grounded wall outlet.

Operating Instructions

General Rice Cooking (Standard Mode)

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. Rinse the rice thoroughly under cold water until the water runs clear.
2. **Add Rice to Inner Pot:** Place the rinsed rice into the inner pot.
3. **Add Water:** Add the appropriate amount of water according to the rice type and desired consistency. A general ratio is 1 cup of rice to 1.5-2 cups of water. Refer to the water level markings inside the inner pot.
4. **Place Inner Pot:** Place the inner pot into the main rice cooker unit. Ensure it is seated correctly.
5. **Close Lid:** Close the lid securely.
6. **Start Cooking:** Plug in the appliance. Select the desired cooking function (e.g., "Cook" or "Rice" if available, or simply press the start button for automatic cooking). The cooker will automatically switch to "Keep Warm" once cooking is complete.
7. **Serve:** Once the "Keep Warm" indicator lights up, allow the rice to rest for 10-15 minutes before serving for best results. Use the provided rice paddle to fluff and serve.

Low Carb Rice Cooking (3-Stage Process: Cook, Drain, Steam)

This unique feature helps reduce carbohydrate content by draining excess starch during the cooking process.

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. Rinse the rice thoroughly.
2. **Place Rice in Steaming Basket:** Put the rinsed rice into the low carb steaming basket.
3. **Add Water to Inner Pot:** Place the steaming basket with rice into the inner pot. Add water to the inner pot, ensuring the water level is below the top of the steaming basket. The water level markings for low carb cooking may be different; consult the specific markings or recipe.
4. **Place Inner Pot:** Insert the inner pot with the steaming basket into the main rice cooker unit.
5. **Close Lid:** Close the lid securely.
6. **Select Low Carb Function:** Plug in the appliance and select the "Low Carb" or "Steam Rice" function. The cooker will automatically perform the 3 stages:
    - **Cook:** Initial cooking phase.
    - **Drain:** Excess starchy water is drained into the outer pot.
    - **Steam:** Final steaming phase to perfect the rice texture.
7. **Serve:** Once cooking is complete and the cooker switches to "Keep Warm", allow the rice to rest for a few minutes. Carefully remove the steaming basket and serve the low carb rice.

Steaming Other Foods

The low carb steaming basket can also be used to steam vegetables, fish, or other foods.

1. **Add Water:** Pour water into the inner pot (do not exceed the maximum fill line).
2. **Prepare Food:** Place the food to be steamed into the low carb steaming basket.
3. **Steam:** Place the steaming basket into the inner pot, then place the inner pot into the main unit. Close the lid.

Select the "Steam" function (if available) or a general cooking function and monitor the steaming process.

4. **Serve:** Carefully remove the steamed food once cooked.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your rice cooker. Always unplug the appliance and allow it to cool completely before cleaning.

- **Inner Pot and Steaming Basket:** Wash these parts with warm, soapy water using a soft sponge. Rinse thoroughly and dry. Do not use abrasive cleaners or metal scrubbers, as they can damage the non-stick coating.
- **Main Unit Exterior:** Wipe the exterior with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Lid and Steam Vent:** Clean the inside of the lid and the steam vent regularly to prevent food residue buildup. The steam vent cover may be removable for easier cleaning.
- **Water Collector (if applicable):** Some models have a water collector for condensation. Empty and clean it after each use.
- **Storage:** Store the cleaned and dried rice cooker in a cool, dry place.

Product care instructions: Hand Wash for removable parts.

Troubleshooting

Problem	Possible Cause	Solution
Rice is undercooked or too hard.	Not enough water; lid not closed properly; power interruption.	Add more water next time; ensure lid is sealed; check power supply.
Rice is overcooked or mushy.	Too much water; rice not rinsed properly.	Reduce water next time; rinse rice thoroughly before cooking.
Water overflowing during cooking.	Too much water; steam vent blocked.	Do not exceed maximum water level; clean steam vent.
"Keep Warm" light not activating.	Appliance malfunction.	Contact customer support.
Appliance does not turn on.	No power; faulty power cord/outlet.	Check power connection and outlet; ensure cord is not damaged.

Specifications

- **Model:** ERJ 7152V
- **Brand:** EuropAce
- **Capacity:** 1.5 Litres
- **Voltage:** 220 Volts
- **Special Features:** Automatic Cooking, One-Touch Operation, Steam Vent, 3 Stage Cooking (Cook, Drain, Steam)
- **Included Components:** 1 x Rice Cooker (Main Unit, Inner Pot, Low Carb Steaming Basket, Measuring Cup, Rice Paddle, Power Cord)
- **Product Care:** Hand Wash for removable parts



Image: Side view of the EuropAce ERJ 7152V rice cooker with a ruler indicating its height is approximately 12 inches (30 cm).

Warranty and Support

This EuropAce Low Carb Steam Rice Cooker ERJ 7152V comes with a**2 Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical support, service, or warranty inquiries, please contact EuropAce customer service. Refer to the official EuropAce website or your purchase documentation for contact details.
EuropAce Official Website: www.europace.com.sg

© 2023 EuropAce. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question