Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CAMRY CR 1290

CAMRY CR 1290 Glass Kettle with Tea Infuser and Temperature Control User Manual

Model: CR 1290 | Brand: CAMRY

1. Important Safety Instructions

Please read these instructions carefully before using the appliance and keep them for future reference. Incorrect use may lead to electric shock, fire, or serious injury.

- Do not immerse the kettle, power base, or power cord in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Always place the kettle on a stable, flat, heat-resistant surface.
- Do not fill the kettle above the MAX level or below the MIN level to prevent boiling dry or splashing.
- Exercise caution when pouring hot water.
- Unplug the kettle from the power outlet when not in use and before cleaning.
- This appliance is intended for household use only.

2. Product Overview

The CAMRY CR 1290 is a versatile glass kettle designed for heating water and brewing tea. It features a durable glass body, a removable stainless steel tea infuser, and precise temperature control.



Figure 2.1: CAMRY CR 1290 Glass Kettle with water and tea infuser. This image shows the kettle filled with water, highlighting the transparent glass body and the internal tea infuser.

Components:

- **Glass Kettle Body:** Transparent, allowing visibility of water level and boiling process.
- **Lid:** Removable for easy filling and cleaning.
- **Handle with Control Panel:** Ergonomically designed handle housing temperature selection buttons and power button.
- **Removable Tea Infuser:** Stainless steel mesh basket for brewing loose leaf tea or herbal infusions.
- **Power Base:** 360° rotational base with power cord storage.

- **Water Level Indicator:** Markings for MIN, 1.2L, and MAX (2.0L).
- **LED Illumination:** Changes color to indicate selected temperature.



Figure 2.2: Exploded view of the CAMRY CR 1290 Glass Kettle components. This image displays the kettle body, lid, tea infuser, and power base separated, illustrating each part.

3. Setup and First Use

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water up to the MAX level. Boil the water and then discard it. Repeat this process 2-3 times to remove any manufacturing residues. Wipe the exterior with a damp cloth.
3. **Positioning:** Place the power base on a dry, flat, and stable surface away from the edge of the countertop. Ensure the power cord is

not dangling or in contact with hot surfaces.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

4.1. Boiling Water

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below MIN or above MAX (2.0L). Close the lid securely.
2. **Place on Base:** Place the kettle firmly on the power base.
3. **Select Temperature:** Press the power button ( ) once to turn on. Use the temperature selection buttons (**+** / **-**) on the handle to choose your desired temperature (60°C, 70°C, 80°C, 90°C, 100°C). The LED illumination will change color to indicate the selected temperature.
4. **Start Heating:** The kettle will automatically start heating the water to the selected temperature. The LED light will remain illuminated during heating.



Figure 4.1: Close-up of the kettle handle showing the power button and temperature selection buttons (60-100°C) with an illuminated LED indicator.



Figure 4.2: The CAMRY CR 1290 Glass Kettle illuminated with blue LED light, indicating heating or a specific temperature setting.

5. **Automatic Shut-off:** Once the water reaches the set temperature, the kettle will automatically switch off, and the LED light will turn off or switch to keep-warm mode if activated.

4.2. Using the Tea Infuser

The removable tea infuser allows for direct brewing of loose leaf tea or herbal infusions within the kettle.

1. **Prepare Infuser:** Open the lid and place your desired amount of loose leaf tea or herbs into the stainless steel infuser basket.
2. **Insert Infuser:** Securely attach the infuser to the lid or place it directly into the kettle, ensuring it is properly seated.

3. **Fill and Heat:** Fill the kettle with water and select the appropriate temperature for your tea (e.g., 80°C for green tea, 90°C for black tea).
4. **Brewing:** Allow the tea to steep for the recommended time.
5. **Remove Infuser:** Once brewing is complete, carefully remove the lid with the infuser attached to prevent over-steeping.



Figure 4.3: CAMRY CR 1290 Glass Kettle with the tea infuser inserted. This image shows the stainless steel infuser basket positioned inside the kettle.

4.3. Keep Warm Function

The kettle features a 2-hour keep warm function to maintain the water at the selected temperature.

- After selecting a temperature and the kettle reaches it, the keep warm function can be activated (refer to specific button on control panel, usually a separate press or a long press of the power button after reaching temperature).
- The kettle will cycle on and off to maintain the water temperature for up to 2 hours.
- To deactivate, press the power button again or lift the kettle from its base.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your kettle.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely.
2. **Exterior Cleaning:** Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
3. **Interior Cleaning:** The interior of the kettle can be cleaned with a soft brush or sponge. Rinse thoroughly with clean water.
4. **Tea Infuser Cleaning:** Remove the tea infuser and rinse it under running water. Use a small brush if necessary to remove tea leaves. It is dishwasher safe.
5. **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
    - Fill the kettle with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution.
    - Boil the mixture and let it stand for at least 30 minutes, or longer for heavy deposits.
    - Discard the mixture and rinse the kettle thoroughly several times with fresh water.
    - Boil fresh water 2-3 times and discard to remove any residual vinegar taste.

6. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in. Kettle not properly seated on base. No power at outlet. Automatic shut-off activated.	Ensure power cord is securely plugged into a working outlet. Place kettle firmly on the power base. Check household circuit breaker or try another outlet. Press the power button to restart.
Water has an unusual taste.	New appliance odor. Limescale buildup.	Perform initial cleaning steps (boil and discard water several times). Descale the kettle as per maintenance instructions.
Kettle switches off before boiling.	Limescale buildup. Kettle is dry boiling.	Descale the kettle. Ensure water level is above MIN.
LED light not working.	Kettle not powered on. Malfunction.	Ensure kettle is powered on and heating. Contact customer support if problem persists.

7. Specifications

Model Number	CR 1290
Brand	CAMRY
Capacity	2 Liters
Power	2200 Watts

Voltage	120 Volts
Material	Stainless Steel, Plastic, Glass
Dimensions (L x W x H)	60 x 60 x 85 cm (Product); 17.2L x 11W x 18.4H cm (Approximate)
Weight	1 Kilogram
Automatic Shut-off	Yes
Noise Level	44 dB
Special Features	Temperature Control, Tea Infuser, Keep Warm Function, LED Illumination

Note: Specifications are subject to change without prior notice for product improvement.

8. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact CAMRY customer service directly.
Please have your model number (CR 1290) and purchase date available when contacting support.
Online Resources: Visit the official CAMRY website for additional product information, FAQs, and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088ZWJX31

More documents and user manuals: **https://manuals.plus/**