Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ CLE-996E, CLU-264C, CLE-876F, CLE-876G, CLE-878, CLE-884A, CLE-884B, CLE-886

HCDZ Replacement Remote Control User Manual

For Hitachi LCD LED Television Models: CLE-996E, CLU-264C, CLE-876F, CLE-876G, CLE-878, CLE-884A, CLE-884B, CLE-886

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your HCDZ Replacement Remote Control. This remote is designed to function as a direct replacement for various Hitachi LCD LED television models, requiring no programming. Simply insert batteries, and it is ready for use.

Package Contents

- 1 x HCDZ Replacement Remote Control
- *Note: Batteries and additional instructions are not included in the package.*

Setup

1. Battery Installation

The remote control requires two (2) AA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with cover removed, showing where to insert AA batteries.

Once batteries are correctly installed, the remote control is ready for immediate use with your compatible Hitachi television. No programming or pairing is required.

Operating Instructions

This replacement remote control functions identically to your original Hitachi remote. Point the remote directly at your television's infrared receiver for optimal performance.



Figure 2: Front view of the HCDZ Replacement Remote Control, displaying its button layout.

Basic Functions

- **Power Button:** Turns the television on or off.
- **Channel Buttons (CH+/CH-):** Changes the television channel up or down.
- **Volume Buttons (VOL+/VOL-):** Increases or decreases the television volume.
- **Mute Button:** Silences the television audio.
- **Input/Source Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Number Buttons (0-9):** Directly selects television channels.
- **Menu Button:** Accesses the television's on-screen menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Navigates through on-screen menus and confirms selections.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

- **Environment:** Avoid exposing the remote control to extreme temperatures, direct sunlight, or high humidity.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AA batteries.
  - Ensure there are no obstructions between the remote control and the television's infrared receiver.
  - Confirm the remote is pointed directly at the television.
- **Limited range or intermittent response:**
  - Ensure batteries are fresh.
  - Reduce the distance between the remote and the television.
  - Check for strong light sources (like direct sunlight or bright fluorescent lights) that might interfere with the infrared signal.
- **Specific buttons not working:**
  - Clean the remote control surface, especially around the buttons, to remove any dirt or debris.
  - If only certain buttons fail, it might indicate internal damage; consider replacing the remote.

Specifications

Feature	Detail
Brand	HCDZ
Compatible Devices	Hitachi LCD LED Televisions
Compatible Models	CLE-996E, CLU-264C, CLE-876F, CLE-876G, CLE-878, CLE-884A, CLE-884B, CLE-886
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Special Feature	No programming needed, works out of package
Batteries Required	2 x AA batteries (not included)

Support

If you encounter issues not covered in this manual or require further assistance, please refer to the product listing where you purchased the remote control for seller contact information. For general television functions, consult your Hitachi television's

original user manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088ZXB69X

More documents and user manuals: **https://manuals.plus/**