Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SanDisk Extreme PRO

SanDisk Extreme PRO 128GB CFexpress Type-B Memory Card User Manual

Model: Extreme PRO

1. Introduction

The SanDisk Extreme PRO 128GB CFexpress Type-B Memory Card is engineered to deliver blazing-fast speeds for professional photographers and videographers. Designed for high-end cameras, this card provides exceptional performance for capturing high-resolution photos and RAW 4K video with sustained speed and reliability.



Figure 1: Front view of the SanDisk Extreme PRO 128GB CFexpress Type-B Memory Card. The card features the SanDisk Extreme PRO branding, CFexpress logo, and indicates 128GB capacity with read speeds up to 1700 MB/s and write speeds up to 1200 MB/s.

Key Features:

- Up to 1700MB/s read and 1200MB/s write speeds for 128GB capacity.
- Enables smooth, RAW 4K video recording with sustainable performance.
- Backwards-compatible with select XQD cameras.
- Includes RescuePRO Deluxe Recovery Software (download required).
- Waterproof design for enhanced durability.

2. Setup

2.1 Compatibility

This CFexpress Type-B card is designed for use with compatible cameras and devices that support the CFexpress Type-

B standard. It is particularly suited for high-end mirrorless cameras and professional video cameras. Please consult your device's user manual to confirm CFexpress Type-B compatibility.

2.2 Inserting the Memory Card

1. Locate the CFexpress Type-B card slot on your camera or device.
2. Orient the SanDisk Extreme PRO CFexpress card correctly, ensuring the gold contacts face the correct direction as indicated by your device.
3. Gently insert the card into the slot until it clicks into place. Do not force the card, as this may cause damage.

2.3 Formatting the Memory Card

For optimal performance and to ensure compatibility with your specific device, it is recommended to format the memory card directly within your camera or device before initial use. Formatting will erase all data on the card, so ensure any important files are backed up beforehand.

1. Turn on your camera or device.
2. Navigate to the menu settings, typically under 'Setup' or 'System'.
3. Locate the 'Format Card' or 'Format Memory' option.
4. Confirm the formatting process.

3. Operation

3.1 Data Transfer Speeds

The SanDisk Extreme PRO CFexpress Type-B card boasts impressive read speeds of up to 1700 MB/s and write speeds of up to 1200 MB/s. These speeds are crucial for:

- Rapid burst-mode shooting of high-resolution still images.
- Seamless recording of RAW 4K and higher resolution video without dropped frames.
- Quick offloading of large files to your computer for efficient post-production workflows.

3.2 Usage with Cameras

Once inserted and formatted, the card is ready for use. Your camera will automatically detect the card and utilize its capabilities for photo and video storage. Ensure your camera's firmware is up to date to maximize compatibility and performance with CFexpress Type-B cards.

3.3 Removing the Memory Card

Always ensure your device is powered off or that the card is safely ejected through the device's menu system before physically removing it. This prevents data corruption and damage to the card or device.

4. Maintenance

4.1 Card Care and Handling

- Keep the card clean and free from dust and debris.
- Avoid touching the gold contacts.
- Store the card in a protective case when not in use.

- The card is designed to be waterproof, but avoid prolonged submersion or exposure to extreme conditions.

4.2 Data Recovery Software

The SanDisk Extreme PRO CFexpress card includes an offer for RescuePRO Deluxe data recovery software. In the event of accidental deletion or data loss, this software can help recover your files. A download is required to access this feature. Visit the SanDisk website for more details and to download the software.

5. Troubleshooting

5.1 Card Not Recognized

- Ensure the card is fully inserted into the slot.
- Verify that your device supports CFexpress Type-B cards. This card type is not compatible with standard SD or XQD slots unless specifically stated by the device manufacturer for XQD backwards compatibility.
- Try formatting the card in your device (refer to Section 2.3).
- Test the card in another compatible device to rule out a device-specific issue.

5.2 Slow Performance

- Ensure your device's firmware is updated to the latest version.
- Verify that your device supports the high speeds of this CFexpress card. Older or lower-end devices may not fully utilize the card's maximum read/write capabilities.
- Check if the card is nearly full. Performance can sometimes degrade when a card is close to its maximum capacity.
- Use a compatible CFexpress card reader for optimal transfer speeds to your computer.

6. Specifications

Feature	Detail
Brand	SanDisk
Model Number	Extreme PRO
Memory Storage Capacity	128 GB
Flash Memory Type	CFexpress Type-B (XQD backwards compatible with select cameras)
Read Speed	Up to 1700 MB/s
Write Speed	Up to 1200 MB/s
Special Feature	Water Proof
Item Weight	1.1 Ounces
Product Dimensions	6 x 4 x 0.1 inches
UPC	619659180782

7. Warranty and Support

7.1 Warranty Information

The SanDisk Extreme PRO 128GB CFexpress Type-B Memory Card comes with a SanDisk Lifetime Limited Warranty. Please retain your proof of purchase for warranty claims. For full terms and conditions, refer to the official SanDisk website or the warranty documentation included with your product.

7.2 Customer Support

For technical assistance, product registration, or to access the RescuePRO Deluxe software download, please visit the official SanDisk support website. You can also find FAQs and additional resources there.
SanDisk Official Website: www.sandisk.com

© 2023 SanDisk. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0891YMVWZ

More documents and user manuals: **https://manuals.plus/**