Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CAB55 CAB55

CAB55 Sewing Machine Case Instruction Manual

Model: CAB55

Introduction

The CAB55 Sewing Machine Case is designed to provide secure transport and organized storage for your sewing machine and its accessories. Constructed from durable materials with protective padding, it offers multiple carrying options and ample space for various sewing essentials. This manual provides instructions for its proper use and care.

Setup

1. Unpacking

Carefully remove the sewing machine case from its packaging. Inspect the case for any signs of damage. Retain packaging for future storage or transport if needed.

2. Attaching the Shoulder Strap

Locate the detachable shoulder strap. Attach each end of the strap to the D-rings located on the sides of the case. Adjust the strap length for comfortable carrying.



Image: Detachable shoulder strap attachment points.

3. Preparing the Interior

Open the main compartment zipper. The case features padded sidewalls and a cushioned bottom to protect your machine. Ensure the interior is clear before placing your sewing machine inside.



Image: Interior padding for machine protection.

Operating Instructions

1. Placing the Sewing Machine

Open the main compartment fully. Carefully lower your sewing machine into the main compartment. The wide opening facilitates easy placement and removal. The main compartment is designed to fit most standard-sized sewing machines up to 17 x 10.25 x 13.25 inches.
Compatible machine brands include SINGER (e.g., 5523, 4411, 4423, 4432, 4452, Simple 3337, 3223R, 3223GY, 3223BY, 2263, Fashion Mate 5560, 3333, 3342, Confidence 7470, 7469Q, Stylist 7258, Tradition 2277, 2250, Sew Mate 5400, Prom-ise II 1512, Start 1304, 1234, Patchwork 7285Q, 1507WC, Brilliance 6180), BROTHER (e.g., NS1750D, XM2701, LX2763, ST150HDH, CS7205, PE535), and JANOME (e.g., 4300QDC, 4120QDC, 3160QDC).



Image: Interior with sewing machine and compatible models list.

2. Utilizing Storage Pockets

The case features multiple pockets for organizing accessories. Use the clear mesh pockets for small items like thread spools, bobbins, and needles. The padded front pockets are suitable for foot pedals, power cables, and manuals. Additional pockets are available for other sewing supplies.



Image: Overview of storage pockets.

3. Carrying Options

The CAB55 case offers three ways to carry:

- **Handheld:** Use the sturdy top handles for short distances.
- **Shoulder Carry:** Attach the adjustable shoulder strap for hands-free transport.
- **Trolley Sleeve:** A strap on the back allows the case to slide over the handle of a luggage trolley for easier mobility during travel.



Image: Three different carrying methods.



Image: Trolley sleeve for luggage attachment.

4. Product Overview Video

Your browser does not support the video tag.

Video: This video provides a visual overview of the CAB55 Sewing Machine Case, demonstrating its features, storage capacity, and portability. It shows the case being opened, accessories being placed in pockets, and different carrying methods.

Maintenance

1. Cleaning

To clean the exterior of the case, wipe with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners. For interior cleaning, a soft brush or vacuum can be used to remove dust and debris from pockets.

2. Storage

When not in use, the sewing machine case can be folded up for compact storage. Store in a cool, dry place away from direct sunlight to preserve material integrity.

Troubleshooting

1. Sewing Machine Does Not Fit

Verify your sewing machine's dimensions against the case's internal capacity (17 x 10.25 x 13.25 inches). Ensure the machine is positioned correctly within the main compartment. Refer to the list of compatible models in the 'Operating Instructions' section.

2. Case Feels Unstable When Carried

Ensure the sewing machine is centered within the main compartment. Distribute accessories evenly among the various pockets to balance the weight. Avoid overloading the case beyond its intended capacity.

Specifications

External Dimensions	17" (L) x 12" (W) x 7.5" (H)
Main Compartment Capacity	Fits machines up to 17" (L) x 10.25" (W) x 13.25" (H)
Material	Heavy-duty nylon, Polyvinyl Chloride (PVC)
Weight	1.5 kg
Closure Type	Zipper
Strap Type	Detachable Shoulder Strap
Handle Type	Web Handle
Number of Pockets	Multiple (including clear mesh and padded front pockets)



Image: Case dimensions.

Warranty Information

The CAB55 Sewing Machine Case comes with a 2-year quality warranty. This warranty covers manufacturing defects and material failures under normal use. For warranty claims or issues, please contact customer support.

Customer Support

For further assistance, questions, or to report any issues with your CAB55 Sewing Machine Case, please visit the official CAB55 store on Amazon or contact their customer service directly through the platform.
CAB55 Store: https://www.amazon.com/stores/CAB55/page/919A3C73-CE76-40C3-9C85-F00BA30FD7C0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0892GFX1N

More documents and user manuals: **https://manuals.plus/**