XVEFAT RCATECHNICOLOR2.5

XVEFAT Replacement Remote Control for RCA Technicolor TVs

Model: RCATECHNICOLOR2.5

1. Introduction

This manual provides instructions for the XVEFAT replacement remote control, designed for use with various RCA Technicolor television models. This remote control requires no programming or setup; simply install batteries to begin operation.

Compatibility

This remote control is compatible with the following RCA Technicolor TV models:

- RTU5540-C
- RLD5515A-H
- RLDED3205A-C
- RLDED3258A-F
- RLDED4016A-G
- TR3201A
- RLDED5078A
- RLDED5078B
- RLD3273A-B
- RLDED3956A
- RLDED5078A-B
- RLDED5078A-E
- RLED1945A-F
- R0032
- RTU6549

2. Product Overview

Familiarize yourself with the buttons on your new remote control.



This image displays the front of the XVEFAT remote control, highlighting the power button, number pad, channel and volume controls, navigation buttons, and various function keys.

3. Setup

Battery Installation

The remote control requires two AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.







This image shows the back of the XVEFAT remote control with the battery compartment open, illustrating the correct orientation for inserting two AAA batteries.

4. Operating Instructions

Basic Functions

- **Power ( ):** Press to turn the TV on or off.
- **Number Pad (0-9):** Use to directly enter channel numbers.
- **CH+/CH-:** Press to change channels sequentially.
- **VOL+/VOL-:** Press to adjust the volume level.
- **Mute ( ):** Press to mute or unmute the TV audio.
- **Source:** Press to cycle through available input sources (e.g., HDMI, AV).
- **Menu:** Access the TV's main menu.
- **Navigation Buttons (▲ ▼ ◄ ►):** Use to navigate through menu options.
- **OK:** Confirm selections within menus.
- **Exit:** Exit the current menu or on-screen display.

Advanced Functions

- **P.MODE (Picture Mode):** Adjust picture settings (e.g., Standard, Dynamic, Movie).
- **S.MODE (Sound Mode):** Adjust sound settings (e.g., Standard, Music, Movie).
- **MTS (Multi-channel Television Sound):** Select audio tracks or SAP (Secondary Audio Program).
- **SLEEP:** Set a timer for the TV to automatically turn off.
- **INFO:** Display current channel information.
- **CC (Closed Caption):** Turn closed captions on or off.
- **V-CHIP:** Access V-Chip parental control settings.
- **ASPECT:** Change the screen aspect ratio (e.g., 16:9, 4:3).
- **Colored Buttons (A, B, C, D):** These buttons may have specific functions depending on the TV model or current menu. Refer to your TV's user manual for details.
- **FAV+/FAV-:** Navigate through favorite channels.
- **HDMI:** Directly select an HDMI input.
- **CH.LIST:** Display the channel list.

5. Maintenance

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

6. Troubleshooting

Common Issues and Solutions

- **Remote not working:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV's sensor.
- **Buttons unresponsive:**
  - This could indicate low batteries. Replace them.
  - Ensure the remote is clean and free from debris that might be jamming buttons.
- **Remote only controls some functions:**
  - Verify that your TV model is listed in the compatibility section. While this remote is designed for broad compatibility, some specific TV functions might require the original remote.

7. Specifications

- **Model:** RCATECHNICOLOR2.5
- **Brand:** XVEFAT
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** RCA Technicolor Televisions
- **Power Source:** 2 x AAA Batteries (not included)
- **Special Feature:** Ergonomic design

8. Warranty and Support

Warranty Information

This product is typically covered by a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact the seller directly.

Customer Support

If you encounter any issues or have questions regarding your XVEFAT remote control, please contact the seller through the platform where it was purchased for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question