Keurig K-Supreme

Keurig K-Supreme Single Serve Coffee Maker User Manual

Model: K-Supreme

Introduction

The Keurig K-Supreme Single Serve Coffee Maker is designed to elevate your coffee experience with its innovative MultiStream Technology. This technology ensures a more even saturation of coffee grounds in every K-Cup pod, extracting full flavor and aroma. The K-Supreme offers multiple brew sizes and customizable options for a perfect cup every time.





Image: The Keurig K-Supreme coffee maker in gray, actively brewing coffee into a red mug. The water reservoir is visible on the left side.

Setup

1. **Unpack and Clean:** Remove all packaging materials and tape from the coffee maker. Wash the water reservoir and drip tray with warm, soapy water. Rinse thoroughly and dry.
2. **Position the Reservoir:** The 66 oz. dual-position reservoir can be placed on the side or rear of the brewer for optimal counter space. Ensure it is securely attached.



Image: Top-down view of the Keurig K-Supreme coffee maker illustrating the two possible positions for the dual-position water reservoir: on the side and at the rear.

3. **Install Water Filter:** If using a water filter (sold separately), soak it in fresh water for 5 minutes, then rinse. Insert it into the filter holder and place it in the reservoir.
4. **Fill Reservoir:** Fill the water reservoir with fresh water up to the MAX fill line.



Image: A hand pouring water into the clear, removable water reservoir of the Keurig K-Supreme coffee maker, demonstrating the ease of refilling.

5. **Perform Cleansing Brew:** Place a large mug on the drip tray. Lift and lower the handle to close the K-Cup pod holder. Press the power button. When the brew size buttons illuminate, select the 8 oz. brew size. The cleansing brew will begin. Discard the hot water. The brewer is now ready for use.

Operating

1. **Power On:** Press the power button to turn on the brewer. The brew size buttons will illuminate when ready.
2. **Insert K-Cup Pod:** Lift the handle and place a K-Cup pod into the K-Cup pod holder. Lower the handle completely to close the lid.



Image: A close-up view inside the Keurig K-Supreme coffee maker's K-Cup pod holder, highlighting the MultiStream Technology with multiple needles designed to saturate coffee grounds evenly.

3. **Select Brew Size:** Choose your desired brew size from 6, 8, 10, or 12 oz. by pressing the corresponding button.





Image: A top-down view of the Keurig K-Supreme coffee maker's control panel, showing the illuminated buttons for 6oz, 8oz, 10oz, and 12oz brew sizes, along with 'Strong' and 'Over Ice' options.

4. **Customize Your Brew:**

- **Strong Brew:** For a bolder cup, press the **STRONG** button before selecting your brew size.
- **Over Ice Brew:** To brew hot over ice for a refreshing iced coffee, fill a large cup with ice and press the **OVER ICE** button before selecting your brew size.



Image: The Keurig K-Supreme coffee maker brewing coffee directly over ice into a tall glass, demonstrating its 'Over Ice' brewing capability.

5. **Brewing:** The selected brew size button will blink while brewing and remain illuminated when complete.
6. **Back-to-Back Brewing:** The brewer is designed for immediate back-to-back brewing without waiting for reheating.
7. **Travel Mug Friendly:** The drip tray can be removed to accommodate travel mugs up to 7 inches tall.

Maintenance

Regular maintenance ensures optimal performance and longevity of your Keurig K-Supreme coffee maker.

- **Cleaning the Brewer:** Regularly wipe down the exterior of the brewer with a damp cloth. The K-Cup pod holder and drip tray can be removed and washed with warm, soapy water.
- **Descaling:** The brewer features a 'Descale' alert that illuminates after every 250 brews. Follow the descaling instructions in the full user manual (PDF) to remove mineral buildup.
- **Water Filter Replacement:** Replace the water filter every 2 months or 60 tank refills, whichever comes first, to maintain water quality.

Troubleshooting

If you encounter issues with your Keurig K-Supreme, refer to the common problems and solutions below. For more detailed troubleshooting, consult the official user manual PDF.

- **'Add Water' Light:** If the 'Add Water' light is illuminated, the water reservoir is low. Refill the reservoir with fresh water.
- **'Descale' Light:** If the 'Descale' light is illuminated, it's time to descale your brewer. Follow the descaling procedure outlined in the full user manual.
- **No Brew/Partial Brew:** Ensure the water reservoir is properly seated and filled. Check that the K-Cup pod is correctly inserted and the handle is fully lowered.
- **Coffee Grounds in Cup:** This may indicate a damaged K-Cup pod or a need to clean the exit needle. Refer to the full manual for cleaning instructions.

Specifications

Key specifications for the Keurig K-Supreme Single Serve Coffee Maker.

Feature	Detail
Brand	Keurig
Model Name	K-Supreme
Color	Gray
Product Dimensions	10.12"D x 14.84"W x 14.41"H
Item Weight	5.78 pounds
Water Reservoir Capacity	66 oz. (Dual-Position, Removable)
Brew Sizes	6, 8, 10, 12 oz.
Special Features	MultiStream Technology, Strong Brew, Over Ice, Travel Mug Friendly
Voltage	110 Volts



Image: Detailed diagram showing the dimensions of the Keurig K-Supreme coffee maker with the water reservoir positioned on the side.



Image: Detailed diagram showing the dimensions of the Keurig K-Supreme coffee maker with the water reservoir positioned at the rear.

Warranty

For information regarding the product warranty, please refer to the official Keurig website or the warranty documentation included with your purchase.

Support

For additional support, detailed instructions, or to download the complete user manual, please visit the official Keurig support page or access the PDF directly via this link: Keurig K-Supreme User Guide (PDF).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question