Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Audio Technica ATH-CKS330XBT

Audio-Technica ATH-CKS330XBT Wireless Earphones User Manual

Model: ATH-CKS330XBT

Introduction

Thank you for purchasing the Audio-Technica ATH-CKS330XBT Wireless Earphones. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully before use and retain it for future reference.



Image: Audio-Technica ATH-CKS330XBT Wireless Earphones, black color.

Package Contents

Ensure all items are present in the package:

- ATH-CKS330XBT Wireless Earphones
- Earpieces (XS, S, M, L)
- USB Charging Cable
- Magnet Clip
- User Manual (this document)



Image: The ATH-CKS330XBT earphones laid out with their accessories, including different sized earpieces, a USB charging cable, and a magnet clip.

Setup

1. Charging the Earphones

Before first use, fully charge the earphones. A full charge takes approximately 2 hours and provides up to 20 hours of continuous playback. A quick 10-minute charge can provide approximately 2 hours of playback.

1. Connect the supplied USB charging cable to the USB port on the earphones.
2. Connect the other end of the USB charging cable to a USB power adapter or a computer's USB port.
3. The indicator lamp will illuminate during charging and turn off when charging is complete.



Image: A graphic indicating up to 20 hours of continuous playback on a full charge.

2. Bluetooth Pairing

To connect your earphones to a Bluetooth device:

1. With the earphones turned off, press and hold the power button until the indicator lamp flashes red and blue alternately. This indicates pairing mode.
2. On your Bluetooth device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "ATH-CKS330XBT" from the list of found devices.
4. Once connected, the indicator lamp will flash blue.

3. Selecting Earpieces

The earphones come with four sizes of earpieces (XS, S, M, L). Choose the size that provides the best fit for your ears for optimal sound quality and comfort. A proper fit ensures effective bass response and noise isolation.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the power button until the indicator lamp flashes blue.
- **Power Off:** Press and hold the power button until the indicator lamp flashes red and then turns off.

Music Playback and Call Controls

The earphones feature inline controls for easy management of music and calls:

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press the '+' button for 2 seconds.
- **Previous Track:** Press the '-' button for 2 seconds.
- **Volume Up:** Press the '+' button briefly.
- **Volume Down:** Press the '-' button briefly.
- **Answer/End Call:** Press the multi-function button once during an incoming call or active call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds during an incoming call.

Low Latency Mode

The Low Latency Mode minimizes the delay between audio and video, providing a smoother experience for gaming and video playback.

- **Activate/Deactivate:** Refer to the specific button combination in the quick start guide or product packaging. (Typically a double-press of a specific button).



Image: A user enjoying video content or gaming with the earphones, highlighting the Low Latency Mode feature.

Multipoint Connection

The ATH-CKS330XBT supports multipoint connection, allowing you to connect to two Bluetooth devices simultaneously. This is convenient for switching between a smartphone and a computer without re-pairing.

- Pair the earphones with the first device.
- Turn off Bluetooth on the first device.
- Pair the earphones with the second device.
- Turn on Bluetooth on the first device. The earphones should now be connected to both devices.



Image: A person using the earphones, with callouts for features like compact design, rapid charging, multipoint connectivity, and the secure neckband style.



Image: An illustration demonstrating the convenience of wireless earphones for web conferences and voice calls.

Maintenance

Proper maintenance ensures the longevity and performance of your earphones.

- **Cleaning:** Regularly wipe the earphones with a soft, dry cloth. For earpieces, remove them and clean with a mild soap solution, then rinse thoroughly and dry completely before reattaching.
- **Storage:** When not in use, store the earphones in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Water:** While the earphones are splash-proof, avoid submerging them in water or exposing them to heavy rain.

Troubleshooting

Problem	Solution
No sound from earphones.	Ensure earphones are powered on and paired. Check volume levels on both earphones and connected device. Re-pair the earphones with your device.
Cannot pair with a Bluetooth device.	Ensure earphones are in pairing mode (flashing red and blue). Turn off and on Bluetooth on your device. Move earphones closer to the device. Clear previous Bluetooth connections on your device.
Charging not working.	Ensure the USB cable is securely connected. Try a different USB port or power adapter. Check if the charging cable is damaged.
Sound quality is poor.	Ensure earpieces are properly fitted. Move closer to the connected device to avoid interference. Check the audio source quality.

Specifications

Feature	Detail
Brand	Audio-Technica
Model Name	ATH-CKS330XBT
Color	Black
Headphone Type	In-ear
Ear Position	In-ear
Impedance	16 Ohms
Audio Driver Type	Dynamic Driver
Audio Driver Size	5.8 mm
Wireless Type	Bluetooth
Communication Interface	Wireless
Control Method	Buttons (Volume Control)
Noise Control	None
Product Highlights	Bluetooth, SOLID BASS, Microphone, Low Latency Mode, AAC compatible, Splash-proof, Rapid charging, Neckband style
Continuous Playback Time	Up to approx. 20 hours

Feature	Detail
Charging Time	Approx. 2 hours (full charge)
Quick Charge	10 min charge for approx. 2 hours playback
Product Weight	24 grams
Product Material	Plastic
Country of Origin	China

Warranty

This product is covered by a **one-year warranty from the date of delivery**. To claim warranty service, proof of purchase is required. The warranty is valid only for use within Japan.
For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Audio-Technica website.

Support

For further assistance, product information, or technical support, please contact Audio-Technica customer service or visit their official website:

- **Audio-Technica Official Website:** www.audio-technica.co.jp
- Refer to the contact information provided in your product packaging for regional support.

© 2026 Audio-Technica Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0892WTJ2P

More documents and user manuals: **https://manuals.plus/**