ALLIMITY RC2134602-01

ALLIMITY RC2134602-01 Remote Control Instruction Manual

For Grundig TV Models: 32-7950T, 32-7955T/C, 32-8050T/C, 32CLC9120BF, 37-7950T/C, 42-7950T/C

1. Introduction

This instruction manual provides essential information for the proper use and maintenance of your ALLIMITY RC2134602-01 replacement remote control. This remote is designed to be compatible with various Grundig TV models, including 32-7950T, 32-7955T/C, 32-8050T/C, 32CLC9120BF, 37-7950T/C, and 42-7950T/C. Please read this manual thoroughly before use to ensure optimal performance.

2. Setup and First Use

The ALLIMITY RC2134602-01 remote control is pre-programmed for the specified Grundig TV models and typically requires no additional setup or programming. To begin using your remote, simply install the batteries.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two new alkaline batteries (AAA size, not included) into the compartment, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote control is ready for immediate use with your compatible Grundig TV.

3. Operating Instructions

This remote control functions identically to your original Grundig remote. Ensure a clear line of sight between the remote's infrared emitter and your TV's infrared receiver for proper operation.




TV
DVB
DVD
AMP
1
2
3
4
5
6
7
8
9
CL
0
AV
ECO
CEC
P+
P−
MENU
TOP MENU
TXT
TVG
RC2134602/01



Figure 1: Front view of the ALLIMITY RC2134602-01 remote control, showing the layout of all buttons. The remote is black with grey and blue buttons, and the model number RC2134602/01 is printed at the bottom.

3.1 Button Functions

- **Power Button (●):** Located at the top left, turns the TV on or off.
- **Source Selection (TV, DVB, DVD, AMP):** Buttons at the top to select input sources.
- **Number Buttons (0-9):** For direct channel selection.
- **CL (Clear):** Clears entered numbers or selections.
- **AV (Audio/Video):** Switches to Audio/Video input.
- **Mute:** Silences the TV audio.
- **? (Help):** Accesses help information.
- **ECO (Eco Mode):** Activates or deactivates energy-saving mode.
- **CEC (HDMI CEC):** Controls HDMI Consumer Electronics Control functions.
- **i (Information):** Displays program or system information.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Central circular pad for menu navigation and selection.
- **Channel Change (P+, P-):** Located on the outer ring of the central navigation cluster, changes channels up or down.
- **Volume Control (+, -):** Located on the inner ring of the central navigation cluster, adjusts the volume up or down.
- **MENU:** Accesses the TV's main menu.
- **TXT (Teletext):** Activates or deactivates Teletext.
- **TOP MENU:** Accesses the top level of a menu.
- **TV/G:** Switches between TV and Guide (or similar function).
- **Color Buttons (Red, Green, Yellow, Blue):** For specific functions within menus or interactive services.
- **Media Playback Controls (Record, Play, Stop, Pause, Rewind, Fast Forward, Skip Back, Skip Forward):** For controlling media playback on connected devices.



Figure 2: Angled view of the ALLIMITY RC2134602-01 remote control, highlighting its ergonomic design and button placement.

4. Care and Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**

- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace the batteries with new alkaline batteries.
- Ensure there are no obstructions between the remote control and the TV's infrared sensor.
- Confirm you are within the effective operating range (up to 10 meters).

- **Specific buttons not working:**
  - This may indicate a faulty button or a specific function not supported by your TV model.
  - Ensure the remote is pointed directly at the TV.
- **Intermittent operation:**
  - Weak batteries are often the cause. Replace them.
  - Ensure no strong light sources (like direct sunlight) are interfering with the TV's IR receiver.

If problems persist after trying these steps, contact your retailer for further assistance.

6. Specifications

Brand	ALLIMITY
Model Number	RC2134602-01
Connectivity Technology	Infrared (IR)
Compatible Devices	Grundig TV models: 32-7950T, 32-7955T/C, 32-8050T/C, 32CLC9120BF, 37-7950T/C, 42-7950T/C
Maximum Range	10 Meters
Power Source	2 x AAA Alkaline Batteries (not included)

7. Warranty and Support

Information regarding product warranty and customer support was not provided in the available product data. For warranty claims or technical assistance, please refer to the documentation included with your purchase or contact the retailer where the product was acquired.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question