Retekess EUF9493A

Retekess TH104 Key Finder User Manual

Model: EUF9493A

1. Introduction

The Retekess TH104 Key Finder is a wireless item locator system designed to help you quickly find misplaced items. This system includes one transmitter and six color-coded receivers, making it an ideal solution for tracking keys, wallets, phones, remote controls, and other small valuables. With its powerful 85dB alarm and 40-meter range, you can easily locate your belongings without the need for a smartphone application.



Image Description: The Retekess TH104 Key Finder system, featuring a black transmitter with six colored buttons (A-F) and six matching color-coded receivers.

2. Package Contents

Please verify that all items are present in your package:

- 1 x Retekess TH104 Transmitter
- 6 x Color-coded Receivers (A, B, C, D, E, F)
- 7 x CR2032 Batteries (pre-installed in receivers, one for transmitter)
- 6 x Key Rings
- 2 x Types of DIY Stickers (icon and blank for custom text)
- 1 x User Manual
- 1 x Battery Opening Tool (guitar pick shape)



Image Description: A complete view of the Retekess TH104 package contents, including the transmitter, six receivers, key rings, stickers, and user manual.

3. Setup

3.1 Battery Installation and Replacement

The receivers come with CR2032 batteries pre-installed. If replacement is needed, follow these steps:

1. Locate the small notch on the side of the receiver.
2. Insert the provided battery opening tool (or a similar thin object) into the notch.
3. Gently pry open the cover of the receiver.
4. Remove the old CR2032 battery and insert a new one, ensuring the positive (+) side faces upwards.
5. Close the cover securely.



Image Description: A visual guide demonstrating how to open a receiver with a tool and replace the CR2032 battery.

3.2 Attaching Receivers to Items

You can attach the receivers to your items using the provided key rings or adhesive stickers:

- **Key Rings:** Use the metal key rings to attach receivers to keys, pet collars, or bags.
- **Adhesive Stickers:** For items like remote controls, wallets, or phones, use the double-sided adhesive stickers to secure the receiver directly to the surface.

3.3 Labeling the Transmitter Buttons

To easily identify which button corresponds to which item, use the provided DIY stickers:

- Choose between the pre-designed icon stickers (e.g., key, wallet) or the blank stickers for custom text.
- Apply the chosen sticker to the designated area next to each button (A-F) on the transmitter.



Image Description: A hand pressing the 'F' button on the transmitter, with an example of DIY stickers used to label items like 'Car's key' and 'Toy'.

4. Operation

4.1 Locating Items

To locate a misplaced item:

1. Identify the button on the transmitter that corresponds to the item you are looking for (e.g., 'A' for keys).
2. Press the corresponding color-coded button on the transmitter.
3. The associated receiver will emit a loud 85dB beep and flash a red LED light, guiding you to your item.



Image Description: A receiver attached to keys on a couch, emitting a 'Bibi' sound and flashing, indicating it has been activated by the transmitter.

4.2 Understanding Range and Sound

The Retekess TH104 utilizes radio frequency (RF) technology, allowing it to penetrate through common household obstacles such as walls, floors, cushions, and leather. The effective range for locating items is up to 40 meters (approximately 130 feet) in open areas. The 85dB sound signal is designed to be clearly audible throughout a room or even in a garden or yard, depending on ambient noise levels.



Image Description: An illustration showing the 40-meter range of the key finder, with the transmitter in a living room and receivers indicated in various parts of a house.

5. Maintenance

To ensure the longevity and optimal performance of your Retekess TH104 Key Finder, please follow these maintenance guidelines:

- **Battery Replacement:** Replace CR2032 batteries in receivers and transmitter as needed (refer to Section 3.1). Low battery can affect range and sound volume.
- **Cleaning:** Wipe the transmitter and receivers with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Water Exposure:** The devices are not waterproof. Avoid exposure to water or high humidity.

6. Troubleshooting

Problem	Possible Cause	Solution
Receiver does not beep or flash.	Low or dead battery in receiver. Receiver is out of range.	Replace the CR2032 battery in the receiver. Move closer to the item and try again.
Short detection range.	Low battery in transmitter or receiver. Excessive obstacles between transmitter and receiver.	Replace batteries in both transmitter and receiver. Reduce obstacles or move to a more open area.
Transmitter buttons unresponsive.	Low or dead battery in transmitter.	Replace the CR2032 battery in the transmitter (located under the back cover).
Sound is too low.	Low battery in receiver. High ambient noise.	Replace the CR2032 battery in the receiver. Try to reduce background noise.

7. Specifications

Feature	Detail
Brand	Retekess
Model Number	EUF9493A
Color	Black
Connectivity Technology	RF (Radio Frequency)
Operating Range	Up to 40 meters (130 feet)
Sound Level	85 dB
Batteries	7 x CR2032 (included)
Material	Acrylonitrile Butadiene Styrene (ABS) Plastic
Item Weight	160 Grams
Compatible Devices	Various items like keys, wallets, phones, remotes, pet collars

8. Warranty and Support

Retekess is committed to providing high-quality products and customer satisfaction.

- **Warranty:** This product comes with a 12-month warranty from the date of purchase, covering manufacturing defects.
- **Customer Service:** For any questions, technical assistance, or warranty claims, please contact Retekess customer support. Our team is available 24/7 to assist you.
- **Online Resources:** Visit the official Retekess store on Amazon for additional product information and support:

Retekess Amazon Store.

© 2023 Retekess. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question