Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hamilton Beach 49933

Hamilton Beach 49933 2-Way 12 Cup Programmable Drip Coffee Maker & Single Serve Machine User Manual

Model: 49933 | Brand: Hamilton Beach

This manual provides instructions for the safe and efficient operation, maintenance, and troubleshooting of your Hamilton Beach 2-Way Coffee Maker.

1. Setup and Initial Use

Before first use, please read all instructions thoroughly. Keep this manual for future reference.

1.1 Unpacking

- Carefully remove all packaging materials and labels from the coffee maker.
- Ensure all components are present: coffee maker unit, 12-cup glass carafe, single-serve brew basket, and single-serve cup rest.

1.2 Initial Cleaning

It is recommended to clean the coffee maker before its first use to remove any manufacturing residues.

1. Wash the glass carafe, carafe lid, single-serve brew basket, and single-serve cup rest in warm, soapy water. Rinse thoroughly and dry.
2. Wipe the exterior of the coffee maker with a damp cloth. Do not immerse the unit in water.
3. Run two full carafe cycles with only water (no coffee grounds) to flush the internal components. Discard the water after each cycle.



Figure 1: Hamilton Beach 2-Way Coffee Maker (Model 49933)

2. Operating Instructions

2.1 Brewing a Full Pot (Carafe Side)

1. Open the carafe-side lid and fill the water reservoir with desired amount of fresh, cold water. Refer to the water level markings on the reservoir.
2. Place a standard basket-style paper filter into the carafe-side filter basket, or use a reusable filter (not included). Add desired amount of ground coffee to the filter.
3. Close the carafe-side lid and ensure the glass carafe is placed securely on the warming plate.
4. Rotate the brew selector knob to the "Carafe" setting.
5. Press the "Brew Now" button to start brewing. The coffee maker will automatically shut off after 2 hours.
6. To program a delayed brew, press the "Program" button, set the desired brew time using the "Hour" and "Minute" buttons, then press "Program" again to confirm.
7. Use the "Brew Options" button to select between Regular and Bold brew strength.



Figure 2: Programmable features for delayed brewing.



Figure 3: Easy coffee ground loading with included scoop.

2.2 Brewing a Single Serve

1. Open the single-serve lid and fill the single-serve water reservoir with desired amount of fresh, cold water (up to 14 oz).
2. Place the single-serve brew basket into the single-serve filter holder. Add desired amount of ground coffee to the brew basket.
3. Close the single-serve lid.
4. Place your mug or travel cup on the single-serve cup rest. Adjust the cup rest height if necessary.
5. Rotate the brew selector knob to the "Single Serve" setting.
6. Press the "Brew Now" button to start brewing.

Simple single-cup brewing

Doesn't use K-Cup®* pods



*K-CUP is a registered trademark of Keurig Green Mountain, Inc. Use of the K-CUP trademark does not imply any affiliation with or endorsement by Keurig Green Mountain, Inc.

Figure 4: This coffee maker does not use K-Cup pods, allowing use of your preferred ground coffee.



Figure 5: Versatile brewing options for single servings or full pots.

3. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

3.1 Daily Cleaning

- Always unplug the coffee maker before cleaning.
- Wash the glass carafe, carafe lid, single-serve brew basket, and single-serve cup rest in warm, soapy water after each use. These parts are top-rack dishwasher safe.
- Wipe the exterior of the coffee maker with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Clean the warming plate with a damp cloth.

3.2 Descaling (Mineral Deposit Removal)

Mineral deposits (calcium) can build up in your coffee maker and affect its performance. Descale every 3-6 months, or more often in hard water areas.

1. Pour 1 cup of white vinegar into the water reservoir (carafe side).
2. Fill the remainder of the reservoir with cold water.
3. Place the empty glass carafe on the warming plate.
4. Brew the vinegar-water solution through a full carafe cycle.
5. After the cycle, turn off the coffee maker and let it sit for 30 minutes.
6. Discard the solution and rinse the carafe thoroughly.
7. Run 2-3 full carafe cycles with only fresh, cold water to remove any remaining vinegar smell or taste.

4. Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	No water in reservoir; Unit not plugged in; Brew selector knob in wrong position.	Fill water reservoir; Plug in unit; Rotate knob to correct setting (Carafe or Single Serve).
Coffee is too weak.	Not enough coffee grounds; Incorrect brew strength selected.	Add more coffee grounds; Select "Bold" brew option.
Coffee overflows from filter basket.	Too many coffee grounds; Filter not seated correctly; Mineral buildup.	Reduce coffee grounds; Ensure filter is properly seated; Descale the coffee maker.
Unit leaks.	Water reservoir overfilled; Carafe/mug not positioned correctly.	Do not overfill water reservoir; Ensure carafe/mug is centered under dispenser.

Figure 6: Common troubleshooting solutions.



Figure 7: Automatic shutoff feature for peace of mind.

5. Product Specifications

Brand: Hamilton Beach

Model Name: Hamilton Beach 2-Way 12 Cup Programmable Drip

Item Model Number: 49933

Color: White

Product Dimensions: 11.1"D x 12.2"W x 13.9"H

Item Weight: 7.4 pounds

Voltage: 120V

Coffee Maker Type: Drip Coffee Machine

Filter Type: Reusable (for single serve)

Special Features: Timer, Removable Tank, Programmable, Auto Pause and Pour, 2-Hour Automatic Shutoff, Select-A-

Brew

Included Components: 2-Way Programmable Coffee Maker, Glass Carafe, Single-Serve Brew Basket, Single-Serve Cup Rest



Figure 8: Product dimensions for placement and reference.

6. Warranty Information

For detailed warranty information, please refer to the official user manual provided with your product or visit the Hamilton Beach website. Typically, Hamilton Beach products come with a limited warranty covering defects in material and workmanship under normal household use.

7. Customer Support

If you have any questions, require assistance, or need to order replacement parts, please contact Hamilton Beach Customer Service.

Online Support: Visit the official Hamilton Beach website for FAQs, product registration, and support resources.

User Manual (PDF): An electronic version of the user manual is available at https://manuals.plus/m/fd770fd699af2472a464c5c2bd94def05c4605d1c17c7d4de901a5c6acd73b43

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0896NP59N

More documents and user manuals: **https://manuals.plus/**