ALLIMITY RC16

ALLIMITY RC16 Replacement Remote Control User Manual for Logik TVs

Model: RC16

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY RC16 replacement remote control. It is designed to operate various Logik TV models, offering full functionality for your television viewing experience. Please read this manual carefully to ensure proper setup and operation of your new remote control.

2. Package Contents

- 1 x ALLIMITY RC16 Replacement Remote Control

Note: AAA batteries are not included and must be purchased separately.

3. Setup: Battery Installation

To begin using your ALLIMITY RC16 remote control, you must first install the batteries.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two (2) new AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.




1
2
3
4
5
6
7
8
9
LIST
0
SLEEP
VOL
PROG
CH
TITLE
ASPECT
S.MODE
P.MODE
GUIDE
MENU
INPUT
OK
BACK
EXIT
SETUP
ANGLE
FAV
TV.RD
AD
MENU
TEXT
ZOOM
S
CANCEL
MIX
SIZE
OK
STEP
HOLD
REVEAL
SUBPAGE
INDEX
GOTO
SLOW
REPEAT
A-B



Image: Front view of the ALLIMITY RC16 remote control. The battery compartment is located on the back, not visible in this image.

Your remote control is now ready for use. No programming is required for compatible Logik TV models.

4. Operating Instructions: Button Functions

The ALLIMITY RC16 remote control features a standard layout for easy navigation and control of your Logik TV. Below is a guide to the main button functions.





Image: Angled view of the ALLIMITY RC16 remote control, showing the full button layout.

4.1. Power and Basic Controls

- **Power (Red Button)**: Turns the TV on or off.
- **Mute**: Mutes or unmutes the TV sound.
- **Source (Input)**: Selects the input source (e.g., HDMI, AV, TV).
- **VOL +/-**: Adjusts the volume level up or down.
- **CH +/-**: Changes the TV channel up or down.
- **Number Buttons (0-9)**: Directly select TV channels.
- **LIST**: Displays a list of channels or recorded programs.
- **SLEEP**: Sets the TV sleep timer.
- **PROG**: Accesses program information or settings.

4.2. Navigation and Menu Controls

- **MENU**: Opens the main TV menu.
- **Directional Arrows (Up, Down, Left, Right)**: Navigate through menus and options.
- **OK**: Confirms a selection or enters a submenu.
- **BACK**: Returns to the previous menu or screen.
- **EXIT**: Closes the current menu or function.
- **INFO (i)**: Displays information about the current program or input.
- **GUIDE**: Opens the electronic program guide (EPG).
- **TITLE**: Accesses title-related functions (e.g., DVD/Blu-ray titles).

4.3. Special Functions and Media Playback

- **ASPECT**: Changes the screen aspect ratio.
- **S.MODE (Sound Mode)**: Selects different sound modes.
- **P.MODE (Picture Mode)**: Selects different picture modes.

- **SETUP**: Accesses system setup options.
- **FAV (Favorite)**: Accesses favorite channels list.
- **TV/RD**: Switches between TV and Radio modes.
- **AD (Audio Description)**: Toggles audio description for visually impaired users.
- **TEXT**: Opens or closes Teletext.
- **ZOOM**: Zooms in or out on the screen.
- **CANCEL**: Cancels an action or selection.
- **MIX**: Mixes Teletext with TV picture.
- **SIZE**: Changes Teletext display size.
- **HOLD**: Holds the current Teletext page.
- **REVEAL**: Reveals hidden Teletext information.
- **SUBPAGE**: Navigates Teletext subpages.
- **INDEX**: Returns to the Teletext index page.
- **GOTO**: Jumps to a specific time or chapter during media playback.
- **SLOW**: Activates slow-motion playback.
- **REPEAT**: Repeats a track or section.
- **A-B**: Repeats a specific segment between two points (A and B).
- **Media Playback Buttons (Play/Pause, Stop, Rewind, Fast Forward, Previous, Next, Record)** Control media playback functions.

5. Compatible Logik TV Models

The ALLIMITY RC16 replacement remote control is compatible with a wide range of Logik TV models, including but not limited to:

- L22LDVB21
- L22LDVS11
- L24FED12
- L22DIGB11
- L22LDVB11
- L24DIGB11
- L24LDVB11
- L19DIGB11
- L22FE12N
- L22LDVN11
- L24FE12N
- L26DVDB21
- L19LDVN11
- L24FE12
- L26DIGB21
- L22FED12
- L22LDVR11
- L24FE13
- L32HE12

- L19LDVP11
- L22FED13
- L22LDVW11
- L24FED13

If your Logik TV model is not listed, please refer to your TV's original manual or contact ALLIMITY customer support for compatibility verification.

6. Specifications

- **Brand**: ALLIMITY
- **Model Name**: RC16
- **Connectivity Technology**: Infrared (IR)
- **Maximum Range**: 10 Meters (approximately 33 feet)
- **Power Source**: 2 x AAA Batteries (not included)
- **Special Feature**: Ergonomic design
- **Compatible Devices**: Logik TVs (specific models listed above)

7. Troubleshooting

7.1. Remote Control Not Responding

- **Check Batteries**: Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new AAA batteries.
- **Line of Sight**: Ensure there is a clear line of sight between the remote control and the TV's IR receiver. Obstructions can block the signal.
- **Remote Sensor**: Clean the IR emitter on the front of the remote control and the IR receiver on your TV with a soft, dry cloth.
- **Distance**: Ensure you are within the effective operating range (up to 10 meters).

7.2. Specific Buttons Not Working

- This can sometimes indicate a faulty button or low battery power. Try replacing the batteries first. If the issue persists for specific buttons, the remote may require replacement.

8. Care and Maintenance

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage**: Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Removal**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Avoid Drops**: Protect the remote control from drops and impacts, which can damage internal components.

9. Warranty and Support

For warranty information or technical support regarding your ALLIMITY RC16 remote control, please refer to the retailer's return policy or contact ALLIMITY customer service through the platform where the product was purchased. Please have your purchase details and product model number (RC16) available when contacting support.