Glade 323636

Glade Automatic Spray Air Freshener Kit - Tropical Blossoms

Model: 323636

1. Product Overview

The Glade Automatic Spray Air Freshener Kit provides continuous fragrance to your home environment. This kit includes an automatic spray holder and a refill with the Exotic Tropical Blossoms scent. The device is designed to release bursts of fragrance at timed intervals or on demand, helping to maintain a fresh and inviting atmosphere.



Image: Glade Automatic Spray Holder with Tropical Blossoms refill.

Key Features:

- **Automatic Fragrance Release:** Delivers fresh bursts of scent every 9, 18, or 36 minutes.
- **On-Demand Boost:** A manual button allows for an immediate extra burst of fragrance.
- **Long-Lasting Scent:** Each refill provides up to 70 days of freshness when used on the lowest setting.
- **Essential Oil Infused:** Fragrances are crafted by master perfumers and infused with essential oils.
- **Versatile Placement:** Can be placed on flat surfaces or mounted to a wall.

2. Setup Instructions

2.1 Unpacking the Unit

Carefully remove all components from the packaging. Ensure you have the automatic spray holder and the fragrance refill(s).



Image: The Glade Automatic Spray Kit components, including the holder and refills, shown within its packaging.

2.2 Opening the Unit

To open the automatic spray holder, locate the ribbed sections on the sides of the unit. Squeeze these ribs while gently pulling the sides of the holder apart. The front cover will hinge open.

Your browser does not support the video tag.

Video: Demonstrates how to open the Glade Automatic Spray unit by pulling the sides apart. This video is provided by the seller, SC Johnson.

2.3 Inserting Batteries

The unit requires two AA batteries (typically included). Insert the batteries into their designated slots, ensuring correct polarity (+/-) as indicated inside the compartment.

2.4 Inserting the Fragrance Refill

Before inserting the refill, ensure the timer setting is in the 'OFF' position and the nozzle points away from your face. Remove the cap from the fragrance refill can. Align the nozzle of the refill can with the opening in the holder and push it

firmly into place until it clicks. Ensure the white plastic lever inside the unit is in the 'up' position for proper insertion. If the lever is down, adjust the timer from 'OFF' to any time setting to reset it.



Image: Diagram illustrating the steps for inserting the fragrance refill and batteries into the automatic spray unit.

2.5 Closing the Unit

Close the front cover of the holder until it securely snaps shut.

3. Operating Instructions

3.1 Setting the Timer

Once the unit is closed, select your desired time interval for automatic fragrance release using the switch located inside the unit. Options typically include 9, 18, or 36 minutes. The first spray will occur a few seconds after selecting a time setting.



Image: Diagram illustrating the timer settings switch for 9, 18, or 36 minutes, and the off position.

3.2 Manual Boost Function

For an immediate burst of fragrance at any time, press the boost button located on the top of the unit. This will release an additional spray of scent.



Image: A hand pressing the boost button located on the top of the Glade Automatic Spray unit for an extra burst of freshness.

4. Maintenance

4.1 Replacing Fragrance Refills

When the fragrance refill is empty, the device will stop dispensing scent. To replace, turn the unit to the 'OFF' position, open the front cover, remove the empty can, and insert a new Glade Automatic Spray Refill following the steps in Section 2.4.

4.2 Checking Batteries

If the unit stops dispensing fragrance even with a full refill, check the batteries. Replace both AA batteries if they are depleted. Batteries typically last for up to 3 refills.

5. Troubleshooting

- **Unit not spraying:**

- Ensure batteries are correctly inserted and not depleted.
- Verify the fragrance refill is not empty and is securely seated.
- Check that the timer is set to an active interval (9, 18, or 36 minutes) and not 'OFF'.
- Confirm the white plastic lever inside the unit is in the 'up' position. If not, cycle the timer switch to reset it.

- **Weak scent:**
  - Increase the frequency of sprays by selecting a shorter time interval (e.g., 9 minutes).
  - Consider placing the unit in a more central location within the room.

6. Specifications

Brand	Glade
Model Number	323636
Scent	Exotic Tropical Blossoms
Item Form	Spray
Product Dimensions	12.06 x 8.88 x 3.69 inches
Item Weight	1.7 Pounds
Manufacturer	SC Johnson

7. Safety Information

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. Keep out of reach of children and pets. Avoid direct inhalation of the spray. In case of eye contact, rinse immediately with plenty of water. If irritation persists, seek medical advice. Use in well-ventilated areas. Do not puncture or incinerate container. Do not expose to heat or store at temperatures above 120°F (49°C).

8. Warranty and Support

For warranty information or product support, please refer to the manufacturer's website or contact their customer service directly. Contact details can typically be found on the product packaging or the official Glade website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question