Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HITACHI SF-P105JJ WH

Hitachi Washing Machine SF-P105JJ WH User Manual

Model: SF-P105JJ WH | Brand: HITACHI

1. Safety Information

Please read all safety instructions carefully before operating the appliance to prevent injury and damage.

- Ensure the washing machine is properly grounded to prevent electric shock.
- Do not operate the machine with a damaged power cord or plug.
- Keep children and pets away from the appliance during operation.
- Do not wash items that are soiled with flammable substances.
- Always unplug the machine before cleaning or performing maintenance.

2. Product Overview

The Hitachi SF-P105JJ WH is a 10.5 Kg top-load automatic washing machine designed for efficient and convenient laundry care.

Key Features:

- 10.5 Kg Capacity
- 4-Step Wash System
- Active Beat Lifter for enhanced washing performance
- Beat Shower for thorough rinsing
- Air Jet Dry with Nano Titanium Filter for effective drying and odor reduction
- Anti-Bacterial Lint Filter for hygienic operation
- Multi-program wash options

Components:



An overhead view of the white Hitachi SF-P105JJ WH top load automatic washing machine. The machine features a transparent blue-tinted lid, a control panel with an LED display, and various program selection buttons. The overall design is sleek and rectangular.

3. Setup and Installation

Unpacking:

Carefully remove all packaging materials, including the base packaging and any protective films. Inspect the machine for any damage incurred during transit.

Location Requirements:

- Place the washing machine on a firm, level surface to minimize vibration and noise.
- Ensure adequate space around the machine for ventilation and access.
- Avoid direct sunlight or heat sources.

Connecting Water and Drain Hoses:

1. Connect the water inlet hose to a cold water tap. Ensure a tight connection to prevent leaks.
2. Position the drain hose into a suitable drain or sink, ensuring it is securely fixed to prevent dislodging during operation.

Power Connection:

Plug the power cord into a grounded electrical outlet. Verify that the voltage matches the machine's requirements.

4. Operating Instructions

Control Panel Overview:

The control panel, located on the top front of the machine, features an LED display and push-button controls for program selection, start/pause, and power. Refer to the diagram in the physical manual for specific button layouts.

Basic Washing Cycle:

1. Load laundry into the drum, ensuring not to overload.
2. Add detergent and fabric softener to their respective dispensers.
3. Press the **POWER** button to turn on the machine.
4. Select the desired wash program using the program selection buttons.
5. Press the **START/PAUSE** button to begin the cycle.

Wash Programs:

The machine offers multiple wash programs tailored for different fabric types and soil levels. Common cycles include:

- **Normal:** For everyday cottons and mixed fabrics.
- **Delicate:** For fragile items requiring gentle care.
- **Heavy Duty:** For heavily soiled items.
- **Quick Wash:** For lightly soiled items needing a fast cycle.
- **Spin:** For draining water and spinning clothes.
- **Rinse:** For an additional rinse cycle.
- **Drain:** For draining water from the tub.

Special Features:

- **4-Step Wash:** Optimizes washing performance through a multi-stage process.
- **Active Beat Lifter & Beat Shower:** Enhances water circulation and fabric agitation for cleaner results.
- **Air Jet Dry:** Utilizes air circulation to reduce drying time and moisture.

- **Nano Titanium Filter:** Helps to reduce odors during the Air Jet Dry process.

5. Maintenance

Cleaning the Exterior:

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Cleaning the Lint Filter:

Regularly remove and clean the anti-bacterial lint filter to maintain washing efficiency and prevent lint buildup. Rinse under running water and reinsert.

Drum Cleaning:

Run a drum cleaning cycle periodically (if available) or a hot wash cycle with a washing machine cleaner to prevent mold and odor buildup.

Water Inlet Filter Cleaning:

Check and clean the water inlet filter screen if water flow is restricted. Turn off the water supply before cleaning.

6. Troubleshooting

Problem	Possible Cause	Solution
Machine does not start	No power; Lid not closed properly; Start/Pause button not pressed.	Check power connection; Ensure lid is fully closed; Press Start/Pause.
Water not filling	Water tap closed; Water inlet hose kinked; Water inlet filter clogged.	Open water tap; Straighten hose; Clean inlet filter.
Machine vibrates excessively	Uneven surface; Load unbalanced; Shipping bolts not removed.	Adjust leveling feet; Redistribute laundry; Remove shipping bolts (if applicable).
Water not draining	Drain hose kinked or blocked; Drain pump filter clogged.	Check and clear drain hose; Clean drain pump filter.

7. Technical Specifications

Specification	Detail
Model Number	SF-P105JJ WH
Capacity	10.5 Kilograms
Type	Top Load, Automatic
Color	White

Specification	Detail
Material	Stainless Steel (Drum/Finish)
Item Weight	9.5 kg
Control Type	Push Button
Display Style	LED
Installation Method	Freestanding
Recommended Use	Residential

8. Warranty and Customer Support

This Hitachi washing machine comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage period and what is covered.

For technical assistance, service requests, or to inquire about spare parts, please contact Hitachi customer support. Contact details can typically be found on the Hitachi official website or in your purchase documentation.

When contacting support, please have your model number (SF-P105JJ WH) and serial number ready.

© 2024 Hitachi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089G91LBR

More documents and user manuals: **https://manuals.plus/**