Lovehoney Mantric

Lovehoney Mantric Bullet Vibrator Instruction Manual

Model: Mantric

1. Introduction

This manual provides detailed instructions for the safe and effective use of your Lovehoney Mantric Bullet Vibrator. Please read this manual thoroughly before first use and retain it for future reference.

The Lovehoney Mantric Bullet Vibrator is designed for personal stimulation, featuring a powerful, whisper-quiet motor and a sleek, tapered silicone tip for precise or broad sensation. Its user-friendly single-button interface makes it suitable for both new and experienced users.



Image 1.1: The Lovehoney Mantric Bullet Vibrator, showcasing its design and control button.

2. Safety Information

- **Material Safety:** The vibrator is made from body-safe silicone. If you experience any irritation, discontinue use immediately.
- **Lubricant Compatibility:** Always use with water-based lubricants. Avoid silicone-based lubricants, as they can damage the silicone material of the product.
- **Waterproof Design:** This product is 100% waterproof, allowing for use in the bath or shower and easy cleaning. Ensure the charging port is dry before charging.
- **Charging Safety:** Use only the provided USB charging cable. Do not overcharge. Disconnect from power once fully charged.
- **Storage:** Store in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep out of reach of children.

- **Disposal:** Do not dispose of the product with household waste. Follow local regulations for electronic waste disposal.

3. Product Components

The Lovehoney Mantric Bullet Vibrator consists of the following main components:

- **Tapered Silicone Tip:** Designed for pinpoint or widespread sensation.
- **Main Body:** Houses the motor and battery, covered in soft silicone.
- **Control Button:** Single button for power and mode selection.
- **LED Indicator:** Located at the base, lights up to indicate power and mode.
- **USB Charging Port:** Located at the base for recharging.



Image 3.1: Detail of the vibrator's control button and base.

4. Setup

1. **Unpack:** Carefully remove the vibrator and its accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the device. Refer to the "Charging" section for instructions.
3. **Clean:** Clean the vibrator before its first use. Refer to the "Cleaning and Maintenance" section.

5. Charging

The Lovehoney Mantric Bullet Vibrator is USB rechargeable.

1. Locate the USB charging port at the base of the vibrator.
2. Insert the small end of the provided USB charging cable into the vibrator's charging port.
3. Connect the larger end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The LED indicator at the base will light up during charging.
5. A full charge takes approximately 90 minutes and provides up to 90 minutes of playtime. Disconnect the cable once charging is complete.



Image 5.1: The vibrator connected to its USB charging cable.

6. Operating Instructions

The vibrator features a simple single-button control for ease of use.

1. **Power On/Off:** Press and hold the control button for 2-3 seconds to turn the vibrator on or off. The LED indicator will light up when powered on.
2. **Change Modes:** Once powered on, short press the control button to cycle through the 7 vibration patterns and 3 intensity levels. The LED base lights up in correlation to each different setting.
3. **Application:** Apply a water-based lubricant to the vibrator. Use the tapered tip for targeted sensation or the wider body for broader stimulation.



Image 6.1: The vibrator's compact size, held in a hand.

7. Cleaning and Maintenance

Proper cleaning and maintenance will extend the lifespan of your vibrator.

1. **Cleaning:** After each use, wash the vibrator thoroughly with warm water and a mild, toy-safe soap or a dedicated toy cleaner.
2. **Rinsing:** Rinse thoroughly to remove all soap residue.
3. **Drying:** Pat dry with a lint-free cloth or allow to air dry completely before storing.
4. **Waterproof Feature:** The 100% waterproof design allows for easy cleaning under running water.



Image 7.1: The vibrator demonstrating its waterproof capability.

8. Storage

Store your Lovehoney Mantric Bullet Vibrator in a clean, dry, and cool environment. Keep it away from direct sunlight, extreme temperatures, and other toys made of different materials to prevent potential damage or reactions.

9. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully (refer to Section 5).

Problem	Possible Cause	Solution
Vibrations are weak or inconsistent.	Low battery.	Recharge the device.
Device is not charging.	Charging cable or power source issue; charging port not clean.	Ensure the USB cable is properly connected and the power source is functional. Clean the charging port if necessary.
Device overheats during use.	Prolonged continuous use; internal malfunction.	Discontinue use immediately and allow the device to cool down. If overheating persists, contact customer support.

10. Specifications

- **Brand:** Lovehoney
- **Model:** Mantric
- **Material:** Body-safe Silicone
- **Color:** Pink
- **Dimensions:** 10 x 9.7 x 5.9 cm
- **Weight:** 100 g
- **Battery:** 1 Lithium Ion (included)
- **Charging:** USB Rechargeable
- **Charge Time:** Approximately 90 minutes
- **Playtime:** Up to 90 minutes (on a full charge)
- **Vibration Modes:** 7 patterns, 3 intensity levels (10 modes total)
- **Waterproof:** 100% Waterproof

11. Warranty and Support

For information regarding warranty coverage, please refer to the documentation provided with your purchase or visit the official Lovehoney website.
If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact Lovehoney customer support or the retailer from whom you purchased the product.
Lovehoney Official Website: www.lovehoney.co.uk

© 2026 Lovehoney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question