KOMOK Electric Pruning Shears

KOMOK Electric Pruning Shears

User Manual

1. Introduction

Thank you for choosing the KOMOK Electric Pruning Shears. This cordless, battery-operated tool is designed to make pruning tasks easier and more efficient, reducing strain on your hands. It features sharp SK5 high carbon steel blades and a powerful brushless motor, capable of cutting branches up to 1.2 inches (30mm) in diameter. Please read this manual thoroughly before operation to ensure safe and effective use.



Image: KOMOK Electric Pruning Shears and its durable carrying case.

2. Safety Information

WARNING: Always exercise extreme caution when operating electric pruning shears. The blades are very sharp and powerful.

- Keep hands and fingers clear of the cutting blades at all times.
- Wear appropriate personal protective equipment, including safety glasses and sturdy gloves.
- Ensure the safety switch is engaged when the tool is not in use or during maintenance.
- Do not allow children or untrained individuals to operate the pruning shears.

- Avoid cutting live electrical wires or other non-plant materials.
- Use only original KOMOK batteries and chargers.

3. Package Contents

Your KOMOK Electric Pruning Shears package should include the following items:



Image: Overview of all items included in the KOMOK Electric Pruning Shears kit.

- Electric Pruning Shears x 1
- Tool Case x 1
- Work Gloves x 1 pair
- Charger x 1
- Allen Wrench x 2
- Lubricant Oil x 1 bottle
- Lithium Battery (2Ah) x 2

- User Manual (English, French, German, Italian, Spanish) x 1

4. Setup

Follow these steps to prepare your pruning shears for use:

1. **Install the Battery:** Align the battery with the slot at the bottom of the shears and slide it in until it clicks securely into place.
2. **Turn on the Safety Switch:** Locate the safety switch on the top of the tool and slide it to the 'ON' position. The LED indicator will turn green, and the shears will beep twice.
3. **Activate the Blades:** To start the power pruning shears, quickly pull the trigger twice. The blades will open, indicating readiness for operation.



Image: Visual guide for installing the battery, activating the safety switch, and preparing the shears for use.

Watch this video for a visual demonstration of the setup process:

Your browser does not support the video tag.

Video: Demonstrates the setup and initial operation of the KOMOK electric pruners, showing battery installation and activation.

5. Operating Instructions

The KOMOK Electric Pruning Shears are designed for ease of use and powerful cutting.

Cutting Operation

- Once activated, position the open blades around the branch you wish to cut.
- Pull the trigger to close the blades and make the cut. Release the trigger to open the blades for the next cut.
- The shears can cut branches up to 1.2 inches (30mm) in diameter.



Image: Illustrates the comfortable one-handed operation of the pruning shears.

Key Features for Operation

- **SK5 High Carbon Steel Blades:** Extremely sharp and durable, ensuring clean cuts for healthy plant growth.
- **Brushless Motor:** Provides strong power and extends the tool's service life, offering 3 to 5 times the life of conventional brush motors.
- **Long-lasting Batteries:** Equipped with two 2Ah lithium batteries, supporting up to 8000+ cuts per charge and providing 8-10 working hours. A battery indicator helps monitor power levels.
- **Ergonomic Design:** The comfortable non-slip handle reduces hand fatigue, making it suitable for prolonged use and for individuals with arthritic hands.
- **Auto Sleep Mode:** The tool enters auto sleep mode after 60 seconds of inactivity to conserve battery.



Image: Highlights the 600W brushless motor technology for efficient operation.

See the shears in action:

Your browser does not support the video tag.

Video: Demonstrates the KOMOK cordless electric pruning shears cutting various branches quickly and efficiently.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your pruning shears.

- **Blade Cleaning:** After each use, clean the blades to remove sap, dirt, and debris. Use a damp cloth and mild detergent if necessary. Dry thoroughly.
- **Lubrication:** Apply a few drops of the provided lubricant oil to the blades and pivot point regularly to ensure smooth operation and prevent rust.
- **Blade Sharpening:** If the blades become dull, they can be sharpened using appropriate tools. Refer to professional sharpening services if unsure.

- **Battery Care:** Store batteries in a cool, dry place. Charge them fully before extended storage and periodically during storage to maintain battery health.
- **Storage:** Store the pruning shears and accessories in their original carrying case in a dry, secure location, out of reach of children.

7. Troubleshooting

If you encounter issues with your KOMOK Electric Pruning Shears, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shears do not turn on.	Battery not properly seated or charged. Safety switch off.	Ensure battery is fully charged and securely installed. Check if the safety switch is in the 'ON' position and pull the trigger twice quickly to activate.
Blades do not close completely or cut cleanly.	Dull blades. Debris caught in blades. Misalignment.	Clean blades thoroughly. Lubricate the pivot point. If blades are dull, sharpen or replace them. Contact customer support if misalignment persists.
Battery slides out during use.	Battery latch issue.	Ensure the battery is firmly clicked into place. If the latch is faulty, contact customer support.
Reduced cutting power.	Low battery charge. Overheating.	Recharge the battery. Allow the tool to cool down if it has been used continuously for a long period.

8. Specifications

Feature	Detail
Brand	KOMOK
Model Number	Electric Pruning Shears (JYH-606)
Cutting Diameter	1.2 inch (30mm)
Blade Material	SK5 High Carbon Steel
Motor Type	Brushless Motor
Power Source	Battery Powered
Battery Type	Lithium Ion (2Ah)
Working Hours (per charge)	8-10 hours (approx.)
Item Weight (with 1 battery)	Approx. 2.2 lbs (1.0 kg)
Wattage	600 watts
Product Dimensions	11.02"L x 4.49"W

9. Warranty and Support

KOMOK provides a warranty for its products to ensure customer satisfaction.

- The electric pruning shears typically come with an 18-month warranty.
- Batteries are generally covered by a 6-month warranty.

For any questions, technical support, or warranty claims, please contact KOMOK customer service through the retailer where you purchased the product or visit the official KOMOK store online. Provide your product model number and purchase details for faster assistance.

© 2024 KOMOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question