Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alltro B089MFYK5Q

Alltro Replacement Remote Control for JTC DVX4 (DVB-PM14009HCATS) - User Manual

Model: B089MFYK5Q

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Alltro replacement remote control, designed for JTC DVX4 (DVB-PM14009HCATS) televisions. Please read this manual thoroughly before using the remote control to ensure proper function and longevity.





Figure 1: Alltro Replacement Remote Control. This image shows the front view of the remote control with its various buttons.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Important: This remote control requires 2 AAA batteries (not included).

2. Initial Use (No Programming Required)

This Alltro replacement remote control is pre-programmed and designed to work directly with JTC DVX4 (DVB-PM14009HCATS) televisions. No additional programming or setup steps are required. Simply install the batteries, and the remote is ready for use.

Operating Instructions

Point the remote control directly at your JTC DVX4 television's infrared receiver. Ensure there are no obstructions between the remote and the television.

- **Power Button:** Press to turn the television on or off.
- **Channel Buttons (CH+/CH-):** Press to change channels up or down.
- **Volume Buttons (VOL+/VOL-):** Press to increase or decrease the volume.
- **Mute Button:** Press to mute or unmute the television's audio.
- **Input/Source Button:** Press to cycle through available input sources (e.g., HDMI, AV).
- **Navigation Buttons (Arrow Keys, OK):** Use to navigate menus and confirm selections.
- **Number Buttons (0-9):** Use to directly enter channel numbers or other numerical inputs.
- **Menu Button:** Access the television's main menu.
- **Exit Button:** Exit current menu or function.

Refer to your JTC DVX4 television's original user manual for specific functions of advanced buttons, as their behavior is determined by the television itself.

Maintenance

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Storage

When not in use for extended periods, remove the batteries from the remote control to prevent leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote control is not working.	• Batteries are dead or incorrectly inserted. • Obstruction between remote and TV. • Remote control is too far from the TV.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the signal path. • Move closer to the television (within 10 meters).
Buttons are unresponsive or sticky.	• Dirt or debris under buttons. • Internal component issue.	• Clean the remote control surface. • If cleaning does not resolve the issue, the remote may require replacement.
Remote works intermittently.	• Weak batteries. • Interference from other electronic devices.	• Replace batteries. • Ensure no other devices are causing infrared interference.

Specifications

Brand: Alltro

Model: B089MFYK5Q

Compatible Devices: Television (JTC DVX4 / DVB-PM14009HCATS)

Connectivity Technology: Infrared

Number of Buttons: 52

Controller Type: Button Control

Maximum Range: 10 Meters

Batteries Required: 2 x AAA (not included)

Product Dimensions: 21.5 x 5 x 1.8 cm

Item Weight: 82 g

Warranty Information

Specific warranty details for this Alltro replacement remote control are not provided in the product information. Please refer to the retailer or your purchase documentation for any applicable warranty terms and conditions.

Support

For further assistance or inquiries regarding your Alltro replacement remote control, please contact the retailer from whom you purchased the product. They can provide support and guidance specific to your purchase.

© 2023 Alltro. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089MFYK5Q

More documents and user manuals: **https://manuals.plus/**