Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alltro UE32F4570, UE32F4570SS, UE32F4570SSXZG, UE32F4580, UE32F4580SS, UE32F5000

User Manual for Alltro Replacement Remote Control

Model: UE32F4570, UE32F4570SS, UE32F4570SSXZG, UE32F4580, UE32F4580SS, UE32F5000

Brand: Alltro

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Alltro Replacement Remote Control. This remote is designed as a direct replacement for various Samsung TV models, offering full functionality without the need for programming.

Product Overview

The Alltro Replacement Remote Control is a full-function remote designed to operate specific Samsung TV models. It requires no programming, making it ready to use with compatible televisions immediately after battery installation.





Figure 1: Front view of the Alltro Replacement Remote Control.



Figure 2: Back view of the Alltro Replacement Remote Control, with packaging.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch to open it.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

Initial Use

This remote control is designed to work immediately with compatible Samsung TV models without any programming. Simply point the remote at your television and press the desired button.

Operating Instructions

The remote control provides full functionality for your Samsung TV. Below are common button functions:

- **Power (Red Button):** Turns the TV on or off.
- **Source:** Selects input sources (HDMI, AV, etc.).
- **Number Pad (0-9):** Direct channel selection.
- **Volume (+/-):** Adjusts the volume level.
- **Channel (P +/-):** Changes channels up or down.
- **Mute:** Mutes or unmutes the TV sound.
- **Menu:** Accesses the TV's main menu.
- **Smart Hub:** Opens the Smart Hub interface for apps and streaming services.
- **Guide:** Displays the electronic program guide.
- **Navigation Pad (Up, Down, Left, Right, Enter):** Navigates through menus and selects options.
- **Return:** Goes back to the previous screen or menu.
- **Exit:** Exits the current menu or application.
- **Color Buttons (A, B, C, D):** Functionality varies by application or TV mode.

Maintenance

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, solvents, or alcohol, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and TV. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure you are within 10 meters of the TV and pointing the remote directly at it.
Some buttons not working.	Dirty contacts under buttons. Specific function not supported by TV model.	Try cleaning the remote. Verify if the specific function is available on your TV model.
Remote feels sluggish.	Low battery power.	Replace batteries.

Specifications

- **Brand:** Alltro
- **Compatible Devices:** Television (Samsung TV models: UE32F4570, UE32F4570SS, UE32F4570SSXZG, UE32F4580, UE32F4580SS, UE32F5000)
- **Connectivity Technology:** Infrared, Radio Frequency
- **Controller Type:** Button Control
- **Maximum Range:** 10 Meters
- **Battery Description:** Alkaline (AAA, not included)
- **Special Features:** No Programming Required
- **Package Dimensions:** 23 x 4.6 x 2.2 cm
- **Weight:** 90 g

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. As this is a replacement remote, specific warranty terms may vary.
No official product videos are available from the seller for this item.

© 2024 Alltro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089QP24L5

More documents and user manuals: **https://manuals.plus/**