Noma CTI1513687

Noma C9 LED Quick Clip Christmas Lights Instruction Manual

Model: CTI1513687

Introduction

This manual provides instructions for the safe and effective use of your Noma C9 LED Quick Clip Christmas Lights. These lights are designed for both indoor and outdoor applications, featuring 25 energy-efficient red LED bulbs on a 16.8-foot strand, equipped with integrated spring-loaded clips for simplified installation. Please read this manual thoroughly before installation and operation.

Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following safety precautions:

- Read all instructions carefully before installing or using the light set.
- Do not overload electrical circuits. Ensure the total wattage of connected strands does not exceed the maximum capacity of the outlet or extension cord.
- Always unplug the light set from the power source when not in use or before performing any maintenance.
- Inspect the light set for any damage to the bulbs, wiring, or plugs before each use. Do not use if damaged.
- Ensure all plugs are fully inserted into outlets and connections are secure.
- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Disconnect the product from the power supply when leaving the house, when retiring for the night, or if left unattended.
- This product is equipped with LED bulbs. Do not attempt to replace bulbs with incandescent types.

Package Contents

- 1 x Noma C9 LED Quick Clip Christmas Lights Strand (25 Red Bulbs, 16.8-foot length)

Setup

The Noma C9 LED Quick Clip Christmas Lights are designed for quick and easy installation on various surfaces.

1. **Unpack and Inspect:** Carefully remove the light strand from its packaging. Uncoil the strand and inspect all bulbs, clips, and wiring for any signs of damage.

2. **Plan Placement:** Determine the desired location for your lights, such as rooflines, gutters, railings, or tree branches.



Image: Noma C9 LED Quick Clip Christmas Lights installed along a snowy roofline, demonstrating typical outdoor placement.

3. **Utilize Quick-Clip Technology:** Each bulb features a built-in spring-loaded clip. These clips allow for secure attachment to various surfaces.



Image: A diagram illustrating the 180-degree rotation capability of the light bulb within its clip, and a close-up of the built-in spring-loaded clip. This feature allows for precise light direction and easy attachment.

4. **Attach Lights:** Open the clip and secure it to the desired surface. The clips are designed to hold firmly to roof shingles, gutters, and branches.



Image: Noma C9 LED Quick Clip Christmas Lights securely attached to a house gutter, showcasing the ease of installation on common architectural features.



Image: Noma C9 LED Quick Clip Christmas Lights clipped onto a tree branch, demonstrating versatility for decorating natural elements.

5. **Adjust Light Direction:** The bulbs can rotate 180 degrees within their clips, allowing you to adjust the light direction as needed.
6. **Connect Multiple Strands:** Each 16.8-foot strand has plug-ins at both ends. You can link up to 90 strands (totaling 2,250 lights) end-to-end. Ensure the total wattage does not exceed the maximum recommended load for your power source.

Operating Instructions

Once the Noma C9 LED Quick Clip Christmas Lights are securely installed:

1. **Power Connection:** Connect the male plug of the light strand (or the first strand in a series) into a standard 120-volt AC electrical outlet.
2. **Activation:** The lights will illuminate upon connection to power. There is no separate on/off switch on the strand itself. Use a timer or unplug the strand to control operation.
3. **Disconnection:** To turn off the lights, simply unplug the power cord from the electrical outlet.

Maintenance

Proper maintenance ensures the longevity and performance of your Noma C9 LED Quick Clip Christmas Lights.

- **Cleaning:** Disconnect the lights from power before cleaning. Wipe bulbs and wiring with a soft, damp cloth. Do not immerse the light strand in water.
- **Inspection:** Regularly inspect the entire light strand for any signs of wear, cuts, or damage to the wiring, plugs, or bulbs. Replace any damaged components or the entire strand if necessary.
- **Storage:** When not in use, especially during off-seasons, carefully coil the light strand. Store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original compact, reusable packaging is ideal for storage.



Image: Noma C9 LED Quick Clip Christmas Lights neatly stored in their clear plastic, reusable container, emphasizing the product's easy storage feature.

- **Bulb Replacement:** These lights use integrated LED bulbs designed for long life. If a bulb fails, it typically does not affect the rest of the strand. Individual bulb replacement is generally not required or recommended.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lights do not illuminate.	• No power to the outlet. • Loose plug connection. • Damaged wiring or bulb. • Circuit overload.	• Check the power outlet with another device. • Ensure the plug is fully inserted into the outlet. • Inspect the entire strand for visible damage. If damaged, discontinue use. • Reduce the number of connected strands or other devices on the circuit.
Some bulbs are not lit.	• Individual bulb failure (rare for LED). • Loose bulb connection.	• LED bulbs are designed for long life; however, if an individual bulb fails, it typically does not affect the rest of the strand. • Ensure all bulbs are securely seated in their sockets.
Lights flicker.	• Loose connection. • Inconsistent power supply.	• Check all plug connections, including end-to-end connections between multiple strands. • Ensure the power source is stable.

Specifications

Brand	Noma
Model Number	CTI1513687
ASIN	B089XPX1D4
Light Color	Red
Bulb Type	LED
Bulb Shape Size	C9
Number of Lights	25
Strand Length	16.8 feet
Power Source	Corded Electric
Voltage	120 Volts
Wattage	2.4 watts
Max Connectable Strands	Up to 90 strands
Indoor/Outdoor Usage	Indoor/Outdoor
Special Features	Weatherproof, Quick Clip Technology, Adjustable Rotation
Material	Plastic (Acrylic Resin)
Water Resistance Level	Water Resistant

Warranty Information

Specific warranty details for the Noma C9 LED Quick Clip Christmas Lights are not provided in this manual. For information regarding product warranty, please refer to the packaging or contact Noma customer support directly. Keep your proof of purchase

for warranty claims.

Support and Contact

If you have any questions, require technical assistance, or need to report an issue with your Noma C9 LED Quick Clip Christmas Lights, please contact Noma customer support.

- **Manufacturer:** NOMA
- **Website:** Refer to the product packaging or search for "Noma Official Website" for contact information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question