LEXIBOOK JC598FZi1

LEXIBOOK Disney Frozen 2 Educational and Bilingual Laptop Instruction Manual

Model: JC598FZi1

Introduction

Welcome to the world of interactive learning with your new LEXIBOOK Disney Frozen 2 Educational and Bilingual Laptop. This device is designed to provide an engaging and educational experience for children, featuring beloved characters Elsa and Anna. It offers 124 activities across various subjects, supporting both English and French languages to foster bilingual development.

The laptop's ergonomic design, inspired by real laptops, includes a realistic mouse and keyboard, making learning intuitive and fun. It's an ideal tool for developing logical thinking, number recognition, musical skills, and language proficiency.



Image: The LEXIBOOK Disney Frozen 2 Educational Laptop, showcasing its design and screen featuring Elsa and Anna.

Setup and First Use

Battery Installation

Your LEXIBOOK laptop requires 2 x 1.5V AA/LR06 batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment on the underside of the laptop.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert two AA/LR06 batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.

Connecting the Mouse

The laptop comes with a wired mouse for enhanced interaction. Plug the mouse connector into the designated port on the

side of the laptop.



Image: The LEXIBOOK laptop shown within its retail packaging, highlighting its compact design and included mouse.

Operating Instructions

Power On/Off

Press the **ON/OFF** button located on the keyboard to turn the laptop on or off.

Language Selection

To switch between English and French, locate the**Lang.** button on the keyboard and press it. The display will indicate the current language.

Volume Control

Adjust the volume using the**Vol +** and **Vol -** buttons on the keyboard.

Navigating Activities

The laptop features a keyboard and a mouse for navigation. Use the arrow keys or the mouse to select activities from the main menu displayed on the LCD screen. Press **Enter** or click the left mouse button to confirm your selection.



Image: A detailed view of the laptop's screen and keyboard, emphasizing the character display and functional layout.

Activities and Games

The LEXIBOOK Disney Frozen 2 laptop offers 124 diverse educational activities and games designed to enhance various skills. These activities are categorized for easy selection:

- **Educational Activities:** Includes lessons in English and French, Mathematics, Dactylography (typing), General knowledge, Logic, Music, and Clock reading.
- **Test the Knowledge:** Fun activities with different levels to learn, test, and improve knowledge across subjects.
- **Games:** Engaging games designed to test logic, memory, and speed.
- **Music & Melodies:** Musical activities for an introduction to music, including notes learning, composing, and playing melodies.
- **Graphic Effects:** The LCD screen displays various animations and graphic effects to make learning more visually appealing.
- **Language:** Focuses on letters, words, typing, and spelling in both English and French.
- **Mathematics:** Covers numbers and basic calculations (addition, subtraction, multiplication, division).



Image: A child engaged with the laptop, illustrating the variety of educational activities available, such as Mathematics, Language, Typing, Music, Logic, Games, and Clock & Time.

Official Product Videos

Your browser does not support the video tag.

Video: An overview of the Lexibook Educational and Bilingual Laptop, demonstrating its features and interactive learning capabilities in English and French.

Your browser does not support the video tag.

Video: A promotional video for the LEXIBOOK JC598FZi1 Disney Frozen 2 Educational and Bilingual Laptop, showcasing its design and various activities.

Maintenance

- **Cleaning:** To clean the laptop, wipe it gently with a slightly damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Battery Care:** Remove batteries if the device will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly according to local regulations.
- **Storage:** Store the laptop in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Laptop does not turn on.	Batteries are low or incorrectly installed.	Check battery polarity. Replace with fresh AA/LR06 batteries.

Problem	Possible Cause	Solution
Screen is blank or flickering.	Low battery power; temporary software glitch.	Replace batteries. Turn the laptop off and on again.
Sound is distorted or absent.	Volume is too low; temporary audio glitch.	Increase volume using the Vol+ button. Turn the laptop off and on again.
Mouse or keyboard not responding.	Mouse not properly connected; temporary input glitch.	Ensure the mouse is securely plugged in. Restart the laptop.

Specifications

Product Dimensions: 24 x 18 x 3.6 cm; 648 g

Batteries Required: 2 x 1.5V AA / LR06 batteries (not included)

Manufacturer Recommended Age: 3 years and up

Item Model Number: JC598FZi1

Educational Objectives: Logical Thinking, Number Recognition, Musical Skill

Languages: English, French

Number of Game Players: 1

Assembly Required: No

Material Type: Plastic

Color: Blue, Purple

First Available Date: 10 June 2020

Warranty and Support

This product is designed with safety in mind and meets relevant safety standards. For specific warranty information or technical support, please refer to the packaging or contact LEXIBOOK customer service directly. Keep your purchase receipt as proof of purchase.
The manufacturer recommends this product for ages 3 years and up, with a safety information note indicating a 2-year period, likely referring to a warranty or expected lifespan under normal use.

© 2025 LEXIBOOK. All rights reserved. Disney Frozen 2 characters are trademarks of Disney.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question