Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lasika SW006

Lasika W-F62 Camouflage Multifunction Sports Watch SW006 User Manual

Model: SW006

1. Product Overview

The Lasika W-F62 Camouflage Multifunction Sports Watch SW006 is designed for active individuals, featuring a durable camouflage design and a range of practical functions. This watch includes a calendar, alarm, hourly chime, LED display, backlight, shock resistance, and a stopwatch. It is also water-resistant up to 3 ATM.



Image 1.1: Front view of the Lasika W-F62 Camouflage Multifunction Sports Watch SW006, displaying the digital time, day, and date, along with button labels (LIGHT, MODE, START, RESET).



Image 1.2: Side view of the Lasika W-F62 watch, showing the profile of the watch case and the strap attachment points.



Image 1.3: Back view of the Lasika W-F62 watch, highlighting the stainless steel back plate secured by four screws and the camouflage pattern on the strap.

2. Setup

The Lasika W-F62 watch comes with a pre-installed Lithium Metal battery. No initial battery installation is required. To begin using your watch, you will primarily need to set the time and date.

2.1 Button Functions

- **LIGHT:** Activates the backlight for illumination in low-light conditions.
- **MODE:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START:** Used to start/stop functions in Stopwatch mode, or adjust values in setting modes.
- **RESET:** Used to reset values in Stopwatch mode, or select items in setting modes.

3. Operating Instructions

3.1 Time and Date Setting

1. From the normal time display mode, press the **MODE** button three times to enter the time setting mode. The seconds digits will begin to flash.
2. Press the **RESET** button to cycle through the settings: Seconds → Hour → Minute → Month → Date → Day of the week.
3. While a digit is flashing, press the **START** button to adjust the value.
4. Once all settings are adjusted, press the **MODE** button to return to the normal time display.

3.2 Alarm Function

1. From the normal time display mode, press the **MODE** button once to enter the Alarm mode.
2. Press the **RESET** button to select the hour or minute digits.
3. Press the **START** button to adjust the flashing hour or minute.
4. To activate/deactivate the alarm, press the **START** and **RESET** buttons simultaneously in Alarm mode. An alarm icon will appear/disappear.
5. Press the **MODE** button to return to the normal time display.

3.3 Stopwatch Function

1. From the normal time display mode, press the **MODE** button twice to enter the Stopwatch mode.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. Press the **MODE** button to return to the normal time display.

3.4 Backlight

Press the **LIGHT** button at any time to illuminate the display for a few seconds. This is useful in dark environments.

3.5 Hourly Chime

To activate or deactivate the hourly chime, press the **MODE** button twice to enter Stopwatch mode. Then, press the **RESET** button to cycle through the options until the hourly chime indicator appears or disappears. Press **MODE** to exit.

4. Maintenance

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Water Resistance:** The watch is rated for 3 ATM (30 meters) water resistance. This means it is suitable for daily use, splashes, and brief immersion. It is **not** suitable for swimming, diving, or showering with hot water, as steam can penetrate the seals. Do not operate buttons while the watch is wet.
- **Battery Replacement:** The watch uses one Lithium Metal battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Display is blank or dim.	Low or depleted battery.	Replace the battery.
Buttons are unresponsive.	Watch may be in a frozen state or internal malfunction.	Try pressing all buttons simultaneously for a few seconds to reset. If problem persists, battery replacement may be needed.
Time is inaccurate.	Incorrect time setting or low battery.	Re-set the time according to Section 3.1. If problem persists, replace battery.
Water inside the watch.	Water resistance compromised due to improper use or seal degradation.	Immediately take the watch to a qualified technician for inspection and repair to prevent further damage. Avoid contact with water.

6. Specifications

Feature	Detail
Brand	Lasika
Model Number	SW006
Display Type	Digital (LED)
Functions	Time, Date, Day, Alarm, Stopwatch, Hourly Chime, Backlight
Water Resistance	3 ATM (30 meters)
Battery Type	1 Lithium Metal battery (included)
Item Weight	100 g
Manufacturer	China

7. Warranty and Support

This Lasika W-F62 Camouflage Multifunction Sports Watch SW006 comes with a**1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

The warranty does not cover:

- Damage resulting from improper use, accidents, or unauthorized repairs.
- Normal wear and tear, including scratches on the case or crystal, or degradation of the strap.
- Water damage if the watch was used beyond its specified water resistance limits or if buttons were operated underwater.

For warranty claims or technical support, please refer to the contact information provided with your purchase documentation or contact your retailer.



Image 7.1: The Lasika W-F62 watch presented in its red retail box, indicating the product as it would be received.

© 2023 Lasika. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the specific battery type and full name for the Lasika W-F62 (SW006) watch?

The documentation for the Lasika W-F62 (Model SW006) specifies that it uses one Lithium Metal battery. While the manual does not list a specific industry code (such as CR2025 or CR2032), most digital sports...

Read full answer

Open the live page

https://manuals.plus/asin/B08B3B9R5J

More documents and user manuals: **https://manuals.plus/**