Gueray Y-01

Gueray Portable CD Player Y-01 User Manual

Model: Y-01

1. Introduction

Thank you for purchasing the Gueray Portable CD Player Model Y-01. This device offers multiple audio playback options including CD, Bluetooth, FM Radio, USB, and AUX. It features dual speakers, a rechargeable battery, and can be used on a desktop or wall-mounted. Please read this manual carefully to ensure proper use and optimal performance.



Image 1.1: The Gueray Portable CD Player Y-01, showcasing its compact design and a battery charge indicator.

2. Package Contents

Please check the package for the following items:

- CD Player (Model Y-01)
- Wall plate & Four screws
- Remote control
- User manual (this document)
- Type-C Charging cable
- 5V-2A USB adaptor



Image 2.1: Illustration of the complete package contents, including the CD player, remote, cables, and mounting hardware.

3. Product Overview

3.1 Features

The Gueray Y-01 CD Player offers a comprehensive set of features:

- **All-in-1 Playback:** Supports CD, CD-R/RW, MP3, WMA formats.
- **Dual Bluetooth 5.0:** Functions as both a Bluetooth receiver (connect to phone, tablet, laptop) and a Bluetooth transmitter (connect to Bluetooth headphones or speakers).
- **Integrated Speakers:** Built-in dual Hi-Fi loudspeakers for clear and balanced sound.
- **Rechargeable Battery:** 1800mAh battery for portable use.
- **Multiple Modes:** FM Radio, USB playback, and AUX input/output.
- **Convenient Design:** Desktop stand and wall-mount capabilities, with a removable dust cover.
- **Additional Functions:** Headphone jack, sleep timer, A-B repeat, memory function, programming playback, and remote control.



Image 3.1: Visual representation of the player's multifunctional capabilities, including various playback modes and features.

3.2 Controls and Ports

Familiarize yourself with the player's controls and ports:



Image 3.2: Detailed diagram of the player's front and side panels, labeling all buttons and ports for easy identification.

1. **USB Port:** For USB flash drive playback.
2. **Earphones Port:** 3.5mm jack for wired headphones.
3. **Power Indicator:** LED light indicating power status.
4. **Type-C Charging Port:** For charging the device.
5. **Power Switch:** To turn the device on/off.
6. **Mode Button:** To switch between CD, Bluetooth, FM, USB, and AUX modes.
7. **Volume -:** Decrease volume.
8. **Volume +:** Increase volume.
9. **Previous Song/Fast Back:** Navigate to the previous track or fast backward.
10. **Play/Pause:** Start or pause playback.
11. **Next Song/Fast Forward:** Navigate to the next track or fast forward.
12. **Dust Cover:** Removable cover for the CD compartment.

4. Setup

4.1 Powering On and Charging

- **Charging:** Connect the provided Type-C charging cable to the player's Type-C port and the 5V-2A USB adaptor to a power outlet. The power indicator will show charging status. A full charge provides hours of continuous playback.
- **Power On/Off:** Press the Power Switch button to turn the player on or off.

4.2 Desktop Use

For desktop use, extend the integrated back brace to provide stable support for the player.

4.3 Wall Mount Installation

To mount the CD player on a wall:

1. Choose a suitable location on the wall.
2. Use the provided wall plate as a template to mark the screw positions.
3. Drill pilot holes and insert the four screws, leaving them slightly protruding.
4. Align the back of the CD player with the wall plate and slide it down to secure.



Image 4.1: Step-by-step guide for wall mounting the CD player, showing the wall plate and how the player attaches.

5. Operating Instructions

5.1 CD Playback

1. Gently press the center of the removable dust cover to pop it open.
2. Place a CD (CD, CD-R/RW, MP3, WMA format) onto the spindle, ensuring it is seated correctly.
3. Close the dust cover.
4. Press the **Mode** button until "CD" mode is displayed.
5. Press the **Play/Pause** button to start playback.
6. Use **Previous/Next** buttons to skip tracks and **Volume +/-** to adjust volume.



Image 5.1: Visual guide for opening the dust cover and loading a CD.

5.2 Bluetooth Mode

The player supports both Bluetooth receiving and transmitting.

5.2.1 Bluetooth Receiving (Connect to Phone/Tablet)

1. Press the **Mode** button until "BLUE" (Bluetooth) mode is displayed. The player will enter pairing mode.

2. On your mobile device (phone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Y-01" from the list to pair. Once connected, you can stream audio from your device to the CD player's speakers.

5.2.2 Bluetooth Transmitting (Connect to Bluetooth Headphones/Speakers)

1. Ensure your Bluetooth headphones or speaker are in pairing mode.
2. Press the **Mode** button on the CD player until "BLUE" mode is displayed.
3. The CD player will automatically search for and connect to nearby Bluetooth audio devices. Once connected, audio from the CD player will be transmitted to your external Bluetooth device.



Image 5.2: Visual guide for connecting the CD player via Bluetooth, both as a receiver and a transmitter.

5.3 FM Radio

1. Press the **Mode** button until "FM" mode is displayed.
2. Use the **Previous**/**Next** buttons to scan for radio stations.
3. Adjust volume with **Volume +/-**.

5.4 USB Playback

1. Insert a USB flash drive into the USB port.
2. Press the **Mode** button until "USB" mode is displayed.
3. The player will automatically begin playing compatible audio files (MP3, WMA) from the USB drive.

5.5 AUX Mode

1. Connect an external audio device (e.g., MP3 player, phone) to the player's 3.5mm AUX input/output port using an AUX cable (not included).
2. Press the **Mode** button until "AUX" mode is displayed.
3. Control playback from your external device.

5.6 Remote Control Usage

The remote control allows convenient operation from a distance. Ensure the player's power button is pressed ON before using the remote. The remote requires 2 AAA batteries (not included).

- **Power Button:** Turns the player on/off (after initial manual power on).
- **Volume +/-:** Adjusts volume.

- **Play/Pause, Previous/Next:** Controls playback.
- **Mode Buttons (CD, USB, FM, Bluetooth, A-B Repeat):** Directly select playback modes or functions.
- **Numeric Buttons:** For direct track selection in CD/USB mode or station selection in FM mode.

5.7 Special Functions

- **A-B Repeat:** Press the A-B button on the remote to mark a starting point (A) and an ending point (B) for a specific section of audio to repeat.
- **Sleep Timer:** Consult the remote control or player interface for sleep timer options to automatically turn off the device after a set period.
- **Playback Modes:** Supports single-track repeat, all-track repeat, and playlist playback modes.
- **Memory Function:** The player retains the last played mode and position.

6. Maintenance

6.1 Cleaning

- Wipe the exterior of the player with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- For the CD lens, use a specialized CD lens cleaning kit if necessary.

6.2 Removable Dust Cover

The player features an upgraded removable dust cover. This cover protects the CD mechanism from dust accumulation, which can cause skipping or errors. It can be easily removed for quicker CD placement and removal, or kept in place for protection. The player functions normally with or without the dust cover attached.

7. Troubleshooting

Problem	Possible Cause	Solution
Player does not power on.	Battery is depleted.	Connect the player to power using the Type-C cable and adaptor.
CD skipping or not playing.	CD is dirty, scratched, or inserted incorrectly. Dust on lens.	Clean the CD. Reinsert the CD correctly. Clean the CD lens with a specialized kit. Ensure dust cover is properly closed.
No sound from speakers.	Volume too low. Mute activated. Headphones connected.	Increase volume. Check if headphones are plugged in.
Cannot pair Bluetooth device.	Player not in Bluetooth mode. Device too far. Pairing failed.	Ensure player is in "BLUE" mode. Move device closer. Restart pairing process on both devices.
FM radio reception is poor.	Weak signal. Interference.	Adjust player position. Try scanning for stations again.

Problem	Possible Cause	Solution
Remote control not working.	Batteries depleted or inserted incorrectly. Player not initially powered on.	Replace remote batteries. Ensure player's main power switch is ON.

8. Specifications

Feature	Detail
Model Number	Y-01
Brand	Gueray
Connectivity Technology	Auxiliary, Bluetooth, USB
Special Features	Bluetooth, Built-In Radio, Portable, Programmable Memory, Rechargeable
Battery	1800mAh Lithium Polymer (included)
Item Weight	1.76 pounds
Package Dimensions	10.08 x 9.69 x 2.32 inches

9. Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official Gueray website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I am in Japan, and even when I switch my Gueray Y-01 CD player to FM mode, I can only receive AM stations. How can I fix this?

Based on the Gueray Y-01 manual, here are the steps to troubleshoot and improve FM radio reception:Verify Mode: Ensure the device is definitely in FM mode by pressing the Mode button until "FM" is...

Read full answer

How do I select numbers 10 and above using the remote control for the Gueray Portable CD Player Y-01?

The user manual for the Gueray Portable CD Player Y-01 states that the remote control has "Numeric Buttons: For direct track selection in CD/USB mode or station selection in FM mode." However, it does...

Read full answer