M&S 79424-200

Wahl Color Code 17 Piece Hair Cutting Kit

Model: 79424-200

Introduction

This manual provides comprehensive instructions for the safe and effective use of your Wahl Color Code 17 Piece Hair Cutting Kit, Model 79424-200. This kit is designed to provide precise and easy haircuts at home, featuring color-coded guide combs for simple length selection and self-sharpening blades for long-lasting performance. Please read this manual thoroughly before first use and retain it for future reference.



Image: The Wahl Color Code 17 Piece Hair Cutting Kit, showcasing the clipper, color-coded guide combs, and the durable storage case.

Safety Information

WARNING: To reduce the risk of injury or damage, always follow basic safety precautions when using electrical appliances.

- **Electrical Safety:** This appliance is for household use only. Do not immerse the clipper in water or other liquids. Keep the cord away from heated surfaces. Always unplug the appliance immediately after use and before cleaning.
- **Sharp Blades:** The clipper blades are sharp. Handle with care. Do not touch the blades with your fingers or other body parts while the clipper is operating. Always use the blade guard when the clipper is not in use.

- **Scissors Safety:** The included scissors have sharp blades. Use caution when handling. Keep out of reach of children.
- **Proper Use:** Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Do not operate the clipper with a damaged cord or plug, or if it is not working properly.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Package Contents

Your Wahl Color Code 17 Piece Hair Cutting Kit includes the following items:

- Wahl Hair Clipper with Blade Guard
- Durable Storage Case
- 10 Color-Coded Guide Combs (ranging from 1/8" to 1")
- Styling Comb
- Scissors
- Cleaning Brush
- Blade Oil
- English/Spanish Instructions/Styling Guide



Image: All 17 pieces of the kit, including the clipper, various color-coded guide combs, scissors, comb, cleaning brush, and blade oil, alongside the storage case.

Setup

1. **Unpack:** Carefully remove all components from the storage case and packaging.
2. **Inspect:** Check the clipper and all accessories for any signs of damage. Do not use if damaged.
3. **Initial Oiling:** Before first use, apply a few drops of the included blade oil to the clipper blades. Turn the clipper on for a few seconds to distribute the oil. Wipe off any excess oil.
4. **Power Connection:** Ensure the clipper's power switch is in the "OFF" position. Plug the clipper into a standard electrical outlet. The cord measures 7 feet in length.



Image: The Wahl hair clipper with its power cord, demonstrating its corded electric power source, along with some guide combs and the cleaning brush.

Operating Instructions

Choosing a Guide Comb:

The kit includes 10 color-coded guide combs, making it easy to select your desired hair length. Each comb is color-matched to a specific length, ranging from 1/8" to 1". Refer to the color chart on the clipper or in the styling guide for precise length identification.

Attaching Guide Combs:

With the clipper turned off, align the guide comb with the clipper blade and snap it securely into place. Ensure it is firmly attached before turning the clipper on.

Using the Adjustable Taper Lever:

The clipper features an adjustable taper lever located on the side. This lever allows you to change the closeness of your cut without changing guide combs. Moving the lever up (towards the blade) provides a closer cut, while moving it down (away from the blade) leaves the hair slightly longer. This is ideal for blending and fading.

Haircutting Tips:

- Always start with a longer guide comb than you think you need, and gradually work your way down to shorter lengths.
- For best results, cut hair when it is clean and dry.
- Use smooth, overlapping strokes.
- Comb the hair frequently to remove loose clippings and check for evenness.
- Use the included scissors for detailing around ears, neckline, or for longer hair sections.

Maintenance

Cleaning the Blades:

1. After each use, turn off and unplug the clipper.
2. Use the included cleaning brush to brush away any loose hair from the blades.

3. For a more thorough cleaning, the blades can be removed (refer to the styling guide for specific instructions).

Oiling the Blades:

To ensure optimal performance and blade longevity, apply 2-3 drops of Wahl clipper oil to the blades after every few haircuts or as needed. Turn the clipper on for a few seconds to allow the oil to spread evenly. Wipe off any excess oil with a soft cloth.
Note: Only use Wahl clipper oil or a similar high-quality blade oil. Do not use hair oil, grease, or any oil mixed with kerosene or any solvent, as this will evaporate and slow down the blades.

Storage:

Store the clipper and all accessories in the durable storage case provided. Ensure the blade guard is on the clipper when stored to protect the blades.

Troubleshooting

- **Clipper does not turn on:**
  - Ensure the clipper is securely plugged into a working electrical outlet.
  - Check the power switch on the clipper to ensure it is in the "ON" position.
- **Clipper pulls hair or cuts poorly:**
  - The blades may be dull or misaligned. Refer to the styling guide for blade alignment instructions.
  - The blades may need oiling. Apply Wahl clipper oil as described in the Maintenance section.
  - Hair buildup may be affecting performance. Clean the blades thoroughly.
- **Clipper runs hot:**
  - Ensure the blades are properly oiled. Lack of lubrication can cause friction and heat.
  - Avoid prolonged continuous use. Allow the clipper to cool down if it becomes excessively warm.

If problems persist, please refer to the Warranty and Support section for assistance.

Specifications

Attribute	Detail
Model Number	79424-200
Power Source	Corded Electric
Cord Length	7 feet (approx. 2.1 meters)
Blade Material	Stainless Steel
Special Features	Self-Sharpening Blades, Color Coded Attachment Guides, Adjustable Taper Lever
Guide Comb Sizes	1/8", 1/4", 3/8", 1/2", 5/8", 3/4", 7/8", 1" (plus left & right ear tapers)
Package Dimensions	25.65 x 15.24 x 6.86 cm
Weight	544 g
Recommended Uses	Head, facial (beard, mustache), body grooming

Warranty and Support

This Wahl Color Code Hair Cutting Kit comes with a**3-year limited manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
For warranty service, technical support, or to purchase replacement parts, please contact Wahl customer service. Contact information can typically be found on the product packaging or the official Wahl website. Please have your model number (79424-200) ready when contacting support.
For more information and tips, you may visit the official Wahl website or refer to the detailed styling guide included in your kit.

© 2024 M&S. All rights reserved. Wahl is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question