Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY WXZY-RC-GD1-ACEF

ALLIMITY Replacement Remote Control User Manual

For Grundig TVs (Models RC-YC1, RC-23, RC-GD1 and compatible series)

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY Replacement Remote Control, designed for use with various Grundig television models. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. This remote control is a direct replacement and typically requires no programming.

2. Product Overview

The ALLIMITY replacement remote control is designed to replicate the functionality of original Grundig TV remote controls, specifically models RC-YC1, RC-23, and RC-GD1, and is compatible with a wide range of Grundig TV series. It features a standard layout for intuitive navigation and control of your television.



Figure 2.1: Front view of the ALLIMITY Replacement Remote Control. This image displays the full button layout, including power, mute, number keys, volume, channel, navigation, and media control buttons.



Figure 2.2: Angled view of the ALLIMITY Replacement Remote Control, highlighting its ergonomic design and button placement.

3. Setup

This replacement remote control is designed for immediate use with compatible Grundig TV models without the need for complex programming or setup procedures. Simply install the batteries, and it should function directly.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. **Note:** Rechargeable batteries may not be compatible or provide optimal performance.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote control is ready for operation.

4. Operating Instructions

The ALLIMITY replacement remote control features a standard button layout for easy control of your Grundig TV. Below is a general guide to common button functions:

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or unmutes the TV audio.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **V+/V-:** Adjusts the volume up or down.
- **P+/P-:** Changes the channel up or down.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **FAV:** Accesses favorite channels.
- **16:9:** Adjusts the screen aspect ratio.
- **REPEAT:** Repeats the current media playback.
- **?/A-B / EPG:** Accesses information or Electronic Program Guide.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback functions.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within interactive menus or teletext.
- **TXT:** Accesses Teletext.
- **i:** Displays information about the current program.

For specific functions related to your TV model, refer to your Grundig TV's original user manual.

5. Maintenance

5.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote control's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Dispose of used batteries according to local regulations.

5.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

6. Troubleshooting

- **Remote control is not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the maximum operating range (approximately 10 meters) and pointing the remote directly at the TV.
- **Some buttons are not working:**
  - This remote is a direct replacement. Verify that the specific function you are trying to use was available on your original Grundig remote and is supported by your TV model.
  - Clean the remote control, as dirt or debris might be interfering with button contacts.
- **TV responds intermittently:**
  - This could indicate low battery power. Replace the batteries.
  - Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the infrared signal.

7. Specifications

Brand	ALLIMITY
Model Number	WXZY-RC-GD1-ACEF
Compatible Grundig Models	RC-YC1, RC-23, RC-GD1, 32GLX3002T, 32GLX3100T2, 32GLX3101T2, 32GLX3102C, 32GLX4000, 32LHD72DVB-T, 32VLC4010C, 32VLE4300BA, 32VLE4301BA, 32VLE4302BF, 32VLE4303BF, 32VLE4304BF, 32VLE4322BF, 32VLE4323BF, 32VLE4324BF, 32VLE434BA, 32VLE4401BF, 32XLC3200BA, 32XLC3220BA, 32XLC325BA, 40VLE4322BF, 40VLE4324BF, 40VLE4420BF, 40VLE4421BF, 48VLE4421BF, 48VLE4421WF, 720117145700
Connectivity Technology	Infrared (Infrarot)
Maximum Range	10 Meters
Power Source	2 x AAA Alkaline Batteries (not included)
Product Dimensions	12 x 7.7 x 0.3 cm
Item Weight	50 g
Color	Black

8. Warranty and Support

For information regarding warranty coverage, returns, or technical support, please refer to the purchase documentation or

contact the seller directly. Specific warranty terms may vary depending on the retailer and region of purchase.
For further assistance, you may also visit the ALLIMITY brand page on Amazon.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08BHMY9R7

More documents and user manuals: **https://manuals.plus/**