Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SEGA SG94459

Instruction Manual

SEGA Demon Slayer: Kimetsu no Yaiba SPM Figure Nezuko Kamado

Model: SG94459

Introduction

This manual provides essential information for the proper setup, care, and maintenance of your SEGA Demon Slayer: Kimetsu no Yaiba SPM Figure Nezuko Kamado. Please read through this manual carefully to ensure the longevity and optimal display of your collectible figure.

Safety Information

Warning: Keep away from small children. This product contains small parts and is intended for collectors aged 15 years and up.

What's in the Box

- Nezuko Kamado Figure
- Display Base Stand

Setup

1. Carefully remove the Nezuko Kamado figure and the display base from their packaging.
2. Identify the pegs on the display base and the corresponding holes on the figure's feet.
3. Gently align the figure's feet with the pegs on the base. Apply light, even pressure to secure the figure onto the base. Do not force the connection.
4. Place the assembled figure on a flat, stable surface away from direct sunlight, extreme temperatures, and high humidity.



©Koyoharu Gotoge / SHUEISHA, Aniplex, ufotable

Figure securely attached to its display base.

Operating (Display)

The Nezuko Kamado SPM Figure is a static collectible designed for display. Once assembled on its base, it can be placed in various settings to enhance your collection. Ensure the display location is:

- **Stable:** To prevent accidental falls and damage.
- **Out of Direct Sunlight:** Prolonged exposure to sunlight can cause paint fading or material degradation.
- **Away from Extreme Temperatures:** Avoid placing near heat sources or in very cold environments.
- **Low Humidity:** High humidity can affect the figure's materials over time.



Front view of the Nezuko Kamado figure.



Rear view of the Nezuko Kamado figure, highlighting hair and garment details.

Maintenance

To keep your figure in pristine condition:

- **Dusting:** Regularly dust the figure with a soft, dry brush or a microfiber cloth to prevent dust buildup.
- **Cleaning:** For more stubborn dirt, lightly dampen a soft cloth with water (distilled water is preferred) and gently wipe the affected areas. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the paint or material.
- **Handling:** Always handle the figure by its base or main body. Avoid touching delicate parts like hair or small accessories to prevent breakage or paint transfer.



Close-up view of Nezuko's facial details.

Troubleshooting

While SEGA figures are crafted with high quality, minor issues can occasionally occur:

- **Figure Not Fitting on Base:** Ensure the pegs and holes are correctly aligned. Apply gentle, even pressure. If resistance is met, do not force it; check for any obstructions or manufacturing defects.
- **Minor Paint Imperfections:** Small variations in paint application are common in mass-produced figures. These are typically not considered defects unless they significantly detract from the figure's appearance.
- **Figure Instability:** Ensure the figure is fully seated on its base and placed on a level surface. If the base

itself is warped, contact customer support.

Specifications

Product Dimensions	6 x 6 x 8 inches
Item Weight	10.8 ounces
Model Number	SG94459
Manufacturer	SEGA
Recommended Age	15 years and up
Release Date	December 2, 2020



Approximate dimensions of the figure.

Warranty and Support

For information regarding warranty, returns, or further product support, please refer to the retailer's policy where the product was purchased or visit the official SEGA website. Keep your proof of purchase for any warranty claims.
For additional inquiries, you may contact SEGA customer service through their official channels.

© 2024 SEGA. All rights reserved. Demon Slayer: Kimetsu no Yaiba © Koyoharu Gotoge / SHUEISHA, Aniplex, ufotable.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08BNQ3YW9

More documents and user manuals: **https://manuals.plus/**