KitchenAid KSM3316

KitchenAid Artisan Mini Series Tilt-Head Stand Mixer Instruction Manual

Models: KSM3316, KSM3311XCU

1. Introduction

Thank you for choosing the KitchenAid Artisan Mini Series Tilt-Head Stand Mixer. This compact yet powerful appliance is designed to simplify your baking and cooking tasks. With its 3.5-quart capacity and versatile attachments, it is ideal for preparing a variety of recipes, from small batches of cookies to a loaf of bread. Its tilt-head design provides easy access to the bowl and accessories, making ingredient addition and cleanup effortless.

2. Safety Information

Please read all instructions carefully before using your KitchenAid Stand Mixer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the mixer from the power outlet before cleaning, assembling, or disassembling parts.
- Keep hands, hair, and clothing, as well as spatulas and other utensils, away from moving beaters during operation to prevent injury.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Ensure the tilt-head is locked in place during operation to prevent movement.
- This appliance is intended for household use only.

3. Package Contents

Your KitchenAid Artisan Mini Series Tilt-Head Stand Mixer package includes the following items:

- KitchenAid Artisan Mini Series Tilt-Head Stand Mixer (Contour Silver)
- 3.5 Quart Stainless Steel Bowl with Handle
- Flat Beater (Coated)
- Dough Hook (Coated)
- Wire Whip (Stainless Steel)

Optional attachments for various culinary tasks are sold separately and can be connected to the front power hub.



Figure 1: KitchenAid Artisan Mini Stand Mixer with 3.5-quart bowl.

4. Setup

1. **Placing the Bowl:** Position the 3.5-quart stainless steel bowl onto the base of the mixer. Rotate the bowl clockwise until it locks securely into the base. The bowl features grooves on its bottom that align with the base for a stable fit.
2. **Attaching Accessories:**
    - Ensure the mixer is unplugged.
    - Push the tilt-head lock lever to the 'unlock' position and tilt the motor head back.
    - Slide the desired accessory (flat beater, dough hook, or wire whip) onto the beater shaft. Align the notch on the accessory with the pin on the shaft, then twist to secure it.
    - Lower the motor head and push the tilt-head lock lever to the 'lock' position. This ensures the head remains stable during operation.



Figure 2: Mixer with dough hook installed and mixing dough.

5. Operating Instructions

1. **Power On:** Plug the mixer into a grounded electrical outlet.
2. **Speed Control:** The mixer features a 10-speed slide control located on the side of the motor head. Slide the lever

to select your desired speed, from 'Stir' (lowest) to '10' (highest), depending on your recipe's requirements.

3. **Attachment Hub:** The front power hub allows for the connection of various optional attachments (sold separately), such as pasta makers, grinders, or ice cream makers. To use, simply remove the hub cover and insert the attachment, securing it with the thumbscrew.
4. **Capacity:** The 3.5-quart stainless steel bowl offers ample capacity for mixing up to 5 dozen cookies, a single loaf of bread, a batch of guacamole, or pulled pork.
5. **Mixing:** The powerful motor is designed to handle nearly any task, from gently stirring wet and dry ingredients to kneading dense bread dough or whipping cream to stiff peaks.



Figure 3: Mixer demonstrating the use of an optional pasta maker attachment on the front power hub.

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your KitchenAid Stand Mixer.

- **Cleaning the Bowl:** The 3.5-quart stainless steel bowl is dishwasher-safe for easy cleaning.
- **Cleaning Attachments:** The coated flat beater, coated dough hook, and stainless steel wire whip are all dishwasher-safe.
- **Cleaning the Mixer Body:** Wipe the mixer body with a damp cloth and dry thoroughly. Do not immerse the mixer body in water or other liquids.



Figure 4: Close-up view of the 3.5-quart stainless steel mixing bowl, highlighting its handle and smooth interior for easy cleaning.

7. Troubleshooting

If your mixer is not operating as expected, please refer to the following common issues:

- **Mixer Not Turning On:** Ensure the power cord is securely plugged into a grounded electrical outlet. Check if the speed control is set to '0' (Off) before attempting to turn it on.

- **Attachments Not Working:** Verify that the chosen attachment is correctly installed on the beater shaft and twisted into place. Ensure the tilt-head is fully lowered and locked.
- **Head Jumps During Mixing:** Confirm that the tilt-head lock lever is in the 'lock' position. This prevents the head from moving during heavy mixing tasks.

For further assistance, please contact KitchenAid Customer Support.

8. Specifications

- **Brand:** KitchenAid
- **Model Name:** KSM3316
- **Item Model Number:** KSM3311XCU Artisan Mini Serie
- **Color:** Contour Silver
- **Product Dimensions:** 7.8"D x 12.3"W x 12.3"H
- **Special Feature:** Removable Bowl, Safety Lock
- **Capacity:** 3.5 Quarts (5 Liters)
- **Controls Type:** Knob (10-speed slide control)
- **Item Weight:** 14.3 Pounds
- **Manufacturer:** KitchenAid
- **UPC:** 753575628550
- **Material:** Zinc
- **Voltage:** 120 Volts
- **Date First Available:** June 23, 2020

9. Warranty and Support

Your KitchenAid Artisan Mini Series Tilt-Head Stand Mixer is backed by KitchenAid's commitment to quality. For specific warranty details, please refer to the documentation included with your product or visit the official KitchenAid website.

This product is eligible for 90-day easy returns. Customer support is available for any questions or assistance you may need.

For customer support, please visit the seller's page or the official KitchenAid support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question