One Fire GJWH102236w5

One Fire Baby Night Light Star Projector

Model: GJWH102236w5 - User Manual

1. PRODUCT OVERVIEW

The One Fire Baby Night Light Star Projector is a versatile device designed to create a soothing and engaging environment for children. It features multiple projection films, Bluetooth music connectivity, 360-degree rotation, and convenient remote control operation. This manual provides detailed instructions for safe and effective use of your projector.

Image 1.1: The One Fire Baby Night Light Star Projector, featuring a rabbit design on top.

2. SAFETY INSTRUCTIONS

- Keep the device away from water and moisture.
- Do not disassemble or attempt to repair the device yourself. Contact customer support if issues arise.
- Use only the provided USB cable for charging.
- Ensure the device is placed on a stable, flat surface.
- Avoid direct eye exposure to the LED light source.
- This product is not a toy. Adult supervision is recommended when used by children.

3. PACKAGE CONTENTS

Please check the package for the following items:

- One Fire Baby Night Light Star Projector Unit
- USB Type-C Charging Cable
- Remote Control

- Projection Films (Quantity: 15 sets, including various themes)

- User Manual

4. PRODUCT FEATURES

- **Safe LED Light Source:** Provides a soft, gentle glow suitable for children's eyes.

- **Multiple Projection Films:** Includes 15 diverse film themes for varied visual experiences.

- **Colorful Lighting Effects:** Offers 96 modes with various color combinations (red, yellow, green, etc.).

- **360° Rotation:** Projects dynamic, moving patterns on walls and ceilings.

- **Bluetooth Music Speaker:** Connects wirelessly to play lullabies or other audio.

- **Remote Control:** Manages power, light colors, brightness, rotation, music, and timer settings.

- **Auto-Off Timer:** Programmable for 15, 30, or 60 minutes.

- **USB Rechargeable:** Convenient Type-C USB charging.

- **Dual Functionality:** Functions as a star projector or a standard night light by removing the projection cover.

Image 4.1: Overview of the 15 colorful projection films included with the night light, categorized into Bedtime Stories, Puzzle Education, and Festival Gifts.

5. SETUP

5.1 Charging the Device

1. Connect the provided USB Type-C cable to the charging port on the projector.

2. Plug the other end of the USB cable into a compatible USB power adapter (5V) or a computer USB port.

3. The charging indicator light will illuminate. Once fully charged, the indicator may change color or turn off.

5.2 Installing/Changing Projection Films

The projector comes with various film themes. Follow these steps to install or change them:

1. Gently remove the top dome cover of the projector.
2. Locate the inner transparent cylinder where the film is placed.
3. Carefully unroll your desired film and insert it into the cylinder, ensuring it fits snugly. The images on the film should face outwards.
4. Replace the top dome cover, aligning it correctly.

Image 5.1: A child interacting with the One Fire Night Light, illustrating its use in a bedroom setting. The top dome cover is visible.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

- Press the power button on the projector or the remote control to turn the device on/off.

6.2 Projection Mode

- Ensure a projection film is installed and the top dome cover is in place for optimal projection.

- Use the light mode button on the projector or remote to cycle through different color combinations.

6.3 Night Light Mode

- To use as a standard night light, remove the inner projection film cylinder and ensure the top dome cover is in place. The device will emit a soft, diffused light.

6.4 Rotation Function

- Press the rotation button on the projector or remote control to activate or deactivate the 360-degree rotation feature.

Image 6.1: The night light projecting an ocean theme with 360-degree silent rotation, creating an immersive experience in a child's room.

7. REMOTE CONTROL FUNCTIONS

The remote control allows convenient operation from a distance. Ensure the remote has working batteries (1 Lithium-ion battery required, not included).

Image 7.1: A hand holding the remote control, demonstrating its use to adjust settings like timer and brightness for the night light.

Button	Function
Power On/Off	Turns the projector on or off.
Light Mode	Cycles through different light colors and effects.
Brightness	Adjusts between 3 brightness levels (100%, 60%, 30%).
Rotation	Activates or deactivates 360-degree rotation.
Music Play/Pause	Plays or pauses Bluetooth-connected music.
Previous/Next Track	Skips to the previous or next song.
Volume Up/Down	Adjusts the music volume.
Timer (15/30/60 min)	Sets the automatic shut-off timer for 15, 30, or 60 minutes.

8. BLUETOOTH PAIRING

To play music through the projector's built-in speaker, follow these steps to pair your device:

1. Ensure the projector is powered on.
2. Activate Bluetooth on your smartphone or other audio device.
3. Search for available Bluetooth devices. The projector will appear as "WH-E01".
4. Select "WH-E01" to pair. A confirmation sound may play from the projector once connected.
5. You can now play music from your device, controlling playback and volume via your device or the projector's remote control.

Image 8.1: A child sleeping peacefully with the night light projecting unicorn images, while a smartphone displays music playback, illustrating the Bluetooth music feature.

9. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the projector. Do not use abrasive cleaners or solvents.
- **Film Care:** Handle projection films carefully to avoid scratches or damage. Store them in a clean, dry place.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight.

10. TROUBLESHOOTING

Problem	Possible Cause	Solution
Projector does not turn on.	Low battery or no power.	Charge the device using the USB Type-C cable. Ensure the power adapter is working.
Projection is blurry or unclear.	Film not installed correctly or top cover is dirty.	Ensure the film is properly seated in the inner cylinder. Clean the top dome cover and lens with a soft cloth. Adjust the distance to the projection surface.
Bluetooth not connecting.	Projector not in pairing mode, or device too far.	Ensure the projector is on. Turn off and on Bluetooth on your device. Move your device closer to the projector. Check if another device is already connected.

Problem	Possible Cause	Solution
Remote control not working.	Dead battery or obstruction.	Replace the remote control battery (1 Lithium-ion). Ensure there is no obstruction between the remote and the projector.
Rotation function is not working.	Rotation feature is off.	Press the rotation button on the projector or remote control to activate it.

11. SPECIFICATIONS

Feature	Detail
Model Number	GJWH102236w5
Dimensions (L x W x H)	13.69 x 13.69 x 16.51 cm
Weight	530 grams
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Input	5 Volts
Rated Power	4.2 Watts
Light Source	LED (4 bulbs)
Luminous Flux	6 lumens
Battery Type	1 Lithium-ion (required, not included)
Connectivity	USB Type-C, Bluetooth (WH-E01)
Special Features	Rechargeable, Remote Control, Auto-Off Timer (15/30/60 min), 360° Rotation

12. WARRANTY AND SUPPORT

One Fire offers a **30-day refund policy** and a **12-month warranty** for this product. If you encounter any issues or have questions regarding your One Fire Baby Night Light Star Projector, please contact our customer support team.

Customer Support:

- For assistance, please refer to the contact information provided on the product packaging or the official One Fire website.

- When contacting support, please have your model number (GJWH102236w5) and purchase details ready.