De'Longhi FH2133

De'Longhi Rapid Crisp Air Fryer Instruction Manual

Model: FH2133

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before using the appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. Product Overview

The De'Longhi Rapid Crisp Air Fryer (Model FH2133) utilizes Duo Heat Technology for efficient cooking. Familiarize yourself with the components before operation.

Components

1. Main Unit with Hinged Lid
2. Control Panel (Digital Touch)
3. Viewing Window
4. 4-Quart Nonstick Cooking Bowl with Handle
5. Upper Heating Element (Convection)

6. Lower Heating Element (Radiant)



Image 2.1: Front view of the De'Longhi Rapid Crisp Air Fryer. This image displays the appliance in its closed state, highlighting the De'Longhi branding, the 'Rapid Crisp' logo, and the main control button on the front.



Image 2.2: Exploded view of the De'Longhi Rapid Crisp Air Fryer components. This image shows the main unit with its lid open, revealing the interior. Separated from the main unit are the removable nonstick cooking bowl with its handle, and the removable ring that sits inside the main unit.

3. Setup

Before first use, ensure the appliance is properly set up and cleaned.

1. **Unpacking:** Carefully remove all packaging materials, stickers, and labels from the appliance.
2. **Cleaning:** Wash the cooking bowl and any removable accessories (like the ring) in warm, soapy water. Rinse thoroughly and dry completely. Wipe the interior and exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 6 inches) around the appliance for proper ventilation. Do not place it directly against a wall or under cabinets.
4. **Assembly:** Insert the clean cooking bowl into the main unit. Ensure it is seated correctly.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance is designed for 120V operation.

4. Operating Instructions

The De'Longhi Rapid Crisp Air Fryer offers versatile cooking options with its Duo Heat Technology and intuitive controls.

Basic Operation

1. **Prepare Food:** Place your ingredients into the nonstick cooking bowl. For best results, do not overfill the basket.
2. **Close Lid:** Ensure the hinged lid is securely closed.
3. **Power On:** Press the power button on the control panel.
4. **Select Temperature:** Use the temperature controls to select one of the 4 preset temperature levels. Refer to the cooking guide (not included in this manual, typically provided separately) for recommended temperatures for various foods.
5. **Set Time:** Use the timer controls to set the desired cooking duration.
6. **Start Cooking:** Press the start button to begin the cooking process. The Duo Heat Technology will activate, utilizing both convection and radiant heat.
7. **Monitor Progress:** Use the viewing window to monitor cooking progress without opening the lid.
8. **Shake/Stir (Optional):** For even cooking, especially with items like fries, you may pause the cooking cycle, open the lid, and gently shake or stir the contents of the bowl. Close the lid to resume.
9. **Finish:** The appliance will signal when the cooking cycle is complete. Carefully open the lid using the handle.
10. **Remove Food:** Using heat-resistant utensils, carefully remove the cooked food from the nonstick bowl.



Image 4.1: Diagram illustrating the Duo Heat Technology in the De'Longhi Rapid Crisp Air Fryer. This image shows a cutaway view of the air fryer with french fries inside, depicting red arrows indicating the circulation of hot air from the top convection element and heat from the bottom radiant element, demonstrating how food is cooked evenly.



Image 4.2: A hand carefully removing the nonstick cooking bowl filled with golden-brown french fries from the De'Longhi Rapid Crisp Air Fryer. The lid of the air fryer is open, showing the internal heating element and fan. This demonstrates the ease of access and removal of cooked food.

Cooking Tips

- For crispier results, lightly brush or spray food with oil.
- Smaller pieces of food generally require shorter cooking times.
- Preheating the air fryer for a few minutes can improve cooking performance for some recipes.
- Avoid overcrowding the cooking bowl to allow for proper air circulation and even cooking.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

1. **Before Cleaning:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Removable Parts:** The nonstick cooking bowl and removable ring are dishwasher safe. Alternatively, they can be washed by hand in warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Interior:** For the interior of the main unit, wipe with a damp cloth. For stubborn residue, a small amount of mild detergent can be used, followed by wiping with a clean, damp cloth to remove any soap residue.
5. **Heating Elements:** Gently clean the heating elements with a soft brush to remove any food particles. Do not use abrasive materials.
6. **Storage:** Ensure all parts are clean and dry before storing the appliance. Store in a cool, dry place.

6. Troubleshooting

If you encounter issues with your De'Longhi Rapid Crisp Air Fryer, refer to the following common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Overcrowding the cooking bowl; insufficient cooking time/temperature; food not shaken/stirred.	Do not overfill the bowl. Increase cooking time or temperature as needed. Shake or stir food halfway through the cooking process.
Food is not crispy.	Not enough oil (for some foods); cooking temperature too low; too much moisture in food.	Lightly spray or brush food with oil. Increase cooking temperature. Pat food dry before cooking.
White smoke coming from appliance.	Grease residue from previous use; cooking high-fat foods.	Clean the cooking bowl and heating elements thoroughly after each use. This is normal when cooking fatty foods; ensure proper ventilation.
Appliance emits unusual odor.	First use odor; burning food residue.	A slight odor is normal during first few uses. Ensure the appliance is clean and free of food residue.

7. Specifications

Key technical specifications for the De'Longhi Rapid Crisp Air Fryer, Model FH2133.

- **Model Name:** FH2133
- **Brand:** De'Longhi
- **Capacity:** 4 Quarts
- **Output Wattage:** 1700 Watts
- **Voltage:** 120.00 V
- **Product Dimensions:** 10.83"D x 10.83"W x 11.41"H
- **Item Weight:** 12.37 Pounds
- **Material:** Plastic
- **Color:** Black
- **Control Method:** Touch (Digital)
- **Special Features:** Duo Heat Technology, Viewing Window, Surround Heating System with Double Elements
- **Nonstick Coating:** Yes
- **Dishwasher Safe Parts:** Yes (Removable bowl and ring)
- **UPC:** 044387213325

8. Warranty and Support

Your De'Longhi Rapid Crisp Air Fryer comes with a limited warranty and customer support options.

Warranty Information

This appliance is covered by a **1-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, accident, commercial use, or unauthorized modifications.

Customer Support

For technical assistance, warranty claims, or to purchase replacement parts, please contact De'Longhi Customer Service. Refer to the official De'Longhi website or your purchase documentation for the most current contact information.
Online Resources: Visit the official De'Longhi website for product registration, FAQs, and additional support materials. www.delonghi.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question