Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arafuna CD5188B-01

ARAFUNA Portable CD Player Model CD5188B-01 Instruction Manual

Your guide to setup, operation, and maintenance.

Overview Setup Operation Maintenance Safety Information Troubleshooting Package Contents Specifications Product Warranty & Support

Introduction

Thank you for choosing the ARAFUNA Portable CD Player Model CD5188B-01. This device is designed to provide high-quality audio playback from your favorite CDs, offering portability and ease of use. Please read this manual thoroughly before operating the device to ensure proper usage and to maximize its lifespan.

Important Safety Information

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Avoid placing the unit near heat sources or in direct sunlight.
- Do not disassemble or attempt to repair the unit yourself. Refer all servicing to qualified personnel.
- Use only the specified power adapter or batteries.
- Keep the unit away from strong magnetic fields.
- Clean the unit with a soft, dry cloth. Do not use liquid cleaners.
- Prolonged listening at high volume levels may cause hearing damage.

Package Contents

Please check that all items are present in your package:

- ARAFUNA Portable CD Player (Model CD5188B-01)
- Remote Control
- USB Power Cable
- Auxiliary Audio Cable (3.5mm)
- Earphones

- User Manual

Product Overview

Familiarize yourself with the various parts and controls of your portable CD player.

Front View



Image: Front view of the ARAFUNA Portable CD Player, showing the LCD display and control buttons.

1. **LCD Display:** Shows track number, playback mode, and battery status.
2. **Play/Pause Button:** Starts or pauses playback.
3. **Stop Button:** Stops playback.
4. **Skip Forward/Fast Forward Button:** Skips to the next track or fast forwards within a track.
5. **Skip Back/Fast Rewind Button:** Skips to the previous track or fast rewinds within a track.
6. **Mode Button:** Selects playback modes (Repeat 1, Repeat All, Intro, Random).

7. **Program Button:** Used to program a custom playback order for tracks.

Side/Rear View



Image: Side view of the ARAFUNA Portable CD Player, highlighting the various ports and controls.

1. **DC 5V Input:** For connecting the USB power cable.
2. **Headphone Jack (3.5mm):** For connecting earphones or external speakers.
3. **Volume Control Dial:** Adjusts the audio output volume.
4. **Hold Switch:** Locks all buttons to prevent accidental operation.
5. **Open Button:** Releases the CD compartment lid.

Internal Components and Features



Image: An exploded view of the CD player showing its internal components, highlighting the upgraded chip for Bass Boost and the Program button for track customization.

- **Bass Boost:** Enhanced audio output for deeper bass.
- **Anti-Skip/Shockproof Protection:** Designed to minimize audio interruptions during movement.

Setup

Powering the Device

The ARAFUNA Portable CD Player can be powered by two AA batteries (not included) or via the included USB power cable.

1. **Using Batteries:**
    - Open the battery compartment on the bottom of the player.
    - Insert two AA batteries, ensuring correct polarity (+/-).
    - Close the battery compartment securely.
2. **Using USB Power:**
    - Connect the small end of the USB power cable to the DC 5V input port on the player.
    - Connect the large end of the USB power cable to a USB power adapter (not included) or a powered USB port (e.g., on a computer).

Connecting Headphones/Speakers

Connect the included earphones or your preferred 3.5mm audio headphones/speakers to the headphone jack on the side of the player.



Image: The ARAFUNA Portable CD Player shown connected to earphones, resting on a desk alongside glasses and a plant.

Operating Instructions

Inserting a CD

1. Slide the "OPEN" switch to open the CD compartment lid.
2. Carefully place a CD onto the center spindle with the label side facing up.
3. Gently press the CD down until it clicks into place.
4. Close the CD compartment lid firmly until it latches.

Basic Playback

1. Ensure the "HOLD" switch is in the OFF position.
2. Press the **PLAY/PAUSE** button to start playback. The LCD will display the track number and elapsed time.
3. To pause playback, press the **PLAY/PAUSE** button again. Press it once more to resume.
4. To stop playback, press the **STOP** button.
5. To skip to the next track, press the **SKIP FORWARD** button.
6. To skip to the previous track, press the **SKIP BACK** button.
7. To fast forward, press and hold the **SKIP FORWARD** button. Release to resume normal playback.
8. To fast rewind, press and hold the **SKIP BACK** button. Release to resume normal playback.
9. Adjust the volume using the **VOLUME** dial on the side of the player.

Playback Modes

Press the **MODE** button repeatedly to cycle through the following playback options:

- **Play in Order:** Plays tracks sequentially.
- **Single Cycle (Repeat 1):** Repeats the current track.
- **ALL (Repeat All):** Repeats all tracks on the CD.
- **INTRO:** Plays the first 10 seconds of each track.
- **RND (Random Play):** Plays tracks in a random order.

Program Playback

You can program up to 20 tracks to play in a specific order.

1. While the CD is stopped, press the **PROGRAM** button. The LCD will show "PROG" and "01".
2. Use the **SKIP FORWARD** or **SKIP BACK** buttons to select the desired first track.
3. Press the **PROGRAM** button again to confirm the track. The display will show "02".
4. Repeat steps 2 and 3 to add more tracks to your program list.
5. After programming all desired tracks, press the **PLAY/PAUSE** button to start programmed playback.
6. To clear the program, press the **STOP** button twice.

Sound Effects

The player offers 5 sound effects. Press the **EQ** button (if available, or refer to remote control) to cycle through:

- Normal
- BBS (Bass Boost System)
- Pop
- Jazz
- Rock
- Classic

Using the Hold Switch

Slide the **HOLD** switch to the ON position to lock all buttons. This prevents accidental button presses during transport or when the player is in a pocket or bag.



Image: A woman running outdoors with the ARAFUNA Portable CD Player, illustrating its enhanced anti-shock capabilities for active use.

MAINTENANCE

Cleaning the Unit

- Wipe the exterior of the player with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or benzene, as these can damage the surface.
- To clean the CD lens, use a specialized CD lens cleaning kit. Do not touch the lens directly.

CD Handling

- Always hold CDs by their edges to avoid fingerprints on the playing surface.

- Store CDs in their cases to protect them from scratches and dust.
- Clean dirty CDs with a soft, lint-free cloth, wiping from the center outwards.

Storage

- When not in use for extended periods, remove batteries to prevent leakage.
- Store the player in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your CD player, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Player does not power on.	Batteries are dead or inserted incorrectly. USB power cable is not connected properly or power source is faulty. Hold switch is ON.	Replace batteries or check polarity. Ensure USB cable is securely connected and power source is active. Slide the Hold switch to OFF.
No sound.	Volume is too low. Headphones/speakers not connected properly. Headphones/speakers are faulty.	Increase volume using the dial. Ensure headphones/speakers are fully plugged into the jack. Test with another pair of headphones/speakers.
CD skips or playback is interrupted.	CD is dirty or scratched. Player is subjected to excessive vibration. CD is not properly seated.	Clean the CD or try a different CD. Minimize movement or place the player on a stable surface. Open and re-seat the CD firmly.
"DISC" or "NO DISC" error on display.	No CD inserted. CD is inserted upside down. CD is unreadable (damaged, non-standard format).	Insert a CD. Ensure the CD is inserted with the label side facing up. Try a different, known-good CD.

Specifications

Feature	Detail
Model Number	CD5188B-01
Product Dimensions	5.7 x 5.7 x 1 inches
Item Weight	12.7 ounces (360 Grams)
Compatible Disc Formats	CD, CD-R, CD-RW, MP3, WMA
Power Source	2 x AA Batteries (not included), DC 5V USB
Connectivity Technology	Auxiliary (3.5mm), USB
Special Features	Portable, Bass Boost, Anti-Skip/Shockproof Protection

Feature	Detail
Included Components	Remote Control, USB Power Cable, Auxiliary Audio Cable, Earphones

Warranty and Customer Support

ARAFUNA products are designed and manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official ARAFUNA website.
If you experience any issues or have questions regarding your ARAFUNA Portable CD Player, please contact our customer support team. Contact information can typically be found on our website or on the packaging.

- **Online Support:** Visit the ARAFUNA official website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or warranty card for the customer service email address.

© 2023 ARAFUNA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08C9RKWQ4

More documents and user manuals: **https://manuals.plus/**