Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aspor A663

Aspor Bluetooth Speaker A663 User Manual

Model: A663

Introduction

Thank you for purchasing the Aspor Bluetooth Speaker A663. This manual provides detailed instructions on how to set up, operate, and maintain your speaker. Please read this manual carefully before use to ensure optimal performance and longevity of your device.



Image: Front view of the Aspor Bluetooth Speaker A663, showcasing its cylindrical design with mesh fabric and red accent buttons.

Package Contents

Please check the package for the following items:

- Aspor Bluetooth Speaker A663
- USB Charging Cable
- AUX Audio Cable
- User Manual



Image: The Aspor Bluetooth Speaker A663, its retail box, USB charging cable, AUX audio cable, and user manual laid out.

Product Features

- Wireless Standard: Bluetooth 4.2
- Transmission Distance: Up to 10 meters
- Output Power: 5W
- Play Time: Approximately 4 hours
- Frequency Effect: 100Hz~18KHz
- Input Power: DC5V 500mA
- Support for Micro SD Card Playback
- Support for AUX Playback
- Support for Hands-free Calls
- Built-in FM Radio

Controls and Indicators

Familiarize yourself with the buttons and ports on your Aspor A663 speaker:



Image: Top view of the Aspor Bluetooth Speaker A663 showing the control panel with buttons and ports. The buttons include power, mode, and volume controls. Ports include DC 5V, TF (Micro SD), USB, and AUX.

- **Power Button ( ):** Press and hold to power on/off.
- **Mode Button (M):** Press to switch between Bluetooth, FM Radio, AUX, and Micro SD card modes.
- **Volume Down** / **Previous Track (<):** Short press for previous track, long press to decrease volume.
- **Volume Up** / **Next Track (>):** Short press for next track, long press to increase volume.
- **DC 5V Port:** For charging the speaker.
- **TF Card Slot:** For Micro SD card playback.
- **USB Port:** (Function not explicitly detailed, typically for USB drive playback or charging out)

- **AUX Port:** For wired audio connection.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the DC 5V port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status (specific light behavior not detailed in product info, refer to device for actual behavior).

2. Powering On/Off

- **To Power On:** Press and hold the Power button () for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the Power button () again for a few seconds until the speaker powers down.

3. Bluetooth Pairing

1. Power on the speaker. It will automatically enter Bluetooth pairing mode (indicated by a flashing light or audible prompt).
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices. You should see "A663" or "Aspor A663" in the list.
4. Select "A663" to connect. Once paired, you will hear a confirmation sound.
5. The speaker will automatically connect to the last paired device when powered on, if that device's Bluetooth is active and within range.

4. AUX Connection

Use the provided AUX audio cable to connect the speaker's AUX port to the audio output jack of your device (e.g., MP3 player, computer). The speaker will automatically switch to AUX mode or you may need to press the Mode button (M) to select AUX.

5. Micro SD Card Playback

Insert a Micro SD card (TF card) with audio files into the TF card slot. The speaker will automatically switch to Micro SD card mode and begin playing music. If not, press the Mode button (M) to select this mode.

Operating

Music Playback

- **Play/Pause:** (No explicit button mentioned, typically the Power button or a dedicated Play/Pause button, assuming it's integrated with Power or Mode for simplicity, or controlled by source device).
- **Next Track:** Short press the '>' button.
- **Previous Track:** Short press the '<' button.
- **Volume Up:** Long press the '>' button.
- **Volume Down:** Long press the '<' button.

Hands-free Calls (Bluetooth Mode)

- **Answer Call:** When a call comes in, press the Power button () once to answer.
- **End Call:** During a call, press the Power button () once to end the call.
- **Reject Call:** Press and hold the Power button () to reject an incoming call.

FM Radio Operation

1. Press the Mode button (M) to switch to FM Radio mode.
2. (No explicit button for auto-scan, assuming Power button or Mode button might trigger it, or it scans automatically upon entering FM mode).
3. Use the '<' and '>' buttons to switch between saved radio stations or manually tune.

Maintenance

- Keep the speaker away from extreme temperatures, direct sunlight, and dusty environments.
- Do not expose the speaker to water or excessive moisture, despite being listed as "Is Waterproof: TRUE" in specifications, general caution is advised for electronics.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for extended periods, charge the speaker at least once every three months to preserve battery life.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Device Bluetooth off; Speaker too far.	Ensure speaker is in pairing mode; Turn on device Bluetooth; Move speaker closer to device (within 10m).
No sound.	Volume too low; Incorrect mode selected; Device not playing.	Increase speaker and device volume; Press Mode button to select correct input; Ensure device is playing audio.
FM radio reception is poor.	Weak signal; Interference.	Relocate the speaker to an area with better reception.

Specifications

Feature	Detail
Model Name	A663
Wireless Standard	Bluetooth 4.2
Transmission Distance	10 meters
Output Power	5W
Frequency Effect	100Hz~18KHz
Input Power	DC5V 500mA
Play Time	4 hours
Battery Life	4 Hours

Feature	Detail
Battery Type	1500mAh/5.55Wh
Special Features	Radio, SD Card, AUX Playback, Hands-free Calls
Is Waterproof	TRUE
Item Weight	450 g
Manufacturer	Aspor

Warranty and Support

For warranty information and customer support, please refer to the product packaging or visit the official Aspor website. Keep your purchase receipt as proof of purchase for warranty claims.
Manufacturer: Aspor
Date First Available: 3 July 2020

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08CB7X41B

More documents and user manuals: **https://manuals.plus/**