LANGGER V ZRS01YM

Langger V Gun Safe (Model ZRS01YM) Instruction Manual

Secure Storage for Firearms and Valuables

1. Important Safety Information

- Always store firearms unloaded with the safety engaged.
- Keep ammunition stored separately from firearms.
- Ensure the safe is securely mounted to prevent unauthorized removal or tipping.
- Keep backup keys and digital codes in a secure location away from the safe and out of reach of children.
- This safe is designed to deter theft and prevent unauthorized access. It is not fireproof or waterproof.

2. Product Overview

The Langger V Gun Safe (Model ZRS01YM) provides secure storage for rifles, shotguns, handguns, and accessories. It features an electronic keypad for quick access, a separate internal lock box, and a removable storage shelf for flexible organization.



Figure 2.1: Overview of the Langger V Gun Safe, illustrating its exterior and interior storage capabilities.



Figure 2.2: Detailed view highlighting the integrally welded construction and key dimensions of the safe, emphasizing its robust design.

3. Setup

3.1 Unboxing and Initial Inspection

Carefully remove the safe from its packaging. Inspect for any signs of damage. Retain packaging materials for future transport or returns.

3.2 Battery Installation

The electronic keypad requires batteries to operate. Locate the battery compartment on the inside of the safe door. Insert the required batteries, ensuring correct polarity. The safe will emit a beep to confirm successful battery installation.

Your browser does not support the video tag.

Video 3.1: This video demonstrates the process of installing batteries into the Langger V Gun Safe's electronic keypad.

3.3 Setting the Digital Code

1. With the safe door open, locate the red reset button on the inside of the door.
2. Press the red reset button. The keypad will beep, and the indicator light will flash.
3. Within 5 seconds, enter your desired 3-8 digit code on the keypad.
4. Press the '#' button to confirm. The safe will beep twice, indicating the new code is set.
5. Test the new code with the door open to ensure it functions correctly before closing the safe.

3.4 Mounting the Safe

The safe is equipped with pre-drilled holes in the back and bottom for secure mounting. Use the provided bolts and hardware to attach the safe to a floor or wall (or both) to prevent tipping and unauthorized removal. Ensure the mounting surface is structurally sound.



Figure 3.1: Illustration of the pre-drilled mounting holes located on the back and bottom of the safe, facilitating secure installation.

4. Operating Instructions

4.1 Opening with Digital Code

1. Enter your programmed 3-8 digit code on the keypad.
2. Press the '#' button. The safe will beep, and the green indicator light will illuminate.
3. Within 5 seconds, turn the handle clockwise to open the door.

4.2 Opening with Backup Key

In case of battery failure or forgotten code, the safe can be opened using the backup key.

1. Locate the keyhole, usually concealed behind the keypad or a small cover.
2. Insert the backup key and turn it clockwise.
3. Turn the handle clockwise to open the door.

4.3 Using the Internal Lock Box

The safe includes a separate internal lock box for additional security of smaller valuables. This lock box operates with its own set of keys, independent of the main safe's electronic lock.



Figure 4.1: Close-up view of the internal lock box, removable shelf, and handgun rest, demonstrating the versatile storage options.

4.4 Silent Mode and Alarm

The safe features an optional silent mode to disable keypad beeps. It also has an alarm function that activates if an incorrect code is entered three consecutive times, or if the safe experiences tampering.



Figure 4.2: Visual representation of the safe's silent mode and alarm system, designed to enhance security and user experience.

5. Maintenance

5.1 Battery Replacement

Replace batteries annually or when the low battery indicator appears. Use high-quality alkaline batteries for optimal performance. Always test the keypad after replacing batteries.

5.2 Cleaning

Clean the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish. Do not use water directly on the keypad or electronic components.

5.3 General Care

Regularly check the door hinges and locking bolts for any signs of wear or obstruction. Keep the interior dry to prevent rust or damage to stored items.

6. Troubleshooting

6.1 Keypad Not Responding

- Check battery levels and replace if necessary.
- Ensure batteries are inserted with correct polarity.
- If the keypad is completely unresponsive, use the backup key to open the safe.

6.2 Door Not Opening After Correct Code

- Ensure the handle is turned within 5 seconds of entering the correct code.
- Check for any obstructions preventing the door from opening.
- If the issue persists, use the backup key.

6.3 Alarm Sounds Unexpectedly

- The alarm may sound after three incorrect code entries or if the safe is tampered with.
- Enter the correct code to silence the alarm.

7. Specifications

Feature	Detail
Brand	LANGGER V
Model Number	ZRS01YM
Product Dimensions	12.01"D x 13.78"W x 57.09"H
Item Weight	88 Pounds

Material	Alloy Steel
Lock Type	Electronic Keypad, Key
Capacity	5-6 Rifles, 5 Handguns (with rest)
Special Features	Combination Lock, Silent Mode, Audible Alarm, Removable Shelf, Pistol Lock Box
Mounting Type	Floor Mount



Figure 7.1: External dimensions of the Langger V Gun Safe.

8. Warranty and Support

8.1 Warranty Information

Please refer to the warranty card included with your purchase for detailed information regarding coverage and terms. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or parts replacement, please contact Langger V customer support through the retailer where the product was purchased or visit the official Langger V website for contact details.

© 2026 LANGGER V. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question