Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lemorele LC06-USA

Lemorele MacBook HDMI to USB Adapter User Manual

Model: LC06-USA

1. Introduction

The Lemorele MacBook HDMI to USB Adapter is designed to expand your display capabilities, allowing you to connect your computer to an external monitor, projector, or TV via HDMI. This adapter supports Full HD 1080P resolution at 60Hz, enhancing productivity by enabling multiple displays. Its compact and durable aluminum alloy design ensures portability and efficient heat dissipation.



Figure 1: Lemorele MacBook HDMI to USB Adapter. This image shows the compact adapter with a USB-A connector on one end and an HDMI port on the other, featuring a sleek grey aluminum casing.

2. Key Features

- **Multiple Displays:** Expands screen space with 1920x1080 @60Hz Full HD displays.
- **System Compatibility:** Works with Windows 10/8.1/8/7 and macOS 10.15+ (driver installation required).
- **Compact and Portable:** Easily fits into bags, no external power adapter needed.
- **Durable Design:** Features an aluminum alloy case for enhanced durability and heat dissipation.
- **Wide Applications:** Suitable for multitasking in various professional and personal settings.



Figure 2: System Compatibility. This image illustrates the adapter's compatibility with Windows (versions 7, 8, 10) and macOS (10.12 and above) operating systems, indicated by respective logos.

3. Setup Instructions

3.1. Driver Installation

This adapter requires driver installation for both Windows (10/8.1/8/7) and macOS (10.15+). The necessary drivers are

typically installed automatically upon first connection or can be found on the manufacturer's support website. Ensure your operating system is up to date for optimal performance.

3.2. Connecting the Adapter

1. Connect the USB-A end of the Lemorele adapter to an available USB port on your laptop, desktop PC, or iMac.
2. Connect an HDMI cable (not included) from the HDMI port on the Lemorele adapter to the HDMI input on your external monitor, projector, or TV.
3. Power on your external display and select the correct HDMI input source.
4. Your computer should detect the new display. Follow on-screen prompts for driver installation if necessary.



Figure 3: Connection Diagram. This diagram illustrates the input (USB from Windows Laptop, MacBook, Desktop PC, iMac) and output (HDMI to Monitor, Projector, TV) connections for the adapter.

4. Operating Instructions

4.1. Display Modes

The adapter supports two primary display modes:

- **Mirror Mode (Duplicate Mode):** Duplicates your primary screen onto the external display. Both screens show the same content.
- **Extend Mode:** Extends your desktop across multiple screens, allowing you to have different applications open on each display for increased workspace.

You can configure these settings through your computer's display settings (e.g., System Preferences > Displays on macOS, Display Settings on Windows).



Figure 4: Display Modes. This image demonstrates both Mirror Mode (where the laptop screen is duplicated on an external monitor) and Extend Mode (where the external monitor acts as an additional, separate display for the laptop).

4.2. Resolution Adjustment

The adapter supports a maximum resolution of 1080p (1920x1080) at 60Hz. If you experience black borders or incorrect scaling in Extend Mode, adjust the resolution settings on your external monitor or within your computer's display settings.



Figure 5: Max Resolution Support. This image shows a laptop connected to a large external display via the adapter, highlighting its support for a maximum resolution of 1080p.

5. Maintenance

The Lemorele HDMI to USB Adapter requires minimal maintenance. To ensure longevity and optimal performance:

- Keep the adapter clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the adapter to extreme temperatures, humidity, or direct sunlight.
- Do not bend or twist the cable excessively, as this can damage internal wiring.
- Store the adapter in a safe place when not in use to prevent physical damage.

6. Troubleshooting

Problem	Possible Cause / Solution
No display on external monitor.	Ensure the adapter is securely connected to both your computer's USB port and the external display's HDMI port. Verify the external display is powered on and set to the correct HDMI input source. Check if the necessary drivers are installed. Reinstall if unsure. Try unplugging and replugging the USB side of the adapter.
Display shows black borders or incorrect scaling.	Adjust the display resolution settings on your computer to match the optimal resolution of your external monitor (1920x1080 for 1080p displays). Check the scaling options in your computer's display settings.
Adapter not recognized by computer.	Ensure your operating system is Windows 10/8.1/8/7 or macOS 10.15+. Linux, Unix, Vista, Chrome OS, and Firestick are not supported. Try connecting the adapter to a different USB port on your computer. Restart your computer and try again.
Intermittent connection or flickering display.	Ensure all cables are securely connected. Try a different HDMI cable. Ensure your computer's drivers are up to date.

7. Specifications

Feature	Detail
Brand	Lemorele
Model Number	LC06-USA
Connector Type	USB-A Input, HDMI Output
Max Resolution	1920x1080 @60Hz (1080p Full HD)
Compatible Devices	Laptop, Monitor, Projector, Television
Supported OS	Windows 10/8.1/8/7, macOS 10.15+
Incompatible OS	Linux, Unix, Vista, Chrome OS, Firestick
Item Weight	1.76 ounces
Package Dimensions	11.06 x 4.92 x 0.83 inches

Feature	Detail
Material	Aluminum Alloy Case

8. Warranty and Support

For information regarding product warranty and customer support, please refer to the purchase platform or contact Lemorele customer service directly. A 30-day return/replacement policy is typically offered for this product.
An official User Guide (PDF) is available for download: Download User Guide (PDF).

© 2023 Lemorele. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08CWRDMNM

More documents and user manuals: **https://manuals.plus/**