Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Onvian KS-WL09C

ONVIAN Remote Control for Wireless Anti-Theft Motorcycle Bike Vehicle Alarm User Manual

Model: KS-WL09C

Product Overview

The ONVIAN Remote Control is designed as a supplementary or replacement remote for compatible ONVIAN wireless anti-theft motorcycle and bicycle alarm systems (e.g., ASIN: B08BYH2LBP/B07MFBV7TW). This compact and durable remote provides convenient wireless operation for arming, disarming, selecting alarm tones, and locating your vehicle.



Image: Front view of the ONVIAN Remote Control, showcasing its sleek design and illuminated blue indicator light, indicating active status or signal transmission.

Key Features:

- **Compatibility:** Specifically designed for ONVIAN motorbike/bicycle anti-theft alarms (ASIN: B08BYH2LBP/B07MFBV7TW).
- **Wireless Operation:** Offers a remote control range of up to 20 meters (66 feet).
- **Power Source:** Operates on one CR2032 (3V) button battery (included).
- **Durability:** Features an IPX5 waterproof rating, suitable for various weather conditions.
- **Long Battery Life:** Designed for low power consumption, with an estimated battery life of over 1 year (assuming 5

times usage per day).

- **Compact Design:** Dimensions of approximately 2.56 x 1.38 x 0.59 inches.

Setup

Battery Installation:

The remote control comes with a CR2032 (3V) button battery pre-installed. If replacement is needed, locate the battery compartment on the back of the remote, open it, and insert a new CR2032 battery with the positive (+) side facing up. Ensure the compartment is securely closed after installation.

Pairing (Learning Code) with Alarm Unit:

To pair the remote control with your ONVIAN alarm unit, follow these steps:

1. **Prepare the Alarm Unit:** Remove the batteries from the main alarm unit.
2. **Reinstall Batteries:** After approximately 30 seconds, reinstall the batteries into the alarm unit.
3. **Enter Learning Mode:** Immediately after reinstalling the alarm unit batteries, long-press the **Vehicle Finder** key (bell icon) on the remote control.
4. **Confirmation:** The alarm host will produce a single "Bi" sound, indicating it has entered the code learning mode.
5. **Complete Pairing:** Press either the **ARM** key (lock icon) or the **DISARM** key (unlocked lock icon) on the remote control. The alarm unit will then produce two "Bi..Bi.." sounds, confirming successful pairing.

Your new remote control should now be ready for use with the alarm system.



Image: Physical dimensions of the ONVIAN Remote Control, showing its length (6.5 cm / 2.559 in), width (3.5 cm / 1.3779 in), and thickness (1.5 cm / 0.59 in).

Operating Instructions

The ONVIAN remote control features four primary functions, accessible via its dedicated buttons:



Image: An illustrative diagram detailing the functions of each button on the ONVIAN Remote Control, including Arm (locked padlock), Disarm (unlocked padlock), Tone Selected (lightning bolt), and Vehicle Finder (ringing bell).

Arm (Locked Padlock Icon): Press this button to activate the alarm system. The alarm will enter an armed state, ready to detect unauthorized movement or tampering.

Disarm (Unlocked Padlock Icon): Press this button to deactivate the alarm system. This will silence the alarm if it's currently sounding and return it to an unarmed state.

Tone Selected (Lightning Bolt Icon): This button allows you to cycle through different alarm tones or sensitivity levels, depending on the specific alarm unit's features. Refer to your main alarm unit's manual for detailed functionality.

Vehicle Finder (Ringing Bell Icon): Press this button to trigger a short sound from the alarm unit, helping you locate your vehicle in a parking lot or crowded area.

Waterproof Functionality:

The remote control is designed with an IPX5 waterproof rating. This means it is protected against low-pressure water jets from any direction. While it can withstand splashes and light rain, it is not intended for submersion in water. Ensure the battery compartment is always securely closed to maintain its water resistance.



Image: The ONVIAN Remote Control shown on a surface with water droplets, emphasizing its IPX5 waterproof capability, making it suitable for outdoor use.

Maintenance

Battery Replacement:

When the remote control's range decreases significantly or it becomes unresponsive, it may be time to replace the battery. The remote uses one CR2032 (3V) button battery. To replace:

1. Locate the battery compartment on the back of the remote.
2. Use a small screwdriver or coin to gently open the compartment cover.

3. Remove the old battery.
4. Insert a new CR2032 battery with the positive (+) side facing upwards.
5. Securely close the battery compartment cover.

Dispose of old batteries according to local regulations.

Cleaning:

To clean the remote control, wipe it with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or immerse the remote in water. Ensure no moisture enters the battery compartment or button crevices.

Storage:

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, consider removing the battery to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding to alarm unit.	• Battery is low or dead. • Remote is not paired with the alarm unit. • Out of range.	• Replace the CR2032 battery. • Perform the pairing (learning code) procedure as described in the "Setup" section. • Move closer to the alarm unit.
Short operating range.	• Low battery. • Environmental interference (e.g., thick walls, other wireless devices).	• Replace the CR2032 battery. • Try operating in an open area to confirm range. Minimize obstacles.
Buttons feel sticky or unresponsive.	• Dirt or debris lodged around buttons. • Internal component issue.	• Gently clean around the buttons with a soft, dry cloth. • If problem persists, contact customer support.

Specifications

Feature	Detail
Model Number	KS-WL09C
Item Weight	0.81 ounces (approx. 23 grams)
Package Dimensions	4 x 2 x 1 inches
Remote Dimensions	Approx. 2.56 x 1.38 x 0.59 inches (6.5 x 3.5 x 1.5 cm)
Batteries Required	1 x CR2032 (3V) button battery (included)
Wireless Remote	Yes
Maximum Range	20 Meters (66 Feet)
Waterproof Rating	IPX5
Manufacturer	OVUK0106

Feature	Detail
Date First Available	July 14, 2020

Warranty Information

The ONVIAN Remote Control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance.
Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty inquiries, please contact ONVIAN customer service. Refer to the product packaging or the official ONVIAN website for the most current contact information.
When contacting support, please have your product model number (KS-WL09C) and purchase details ready.

© 2024 Onvian. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08CXXB86B

More documents and user manuals: **https://manuals.plus/**