vhbw L336

vhbw Universal 3-in-1 Learning Remote Control L336 User Manual

1. Introduction

The vhbw Universal 3-in-1 Learning Remote Control L336 is designed to consolidate control of up to three different electronic devices into a single unit. This remote is compatible with various audio and video equipment, including televisions, DVD players, Blu-ray players, Hi-Fi systems, DVB, SAT, STB, AMP, VCD, VCR, and CBL devices. Its learning function allows it to replicate commands from your original remote controls, providing a convenient solution for managing your home entertainment system.

Important Note: This remote control is not suitable for operating air conditioning units.

2. Safety Information

- Always insert batteries with correct polarity (+/-). Incorrect insertion can cause damage to the remote control or batteries.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations. Do not dispose of batteries in fire.
- Keep the remote control and batteries out of reach of children.
- Avoid exposing the remote control to extreme temperatures, direct sunlight, or moisture.

3. Package Contents

- 1 x vhbw Universal 3-in-1 Learning Remote Control L336
- 1 x Instruction Manual (English)

4. Product Overview

The vhbw L336 remote control features a comprehensive button layout for various functions, including device selection, power, numerical input, channel and volume control, navigation, and special function keys. The ergonomic design ensures a comfortable grip.



Figure 4.1: Front view of the vhbw L336 Universal Remote Control, showing the full button layout.



Figure 4.2: Close-up of the top section, highlighting the device selection buttons (TV, SAT, DVD/HIFI) and the power button.



Figure 4.3: Back view of the vhbw L336 remote control, illustrating the battery compartment.

5. Setup

5.1 Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 4.3).
2. Slide open the battery compartment cover.
3. Insert two (2) AAA Micro R03 batteries (not included), ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

5.2 Learning Function (Programming the Remote)

The learning function allows the vhbw L336 remote to copy infrared (IR) signals from your original remote controls. This process must be performed for each function you wish to transfer.

1. **Select Device:** On the vhbw L336 remote, press one of the device selection buttons (e.g., **TV**, **SAT**, or **DVD/HIFI**) for the device you intend to program. The selected device button may illuminate or flash to indicate it is ready for programming.
2. **Position Remotes:** Place the vhbw L336 remote and your original remote control 2 to 3 cm apart, facing each other directly (IR emitters aligned).
3. **Initiate Learning on L336:** Press and hold the specific function button on the vhbw L336 remote that you wish to program (e.g., **POWER**, **VOL+**, **CH+**). The indicator light on the L336 remote may change to signal it is in learning mode.
4. **Transmit Signal from Original Remote:** While holding the button on the L336, press and hold the corresponding function button on your original remote control.
5. **Confirm Learning:** The indicator light on the vhbw L336 remote should flash or change state to confirm that the signal has been successfully learned. Release both buttons.
6. **Repeat for Additional Functions:** To program more functions for the same device, repeat steps 3 to 5 for each desired button.

7. **Exit Learning Mode:** Once all desired functions are programmed, the remote may automatically exit learning mode after a period of inactivity, or you may need to press a specific button (e.g., the device selection button again) to exit. Refer to the remote's indicator light for confirmation.

6. Operating the Remote Control

6.1 Device Selection

Before operating a device, select the corresponding mode on the vhbw L336 remote by pressing one of the device selection buttons (**TV**, **SAT**, or **DVD/HIFI**). The remote will then send commands for the selected device.

6.2 Basic Functions

- **Power:** Press the **POWER** button to turn the selected device on or off.
- **Volume:** Use the **VOL+** and **VOL-** buttons to adjust the volume.
- **Channel:** Use the **CH+** and **CH-** buttons to change channels.
- **Navigation:** Use the directional arrow buttons and the **OK** button for menu navigation.
- **Number Pad:** Use the numerical buttons (0-9) for direct channel input or other numerical selections.

The remote control has an operating range of over 8 meters, provided there is a clear line of sight between the remote's IR emitter and the device's IR receiver.

7. Maintenance

- **Cleaning:** Clean the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance diminishes or if the indicator light does not respond as expected. Follow the battery installation steps in Section 5.1.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace batteries with new AAA Micro R03 batteries.
Remote not controlling device.	Incorrect device selected. No line of sight. Function not programmed correctly.	Ensure the correct device button (TV, SAT, DVD/HIFI) is selected. Point the remote directly at the device. Re-program the specific function using the learning steps in Section 5.2.
Short operating range.	Weak batteries. Obstruction between remote and device.	Replace batteries. Ensure no objects are blocking the signal path.
Some buttons do not work.	Specific buttons not programmed or programmed incorrectly.	Re-program the non-working buttons using the learning steps in Section 5.2.

9. Specifications

Feature	Specification

Feature	Specification
Brand	vhbw
Model Name	L336
Color	Black
Material	Plastic
Dimensions (L x W x H)	18.5 x 4.7 x 2.7 cm
Weight	Approximately 67 g
Power Source	2 x AAA Micro R03 Alkaline Batteries (not included)
Max. Supported Devices	3
Connectivity Technology	Infrared (IR), Bluetooth (for compatible devices)
Max. Operating Range	8 meters
Special Features	Ergonomic design, Universal compatibility, Learning function

10. Warranty and Support

This vhbw product is a high-quality compatible accessory. For specific warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. As a compatible accessory, warranty terms may vary.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question