**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## ZdalaMit AH59-02546B

# User Manual

ZdalaMit AH59-02546B Replacement Remote Control

## Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your ZdalaMit AH59-02546B Replacement Remote Control. This remote is designed to be compatible with various Samsung Soundbar models, offering a seamless replacement experience without the need for complex programming.
**Compatible Samsung Soundbar Models:**

- HW-F550
- HW-F551
- HW-FM55C
- HW-F550/ZA
- HW-F551/ZA
- HW-FM55C/ZA
- HW-F550/ZC
- HW-F551/ZC
- HW-FM55C/ZC

## Package Contents

Upon opening the package, please ensure all items are present and in good condition.

- 1x AH59-02546B Replacement Remote Control

*Note: Batteries and additional manuals are not included in the package.*

## Setup

The AH59-02546B replacement remote control is designed for immediate use with compatible Samsung Soundbar models without requiring any programming or pairing procedures.

### Installing Batteries

1. Locate the battery compartment on the back of the remote control.

2. Slide open the battery compartment cover.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.




Image: Front view of the AH59-02546B replacement remote control, showing all buttons and the model number at the bottom. This image illustrates the overall design and button layout of the remote.




Image: Angled view of the AH59-02546B replacement remote control, highlighting its ergonomic shape and button placement from a side perspective. This view provides a better sense of the remote's depth and contours.

# Operating the Remote Control

Once batteries are installed, the remote is ready to operate your compatible Samsung Soundbar. Point the remote directly at the soundbar's infrared receiver.

## Key Functions

| Button | Function |
|---|---|
| **POWER** | Turns the soundbar power on or off. |
| **TV POWER** | Turns the connected TV power on or off. |
| **SOURCE** | Cycles through available input sources (e.g., D.IN, AUX, HDMI). |
| **AUTO POWER** | Enables or disables the Auto Power Link feature. |
| **SPEAKER** | Adjusts speaker settings or modes. |
| **TV SOURCE** | Switches the TV input source. |
| **SoundShare** | Connects to compatible Samsung TVs via SoundShare. |
| **REPEAT** | Repeats playback (functionality may vary by soundbar model). |
| **Anynet+** | Activates Samsung's Anynet+ (HDMI-CEC) function. |
| **VOL (+/-)** | Adjusts the soundbar's master volume. |
| **TV VOL (+/-)** | Adjusts the connected TV's volume. |
| **CH (Up/Down)** | Changes channels on the connected TV. |
| **AUDIO SYNC** | Adjusts audio delay to synchronize with video. |
| **TV MUTE** | Mutes or unmutes the connected TV's audio. |
| **TV INFO** | Displays information about the current TV program or input. |
| **TV PRE-CH** | Returns to the previously viewed TV channel. |
| **TV EXIT** | Exits the current menu or function on the TV. |
| **SOUND EFFECT** | Cycles through various sound effects or modes (e.g., Standard, Music, Cinema). |
| **SMART VOLUME** | Enables or disables Smart Volume to maintain consistent volume levels. |
| **S/W LEVEL (Left/Right)** | Adjusts the subwoofer volume level. |
| **MUTE** | Mutes or unmutes the soundbar's audio. |
| **3D SOUND PLUS** | Activates or deactivates 3D Sound Plus feature. |
| **DRC** | Enables or disables Dynamic Range Control. |
| **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop)** | Controls media playback functions. |

## Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the remote. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Exposure:** Keep the remote away from direct sunlight, heat sources, and excessive moisture.

## Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions:

| Problem | Possible Cause / Solution |
|---|---|
| Remote is not responding. | ◦ **Batteries:** Check if batteries are inserted correctly with correct polarity (+/-). Replace with new AAA alkaline batteries.<br>◦ **Line of Sight:** Ensure there are no obstructions between the remote and the soundbar's infrared receiver.<br>◦ **Distance:** Make sure you are within the effective range of the remote control. |
| Certain buttons do not work. | ◦ **Compatibility:** Verify that your Samsung Soundbar model is listed as compatible. Some buttons may have specific functions only available on certain soundbar models.<br>◦ **Soundbar State:** Ensure the soundbar is powered on and in an appropriate mode for the button's function. |
| Remote works intermittently. | ◦ **Low Batteries:** Replace batteries with new ones.<br>◦ **Interference:** Move away from strong light sources or other electronic devices that might cause infrared interference. |

## Specifications

| Feature | Detail |
|---|---|
| **Model Number** | AH59-02546B |
| **Brand** | ZdalaMit |
| **Power Supply** | 2 x 1.5V AAA Alkaline Batteries (not included) |
| **Dimensions (L x W x H)** | 4.8 x 1.2 x 0.5 inches |
| **Item Weight** | 1.41 ounces |

| Feature | Detail |
| --- | --- |
| **Special Feature** | Pre-Programmed (No programming or pairing needed) |
| **Compatible Devices** | Samsung Soundbar models: HW-F550, HW-F551, HW-FM55C, HW-F550/ZA, HW-F551/ZA, HW-FM55C/ZA, HW-F550/ZC, HW-F551/ZC, HW-FM55C/ZC |

## Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the seller's policy at the time of purchase. Typically, replacement parts may come with a limited warranty against manufacturing defects.
If you have any questions or require further assistance, please contact the seller or manufacturer directly. Contact information can usually be found on your purchase receipt or the product listing page.
For general inquiries or troubleshooting tips, you may also refer to the product's listing on Amazon:Amazon Product Page

© 2025 ZdalaMit. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B08DK7L67D**

More documents and user manuals: **https://manuals.plus/**