**ZdalaMit AKB36097101**

# ZdalaMit AKB36097101 Replacement Remote Control User Manual

For LG DVD Video Cassette Recorder Models: RC897T, RC700N, RC797T, RC397HM, RC397H, RC389H

## 1. Introduction and Overview

This manual provides instructions for the ZdalaMit AKB36097101 Replacement Remote Control. This remote is designed to function as a direct replacement for the original remote controls of specific LG DVD Video Cassette Recorder models. It requires no programming or pairing; simply insert batteries for immediate use.

**Compatible LG DVD Video Cassette Recorder Models:**

- RC897T
- RC700N
- RC797T
- RC397HM
- RC397H
- RC389H

## 2. Setup: Battery Installation

The remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.




DVD
VCR
EJECT
OPEN/CLOSE
INPUT
1
2
3
CH+
4
5
6
CH−
7
8
9
V+
DASH
INPUT
0
V−
PAUSE/STEP
PLAY
STOP
HOME
CH/TRK
DISC MENU/LIST
FAV.
CH
ENTER
FAV.
CH
DISPLAY
RETURN
CH/TRK
BACKWARD
FORWARD
SKIP
AUDIO
SUBTITLE
ZOOM
I.SKIP
REC
REC MODE
DUBBING
TITLE
PALY MODE
MARKER-SEARCH
THUMBNAIL
CHP.ADD
TV/VCR
TIMESHIFT
CLEAR



Image: Angled view of the ZdalaMit AKB36097101 remote control, showing its overall design and button layout.

## 3. Operating Instructions

Once batteries are installed, the remote control is ready for use with your compatible LG DVD Video Cassette Recorder. No additional programming or pairing is required.

### Basic Functions:

- **POWER (DVD/VCR):** Turns the DVD/VCR unit on or off.
- **TV POWER:** Turns the television on or off.
- **INPUT:** Selects the input source on the television.
- **EJECT OPEN/CLOSE:** Opens or closes the disc tray.
- **Number Buttons (0-9):** Used for direct track selection or time input.
- **CH+/CH- (Channel Up/Down):** Changes channels on the TV or VCR tuner.
- **V+/V- (Volume Up/Down):** Adjusts the volume.
- **PLAY (►):** Starts playback of a DVD or VCR tape.
- **PAUSE/STEP ( ▮▮):** Pauses playback or advances frame by frame.
- **STOP (■):** Stops playback.
- **REWIND (◄◄)/FAST FORWARD (►►):** Rewinds or fast forwards playback.
- **REC (●):** Initiates recording (VCR function).
- **HOME:** Accesses the main menu or home screen.
- **ENTER:** Confirms selections in menus.
- **Directional Arrows (▲◄▼►):** Navigates through menus and options.
- **RETURN:** Goes back to the previous menu or screen.




Image: Front view of the ZdalaMit AKB36097101 remote control, highlighting the button layout and labels for various functions.

## 4. Maintenance

### Battery Replacement:

Replace batteries when the remote control becomes unresponsive or its range decreases significantly. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

### Cleaning:

To clean the remote control, wipe it with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the remote's surface or internal components.

## 5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the LG DVD Video Cassette Recorder.

- Confirm you are within the maximum operating range (approximately 33 feet).

- **Specific buttons not working:**
  - This may indicate low battery power. Replace batteries.
  - Ensure the remote is pointed directly at the infrared receiver on your LG unit.

## 6. Specifications

| | |
|---|---|
| **Model Number** | AKB36097101 |
| **Brand** | ZdalaMit |
| **Compatible Devices** | LG DVD Video Cassette Recorders (RC897T, RC700N, RC797T, RC397HM, RC397H, RC389H) |
| **Connectivity Technology** | Infrared |
| **Power Supply** | 2 x 1.5V AAA Alkaline Batteries |
| **Maximum Range** | Approximately 33 feet (10 meters) |
| **Button Quantity** | 18 |
| **Item Dimensions (L x W x H)** | 7.54" x 1.99" x 0.55" (19.15 cm x 5.05 cm x 1.4 cm) |
| **Item Weight** | 40 Grams |

## 7. Warranty Information

This ZdalaMit AKB36097101 Replacement Remote Control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.

## 8. Support

If you encounter any issues or have questions regarding your ZdalaMit AKB36097101 Replacement Remote Control that are not addressed in this manual, please contact the seller or manufacturer for assistance. Provide your product model number (AKB36097101) and a detailed description of your query for faster support.