Elechomes 5-in-1 Cordless Handheld Vacuum Cleaner B08DKHG2Z1

Elechomes 5-in-1 Cordless Handheld and Stick Vacuum Cleaner

Model: B08DKHG2Z1

1. Introduction

Thank you for choosing the Elechomes 5-in-1 Cordless Handheld and Stick Vacuum Cleaner. This versatile cleaning tool is designed for efficient removal of dust, debris, and pet hair from various surfaces in your home and car. Its powerful suction, fast charging technology, and multiple attachments make it suitable for diverse cleaning tasks.

Please read this manual thoroughly before operating the appliance to ensure safe use, optimal performance, and extended product life. Keep this manual for future reference.

2. Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.

- Do not pick up toxic material, such as chlorine bleach, ammonia, or drain cleaner.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not charge the unit outdoors.
- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- When charging, please turn off the handheld vacuum cleaner.
- Do not use the portable vacuum cleaner during the charging process to protect the battery life.

3. Package Contents

Carefully unpack your Elechomes vacuum cleaner and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- 1 x Elechomes Handheld Vacuum Unit
- 1 x HEPA Filter (pre-installed)
- 1 x Slit Nozzle (Crevice Tool)
- 1 x Rubber Cylinder Nozzle (for liquids)
- 1 x Brush Nozzle (Dust Brush)
- 1 x Hose
- 1 x Extension Tube
- 1 x Floor Brush Head
- 1 x Charging Cable / Adapter



Image: All included accessories for the Elechomes Handheld Vacuum Cleaner, including various nozzles, hoses, and the main unit.

4. Setup and Assembly

4.1 Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the charging cable to the vacuum's charging port and plug the adapter into a power outlet. The battery indicator lights will show the charging status. A full charge typically takes 3-4 hours. Do not operate the vacuum while it is charging.



Image: The Elechomes handheld vacuum connected to its charging cable and adapter, indicating its fast charging technology and 30-minute runtime.

4.2 Attaching Accessories

The vacuum comes with various attachments for different cleaning needs. To attach an accessory, align it with the suction nozzle of the main unit and push firmly until it clicks into place. To remove, pull the accessory away from the main unit.

- **Slit Nozzle (Crevice Tool):** Ideal for narrow gaps, corners, and hard-to-reach areas.
- **Rubber Cylinder Nozzle:** Designed for vacuuming small amounts of liquid spills.
- **Brush Nozzle (Dust Brush):** Suitable for cleaning delicate surfaces, upholstery, and keyboards.
- **Hose & Extension Tube:** Connect these to extend reach, allowing the vacuum to be used as a stick vacuum or for cleaning high areas. The floor brush head can be attached to the extension tube for floor cleaning.



Image: Close-up view of the various attachments: Rubber Brush for liquids, Crevice Brush for tight spaces, Dust Brush for surfaces, and an Extension Hose for extended reach, shown in use for car interior cleaning.

5. Operating Instructions

5.1 Powering On/Off

Press the power button located on the top of the vacuum to turn it on. Press it again to turn the vacuum off.

5.2 General Cleaning

Select the appropriate attachment for your cleaning task. For general dry debris, use the brush nozzle or slit nozzle. For larger areas or floors, assemble the extension tube and floor brush head. For liquid spills, use the rubber cylinder nozzle.



Image: The Elechomes handheld vacuum demonstrating its wet and dry cleaning capabilities, showing it picking up dry crumbs and a liquid spill.



Image: The Elechomes handheld vacuum with 7000Pa suction power, shown cleaning up various messes including spilled liquid, pet hair, and food crumbs from different surfaces.

5.3 Noise Level

The vacuum operates at a low noise level, typically below 70dB, minimizing disturbance during use.



Image: The Elechomes handheld vacuum operating with low noise (below 70dB) near a sleeping dog, highlighting its quiet operation.

6. Maintenance

6.1 Emptying the Dust Cup

To maintain optimal suction, empty the dust cup regularly, especially after each significant use. Hold the dust cup steadily and detach it from the main unit. Dispose of the collected debris. Reattach the dust cup securely.

6.2 Cleaning the HEPA Filter

The HEPA filter is washable and designed for extended use. It is not necessary to clean the filter after every use, but regular cleaning is recommended to prevent clogging and maintain strong suction. To clean, remove the filter from the dust cup. Rinse it under running water until clean. Ensure the filter is completely dry before reinserting it into the vacuum. Do not use the vacuum with a wet filter.



Image: A diagram illustrating the enhanced upgrade HEPA filter, showing its components and the process of washing it to maintain strong suction and prevent clogging.

7. Troubleshooting

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is depleted.	Charge the vacuum fully (3-4 hours).
Reduced suction power	Dust cup is full. Filter is clogged. Nozzle/hose is blocked.	Empty the dust cup. Clean the HEPA filter. Check and clear any blockages in the nozzles or hose.

Problem	Possible Cause	Solution
Short operating time	Battery not fully charged. Battery life degraded over time.	Ensure the vacuum is fully charged. If battery life significantly decreases, contact customer support.
Vacuum gets hot during use	Normal operation for extended use. Blocked airflow.	It is normal for the motor to heat up during prolonged use. Ensure dust cup is not full and filters are clean to prevent overheating due to restricted airflow.

8. Specifications

- **Power:** 100W
- **Battery:** 4 x 2500mAh rechargeable Lithium-Ion battery
- **Input:** 100-240V 50/60Hz
- **Output:** 18V 500mA
- **Working Time:** 30-40 minutes (fully charged)
- **Charging Time:** 3-4 hours
- **Suction Power:** 7000Pa (7Kpa)
- **Noise Level:** < 70dB
- **Dust Cup Capacity:** 0.5 Liters
- **Filter Type:** Washable HEPA
- **Form Factor:** Handheld, convertible to Stick
- **Surface Recommendation:** Carpet, Hard Floor, Ceramic Tile, Sofa, Car

9. Warranty and Support

Elechomes products come with a standard manufacturer's warranty. For specific warranty details, registration, or technical support, please refer to the warranty card included with your purchase or visit the official Elechomes website. If you encounter any issues not covered in this manual, please contact Elechomes customer service for assistance.

© 2026 Elechomes. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question