Crock-Pot CSC066X

Crock-Pot TimeSelect Programmable Slow Cooker

Model: CSC066X

User Manual

Introduction

Thank you for purchasing the Crock-Pot TimeSelect Programmable Slow Cooker. This appliance is designed to simplify meal preparation, allowing you to enjoy delicious, home-cooked meals with minimal effort. Its innovative TimeSelect technology offers both scheduled and manual cooking options, adapting to your busy lifestyle. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using this product.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the base unit, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to 'OFF', then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Avoid sudden temperature changes, such as adding refrigerated foods into a heated pot.
- The ceramic stoneware is designed for use only in this appliance. It must not be used on a stovetop or in an oven.
- Always ensure the lid is properly seated during cooking.

Components

- Glass Lid with Handle
- Removable Ceramic Stoneware Pot (5.6L capacity)
- Heating Base Unit with Digital Control Panel
- Power Cord



Front view of the Crock-Pot TimeSelect Programmable Slow Cooker, showing the stainless steel exterior, glass lid, and digital control panel.



Detailed view of the digital control panel, highlighting the 'Schedule Meal', 'Food', 'Amount', 'Clock Set', 'Hour', 'Minute', 'Manual', 'Temp', and 'Cancel Timer' buttons, along with the digital display showing 'Earliest End Time' and current time.

Before First Use

1. Remove all packaging materials and labels from the appliance.
2. Wash the ceramic stoneware pot and glass lid in warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the heating base unit with a soft, damp cloth. Do not immerse the base unit in water.
4. Ensure all parts are completely dry before assembly and use.

Setup

1. Place the heating base unit on a dry, level, heat-resistant surface.
2. Carefully place the ceramic stoneware pot into the heating base.
3. Add your ingredients to the stoneware pot.
4. Place the glass lid on top of the stoneware pot.
5. Plug the power cord into a standard electrical outlet. The display will illuminate.

Operating Instructions

The Crock-Pot TimeSelect Slow Cooker offers two primary cooking modes:**Schedule Meal** and **Manual**.

1. Schedule Meal Function

This function allows you to program the slow cooker to have your meal ready at a specific time, automatically adjusting the cooking process.

1. Press the **SCHEDULE MEAL** button.
2. Press the **FOOD** button to select the type of food: Meat, Poultry, Soup/Stew, or Vegetables.
3. Press the **AMOUNT** button to indicate the quantity of food: +2 LBS (for larger quantities) or 0-2 LBS (for smaller quantities).
4. Use the **HOUR** and **MINUTE** buttons to set the desired end time for your meal.
5. Press the **START/PAUSE** button to begin cooking. The display will show the 'Earliest End Time' and count down.

2. Manual Function

The Manual function provides traditional slow cooking control with High or Low temperature settings and a programmable timer.

1. Press the **MANUAL** button.
2. Press the **TEMP** button to select either HIGH or LOW cooking temperature.
3. Use the **HOUR** and **MINUTE** buttons to set the desired cooking duration.
4. Press the **START/PAUSE** button to begin cooking. The display will count down the remaining cooking time.

3. Keep Warm Setting

Once the programmed cooking cycle (either Schedule Meal or Manual) is complete, the slow cooker will automatically switch to the **KEEP WARM** setting. This maintains the food at a safe serving temperature without overcooking. The 'KEEP WARM' indicator will illuminate, and a timer will begin counting up to indicate how long the food has been kept warm. This setting typically lasts for up to 4 hours.

4. Clock Set

To set the current time on the display:

1. Press the **CLOCK SET** button.
2. Use the **HOUR** and **MINUTE** buttons to adjust the current time.
3. Press **CLOCK SET** again to confirm.

5. Cancel Timer

To stop any active cooking program, press the **CANCEL TIMER** button. This will return the unit to standby mode.

Care and Cleaning

Proper care and cleaning will ensure the longevity and performance of your slow cooker.

1. Always unplug the slow cooker and allow it to cool completely before cleaning.
2. The ceramic stoneware pot and glass lid are dishwasher-safe. Alternatively, they can be washed by hand with warm, soapy water. Avoid abrasive cleaners or scouring pads that may scratch surfaces.
3. The heating base unit should be wiped clean with a soft, damp cloth. Never immerse the heating base in water or any other liquid.
4. Do not use harsh chemicals or abrasive materials on the control panel.
5. For stubborn food residue on the stoneware pot, fill it with warm, soapy water and let it soak for a few hours before cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the unit is securely plugged into a working outlet. Check circuit breaker.
Food is not cooking properly.	Lid not sealed; incorrect temperature/time setting; too much liquid.	Ensure lid is properly seated. Verify selected temperature and time. Reduce liquid if necessary.
Display is blank or flickering.	Power interruption; internal malfunction.	Unplug the unit for 5 minutes, then plug back in. If problem persists, contact customer support.
Food is burning on the bottom.	Too high temperature; insufficient liquid; food stuck to bottom.	Use a lower temperature setting. Ensure adequate liquid. Stir occasionally if recipe allows.

Specifications

- **Model:** CSC066X
- **Brand:** Crock-Pot
- **Capacity:** 5.6 Liters
- **Power:** 240 Watts
- **Voltage:** 220V
- **Material:** Stainless Steel, Ceramic
- **Color:** Stainless Steel
- **Dimensions (L x W x H):** 28.5 x 41 x 25 cm
- **Weight:** 6.2 Kilograms
- **Dishwasher Safe Parts:** Ceramic Stoneware Pot, Glass Lid
- **Country of Origin:** China

Warranty and Support

This Crock-Pot appliance is covered by a limited warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Crock-Pot website. If you experience any issues or require assistance, please contact Crock-Pot customer support. Keep your proof of purchase for warranty claims.
For further assistance, please visit the official Crock-Pot website.

© 2025 Crock-Pot. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question