Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool C00323365

Whirlpool Chest Freezer Wire Basket Instruction Manual

Model: C00323365

1. Introduction

This instruction manual provides essential information for the proper use and maintenance of your Whirlpool Chest Freezer Wire Basket, model C00323365. This accessory is designed to enhance the organization and accessibility of items within compatible Whirlpool chest freezers. Please read this manual thoroughly before use.

2. Product Overview

The Whirlpool Chest Freezer Wire Basket is an original manufacturer replacement part designed for specific chest freezer models. It provides a convenient storage solution for smaller or frequently accessed items, preventing them from being buried at the bottom of the freezer.

Key Features:

- Original manufacturer part (C00323365)
- Durable wire construction
- Designed for optimal fit in compatible Whirlpool chest freezers

Figure 1: Angled view of the Whirlpool Chest Freezer Wire Basket.

Dimensions:

- Length (top edge): 52 cm
- Width: 13.5 cm
- Height: 20 cm

3. Compatible Models

This wire basket (Part Number C00323365) is compatible with a range of Whirlpool chest freezer models. Please verify your freezer's model number against the list below to ensure compatibility:

- AFG044/G, AFG045/G, AFG053/G, AFG054/G
- AFG060AP, AFG060E-AP, AFG070AP, AFG070E-AP
- AFG070NFAP, AFG070NFE-AP, AFG072/01/G, AFG073/1/G
- G074/1/G, AFG075/1/G, AFG090AP, AFG090E-AP
- AFG514/G, AFG5162-C/H, AFG5163-C/H, AFG5166-C/H
- AFG5167-C, AFG519/G, AFG519/H, AFG519-C/H
- AFG52220/G, AFG520-1/G, AFG521/H, AFG5220-C/H
- AFG5222-C/H, AFG5226-C/H, AFG5227-C, AFG5227-L
- AFG522-C/H, AFG5242-C/H, AFG5242E, AFG5242-L
- AFG5246-L, AFG5246-C, AFG524-C/H, AFG525/G

4. Setup

The wire basket is designed for easy installation. Follow these steps to set up your basket:

1. Ensure your chest freezer is unplugged or powered off before reaching inside.

2. Carefully lower the wire basket into the designated slot or hanging rails within your chest freezer. The basket's handles are designed to rest on the freezer's interior rim or support ledges.
3. Confirm that the basket is stable and securely seated before placing items inside.

Figure 2: Top-down view of the wire basket, showing its rectangular shape and grid pattern.

5. Operating

Once installed, the wire basket can be used to organize various frozen food items. It is particularly useful for:

- Storing frequently accessed items for easy retrieval.
- Separating smaller items from larger, bulkier frozen goods.
- Organizing different categories of food to improve freezer efficiency.

To access items below the basket, simply lift the basket by its handles and set it aside temporarily. Always ensure the basket is properly seated before closing the freezer lid.

Figure 3: Side view of the wire basket, illustrating its depth and handle design.

6. Maintenance

Regular cleaning of the wire basket will help maintain hygiene and prolong its lifespan.

1. Remove the basket from the freezer.
2. Wash the basket with warm water and a mild dish soap. Avoid abrasive cleaners or scouring pads that could damage the finish.
3. Rinse thoroughly with clean water.
4. Dry the basket completely before returning it to the freezer to prevent ice buildup or rust.

7. Troubleshooting

If you encounter any issues with your wire basket, consider the following:

- **Basket does not fit:** Double-check the model number of your chest freezer against the list of compatible models in Section 3. Ensure the basket is oriented correctly.
- **Basket is unstable:** Ensure the basket's handles are properly seated on the freezer's internal support ledges or rim. Remove any obstructions that might prevent it from sitting level.

8. Specifications

Attribute	Detail
Brand	Whirlpool
Model Number	C00323365
Product Dimensions (L x W x H)	52 cm x 13.5 cm x 20 cm
Manufacturer	Whirlpool
ASIN	B08DYD3911

9. Warranty and Support

This Whirlpool original manufacturer part is typically covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, please refer to the documentation provided with your Whirlpool chest freezer or contact Whirlpool customer support directly.

For further assistance or to inquire about replacement parts, please visit the official Whirlpool website or contact their customer service department.

© 2023 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08DYD3911

More documents and user manuals: **https://manuals.plus/**