Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Domo DO531FR

DOMO DO531FR Delifryer XXL 5L User Manual

Model: DO531FR

1. Important Safety Instructions

Read all instructions carefully before using the appliance.

- Do not immerse the cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.
- Ensure the frying basket and grill plate are properly inserted before operation.
- Do not block any ventilation openings.
- The appliance operates at high temperatures; avoid touching hot surfaces. Use handles or knobs.

Electrical Safety

- Connect the appliance only to an earthed wall socket.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage.
- Do not use an extension cord unless it is fully extended and rated for the appliance's power.

General Precautions

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

2. Product Overview

The DOMO DO531FR Delifryer XXL is a versatile hot air fryer designed for healthier cooking with up to 80% less fat compared to traditional frying methods. Its rapid air circulation technology ensures quick and energy-efficient cooking. This appliance is suitable for preparing a variety of foods, including fries, croquettes, snacks, chicken, meat, quiches, and cakes.



Image: Front view of the DOMO DO531FR Delifryer XXL, showcasing its sleek black design and control panel.

Key Features:

- Hot air frying: Up to 80% less fat than conventional frying.
- Rapid air circulation for fast and energy-efficient cooking.
- Capacity: 5 liters (1.4 kg of fries).
- Adjustable temperature: 80°C to 200°C.
- Timer: Up to 30 minutes.

- Frying basket with non-stick grill plate.
- Power and ready indicator lights.
- Easy to use mechanical controls.
- Cool touch housing.
- Overheat protection.



Image: The DOMO DO531FR Delifryer XXL positioned next to a plate of cooked fries and a piece of meat, demonstrating its cooking capabilities.

Components:

- Main Unit (Cool Touch Housing)
- Control Panel (Temperature and Timer Dials)
- Frying Basket
- Non-stick Grill Plate
- Power Cord



Image: Side view of the DOMO DO531FR Delifryer XXL, showing the handle of the frying basket.



Image: Close-up of the DOMO brand logo on the front of the Delifryer XXL.

3. Setup and First Use

Unpacking

1. Remove all packaging materials from the appliance.
2. Check that all parts are present and in good condition.
3. Dispose of packaging materials responsibly.

Before First Use

1. Wipe the main unit with a damp cloth.
2. Clean the frying basket and grill plate thoroughly with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher safe.
3. Dry all parts completely before assembly.
4. Place the appliance on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm of free space on the back, sides, and above the appliance.
5. Do not place the appliance on a surface that is not heat-resistant.

Initial Operation (Burn-in)

It is recommended to run the air fryer empty for about 10-15 minutes during its first use to eliminate any manufacturing odors.

1. Insert the grill plate into the frying basket, then slide the basket into the main unit.
2. Plug the power cord into an earthed wall socket.
3. Set the temperature to 200°C and the timer to 15 minutes.
4. A slight odor or smoke may be present during this initial use; this is normal and will dissipate.
5. After the timer finishes, unplug the appliance and let it cool down completely.

4. Operating Instructions

General Operation

1. Place the appliance on a stable, level, heat-resistant surface.
2. Pull out the frying basket from the main unit.
3. Place the grill plate inside the frying basket.
4. Place the ingredients into the frying basket. Do not exceed the MAX fill line.
5. Slide the frying basket back into the main unit until it clicks into place.
6. Plug the power cord into an earthed wall socket. The power indicator light will illuminate.
7. Turn the temperature dial to your desired temperature (80°C to 200°C).
8. Turn the timer dial to your desired cooking time (up to 30 minutes). The appliance will start heating, and the ready indicator light will illuminate.
9. During cooking, the ready indicator light may cycle on and off as the appliance maintains the set temperature.
10. Some ingredients may require shaking halfway through the cooking time. To do this, pull out the basket by the handle, shake it gently, and then slide it back into the appliance. The appliance will resume cooking.
11. When the timer reaches zero, a bell will ring, and the appliance will automatically shut off.
12. Carefully pull out the frying basket. Use heat-resistant tongs to remove the cooked food.
13. Unplug the appliance from the wall socket and allow it to cool down before cleaning.


200°C
20-25 min
180°C
8-15 min
180°C
15-20 min
180°C
12-18 min
180°C
25-30 min
180°C
12-18 min
TEMP
°C
200 180 160 140 120 100 80
TIME
min
30 25 20 15 10 5 00

Image: Top-down view of the DOMO Delifryer XXL with the basket pulled out, showing a batch of fries ready for cooking or just cooked.

Cooking Guide (Approximate Times)

The following table provides approximate cooking times and temperatures for common foods. These are guidelines; actual times may vary based on food quantity, size, and desired crispness.

Food Item	Temperature	Time	Notes
Frozen Fries (1.4 kg)	180-200°C	20-30 min	Shake halfway
Fresh Fries	180°C	15-25 min	Shake halfway, add a tablespoon of oil if desired
Chicken Drumsticks	180°C	20-25 min	Flip halfway
Steak	180°C	8-12 min	Flip halfway, adjust for desired doneness
Fish Fillets	180°C	12-18 min	
Vegetables (e.g., broccoli, bell peppers)	160-180°C	10-15 min	Toss with a little oil
Muffins/Cakes	160°C	15-20 min	Use appropriate bakeware





Image: Top-down view of the DOMO Delifryer XXL with the basket pulled out, containing cooked fish fillets and potato wedges.


200°C
20-25 min
180°C
8-15 min
180°C
15-20 min
180°C
12-18 min
180°C
25-30 min
180°C
12-18 min
TEMP
°C
200 180 160 140 120 100 80
TIME
min
00 10 20 30 40 50

Image: Top-down view of the DOMO Delifryer XXL with the basket pulled out, showing two cooked corn on the cobs.


200°C
20-25min
180°C
8-15min
180°C
15-20min
180°C
12-18min
180°C
25-30min
180°C
12-18min
TEMP
°C
200 180 160 140 120 100 80
TIME
min
30 25 20 15 10 5 00

Image: Top-down view of the DOMO Delifryer XXL with the basket pulled out, containing a cooked piece of meat.


200°C
20-25min
180°C
8-15min
180°C
15-20min
180°C
12-18min
180°C
25-30min
180°C
12-18min
TEMP
°C
200 180 160 140 120 100 80
TIME
min
00 05 10 15 20 25 30

Image: Top-down view of the DOMO Delifryer XXL with the basket pulled out, showing two cooked fish fillets.

5. Cleaning and Maintenance

Clean the appliance after every use.
The frying basket and grill plate have a non-stick coating, which makes cleaning easy. Do not use metal utensils or abrasive cleaning materials, as this may damage the non-stick surface.

Cleaning Steps

1. Unplug the appliance from the wall socket and allow it to cool down completely before cleaning.
2. Remove the frying basket and grill plate.
3. Clean the frying basket and grill plate with hot water, dish soap, and a non-abrasive sponge. They are also dishwasher safe.
4. Wipe the exterior of the appliance with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. Clean the heating element inside the appliance with a cleaning brush to remove any food residue.
6. Ensure all parts are completely dry before storing or reassembling.

Storage

Store the appliance in a cool, dry place when not in use. Ensure it is clean and dry before storage.

6. Troubleshooting

Problem	Possible Cause	Solution
The appliance does not work.	The appliance is not plugged in. The timer is not set. The frying basket is not inserted correctly.	Plug the main plug into an earthed wall socket. Turn the timer dial to the desired cooking time. Push the frying basket into the appliance until it clicks into place.
Food is not cooked evenly.	Too much food in the basket. Food not shaken/flipped.	Reduce the amount of food per batch. Shake or flip the food halfway through the cooking time.
White smoke comes out of the appliance.	Fat residues from previous use. High fat content ingredients.	Clean the basket and grill plate thoroughly after each use. For high-fat foods, excess fat may drip into the pan. This is normal.
Fresh fries are not crispy.	Not enough oil used. Potatoes not properly prepared.	Add a tablespoon of oil to the fries before frying. Soak potato sticks in water for 30 minutes, then dry them thoroughly before adding oil.

7. Specifications

Specification	Value
Brand	Domo
Model Number	DO531FR
Color	Black
Dimensions (L x W x H)	35.2 x 35.5 x 36.6 cm
Capacity	5 Liters
Power	2000 Watts
Voltage	230 Volts
Material	Plastic
Weight	4.88 Kilograms
Special Feature	Programmable (Timer)

8. Warranty and Support

Information regarding specific warranty terms and conditions for the DOMO DO531FR Delifryer XXL is not available in this manual. Please refer to the warranty card included with your product or contact DOMO customer support for details. For technical support, spare parts, or service inquiries, please contact your local DOMO distributor or visit the official DOMO website.
Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 DOMO. All rights reserved.
This manual is subject to change without notice.
For the latest information, please visit www.domo-elektro.be.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08F6PWS5Q

More documents and user manuals: **https://manuals.plus/**