Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ciciglow 8G

CiCiglow 7-inch TFT LCD Portable E-Book Reader User Manual

Model: 8G

1. Introduction

Thank you for choosing the CiCiglow 7-inch TFT LCD Portable E-Book Reader. This device is designed to provide a comfortable and versatile reading experience, supporting various e-book formats, music, video, and photo playback. Its compact design and long battery life make it ideal for use at school, during travel, or outdoors.
This manual provides detailed instructions on how to set up, operate, and maintain your e-book reader. Please read it thoroughly before using the device to ensure optimal performance and longevity.



Image: The CiCiglow E-Book Reader showing its user interface with various menu options.

2. Safety Information

Please observe the following safety guidelines to prevent damage to your device or personal injury:

- **Water Resistance:** The device features a waterproof design for effective splash protection. **It cannot be submerged in water.** Avoid exposing the device to heavy rain, direct water jets, or submersion.
- **Temperature:** Do not expose the device to extreme temperatures (hot or cold).
- **Cleaning:** Use a soft, dry cloth for cleaning. Avoid harsh chemicals or abrasive materials.
- **Battery:** Do not attempt to replace the battery yourself. Refer to qualified service personnel for battery-related issues.
- **Disassembly:** Do not attempt to disassemble or modify the device. This will void the warranty and may cause damage.



Image: The e-reader demonstrating its splash-resistant design.

3. Package Contents

Verify that all items are present in the package:

- CiCiglow 7-inch TFT LCD Portable E-Book Reader
- USB Charging Cable
- Earphones
- User Manual (this document)



Image: The e-reader along with its USB cable and earphones.

4. Product Overview

Familiarize yourself with the device's components and controls.



Image: Front view of the e-reader.

4.1. Controls and Ports

- **Display:** 7-inch TFT LCD screen.
- **Navigation Buttons:** Used to navigate menus and turn pages.
- **Power Button:** Turns the device on/off.
- **USB Port:** For charging and data transfer.
- **TF Card Slot:** For expandable storage.
- **Headphone Jack:** For audio output.



Image: Side profile of the e-reader, illustrating its lightweight design.

5. Setup

5.1. Charging the Device

Before first use, fully charge the e-book reader. Connect the included USB cable to the device's USB port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status.

5.2. Inserting a TF Card

To expand storage, insert a TF (microSD) card into the designated slot. Ensure the card is inserted correctly until it clicks into place. The device supports TF cards for additional storage of books, music, videos, and photos.

5.3. Transferring Files

Connect the e-book reader to your computer using the USB cable. The device will appear as a removable disk. You can then drag and drop your e-book files (e.g., EPUB, PDF, TXT, FB2), music (e.g., MP3), videos (e.g., FLV, MKV, MOV, RM, RMVB, VOB), and photos (e.g., BMP, GIF, PNG) into the appropriate folders on the device or TF card.

6. Operating Instructions

6.1. Power On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the options. A short press will put the device into sleep mode.

6.2. Navigation

Use the physical navigation buttons on the side of the device to move through menus, select options, and turn pages while reading. The central button typically acts as a confirmation or 'OK' button.



Image: Detail of the flip-book and navigation buttons.

6.3. Reading E-Books

1. From the main menu, select the 'Books' or 'My Library' option.
2. Browse your stored books and select one to open.
3. Use the navigation buttons to turn pages.
4. **Adjusting Reading Settings:** While reading, access the menu (usually by pressing a central or dedicated menu button) to adjust font size, brightness, and text color to reduce eye fatigue.
5. **Bookmarks:** The device supports adding bookmarks. You can skip to specific pages and easily resume reading from your last bookmarked position.



Image: The e-reader's main menu, showing various functions.

6.4. Multimedia Playback

The e-book reader supports playing music, videos, and viewing photos.

- **Music:** Select the 'Music' option from the main menu. Browse your music files and select one to play. Connect earphones to the headphone jack for private listening.
- **Video:** Select the 'Video' option. Browse and play your video files.
- **Photos:** Select the 'Photos' option. Browse and view your image files.

7. Maintenance

7.1. Cleaning

Wipe the screen and body of the device with a soft, lint-free cloth. Do not use liquid cleaners, aerosols, or solvents.

7.2. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

7.3. Storage

Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

8. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; device frozen.	Charge the device for at least 30 minutes. If still unresponsive, perform a hard reset (refer to device specifications for reset method, usually holding power button for 10-15 seconds).
Cannot transfer files.	USB connection issue; incorrect file format.	Ensure the USB cable is securely connected. Try a different USB port or cable. Verify that the file formats are supported (BMP, EPUB, FB2, FLV, GIF, MKV, MOV, PDF, PNG, RM, RMVB, TXT, VOB).
Screen is unresponsive or flickering.	Software glitch; physical damage.	Restart the device. If the issue persists, contact customer support.
TF card not recognized.	Card not inserted correctly; incompatible card.	Reinsert the TF card firmly. Ensure the card is formatted correctly (FAT32 or exFAT). Try a different TF card.

9. Specifications

- **Display:** 7-inch TFT LCD
- **Resolution:** 800x480
- **Processor:** High-speed built-in ARM9 core
- **Internal Storage:** 16 GB
- **Expandable Storage:** Supports TF Card
- **Battery:** 2100mAh (provides several weeks of reading on a single charge)
- **Connectivity:** USB
- **Supported E-book Formats:** EPUB, PDF, TXT, FB2
- **Supported Multimedia Formats:**
  - **Video:** FLV, MKV, MOV, RM, RMVB, VOB
  - **Audio:** (Not explicitly listed, but implied by 'music' feature. Common formats like MP3 are usually supported.)
  - **Image:** BMP, GIF, PNG
- **Human Interface Input:** Buttons
- **Bluetooth Support:** No
- **Water Resistance:** Splash protected (not submersible)

10. Warranty and Support

Your CiCiglow E-Book Reader comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact CiCiglow customer service through the retailer where you purchased the product or visit the official CiCiglow website.
Keep your purchase receipt as proof of purchase for warranty purposes.

© 2023 CiCiglow. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08F7Y3XRP

More documents and user manuals: **https://manuals.plus/**