Whirlpool FRESH CARE 6112

Whirlpool FRESH CARE 6112 6.0 kg Fully-Automatic Front Loading Washing Machine User Manual

Model: FRESH CARE 6112

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new Whirlpool FRESH CARE 6112 6.0 kg Fully-Automatic Front Loading Washing Machine. Please read these instructions carefully before using the appliance and retain them for future reference.
Your Whirlpool washing machine is designed to provide excellent washing performance with advanced features for fabric care and energy efficiency.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the appliance is properly grounded.
- Do not allow children to play on or in the appliance.
- Do not operate the washing machine if it is damaged or malfunctioning. Contact qualified service personnel.
- Unplug the appliance before performing any maintenance or cleaning.
- Do not wash items that have been previously cleaned in, washed with, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances.
- Keep flammable materials and vapors away from the appliance.
- Ensure water supply hoses are securely connected to prevent leaks.

3. Product Overview

The Whirlpool FRESH CARE 6112 is a 6.0 kg fully-automatic front-loading washing machine designed for efficient and gentle fabric care.

Key Features:

- **6.0 kg Capacity:** Suitable for small to medium laundry loads.
- **FRESH CARE+ Technology:** Slow, gentle drum movements combined with steam keep garments fresh inside the drum for up to 6 hours after the wash cycle ends, preventing odors and wrinkles.
- **6th Sense SoftMove Technology:** Intelligently senses the load and adapts drum rotation speed to create specific movements, minimizing friction and optimizing washing performance for different fabric types.
- **Colours 15° Program:** Offers superior color protection by using softeners to create a protective veil on clothes, preventing colors from fading.
- **1200 RPM Spin Speed:** High spin speed for effective water extraction, leading to faster drying times.
- **Slim & Compact Design:** With a depth of only 44 cm, it fits into smaller spaces.
- **European Craftsmanship:** Designed, manufactured, and imported from Europe.

Components:



Figure 1: Front view of the Whirlpool FRESH CARE 6112 washing machine. This image displays the main body of the appliance, including the front-loading door, control panel, and detergent dispenser drawer.



Figure 2: Close-up of the control panel. This image shows the rotary program selector, digital display, and touch

buttons for temperature, spin speed, FreshCare+, and start delay functions.



Figure 3: Open detergent dispenser drawer. This image illustrates the compartments for pre-wash detergent, main wash detergent, and fabric softener, along with the maximum fill line indicator.



Figure 4: Interior view of the washing machine drum. This image shows the stainless steel drum with its perforations and lifters, designed for effective washing and gentle fabric treatment.



Figure 5: Illustration of various drum motion types. This graphic depicts different drum movements like Energetic Motion for whites/cottons, Slow Motion for silk/delicates, Wave Motion for synthetics/denims, Soft Cradle for wool, Power Shower for duvets, and Colour Bath for light/dark fabrics, highlighting the 6th Sense SoftMove Technology.

4. Setup and Installation

Proper installation is crucial for the safe and efficient operation of your washing machine. It is recommended to have the appliance installed by a qualified technician.

Unpacking:

- Remove all packaging materials.
- Remove the transport bolts from the rear of the machine. Keep these bolts for future transport.

Location:

- Place the machine on a flat, stable floor.
- Ensure there is adequate space around the machine for ventilation and access.
- Avoid placing the machine in areas where the temperature may drop below freezing.

Leveling:

Adjust the adjustable feet at the bottom of the machine to ensure it is perfectly level. A level machine reduces vibration and noise during operation.

Water Connection:

- Connect the water inlet hose to a cold water tap with a 3/4-inch thread.
- Ensure all connections are tight to prevent leaks.

Drain Hose:

- Position the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fixed to prevent displacement during draining.
- The drain hose should not be kinked or obstructed.

Electrical Connection:

- Plug the power cord into a grounded electrical outlet.
- Ensure the voltage and frequency match the specifications of your appliance (240 Volts).



Figure 6: Rear view of the washing machine showing water inlet and drain hose connections, and the power cord. This image helps in identifying the connection points for installation.

5. Operating Instructions

Follow these steps for effective and safe operation of your washing machine.

5.1 Preparing Laundry:

- Sort laundry by fabric type, color, and degree of soiling.
- Check garment care labels for washing instructions.
- Empty pockets and close zippers and fasteners.

5.2 Loading Laundry:

- Open the washing machine door.
- Load items loosely into the drum, ensuring not to overload. Overloading can reduce washing efficiency and cause damage.
- Close the door firmly until it clicks shut.

5.3 Adding Detergent and Additives:

- Pull out the detergent dispenser drawer.

- Add the appropriate amount of detergent to the main wash compartment (II).
- If using fabric softener, pour it into the designated compartment (flower symbol) up to the 'MAX' mark.
- Close the detergent drawer gently.

5.4 Selecting a Program:

- Turn the program selector knob to choose the desired wash program. Available programs include:**Mixed, White, Cotton, eCotton, Sport, Duvet, Jeans, Spin & Drain, Colours 15°, Rapid 30**, and more.
- The display will show the default temperature and spin speed for the selected program.

5.5 Adjusting Settings:

- **Temperature (Temp.):** Press the 'Temp.' button to adjust the wash temperature if desired.
- **Spin Speed:** Press the 'Spin speed' button to modify the spin speed.
- **FreshCare+:** Activate this option to keep clothes fresh for up to 6 hours after the cycle.
- **Start Delay:** Use this option to delay the start of the wash cycle.

5.6 Starting the Wash Cycle:

- Press the 'Start/Pause' button to begin the selected program.
- The door will lock, and the cycle will start.

5.7 Ending the Cycle:

- At the end of the cycle, the display will indicate 'End' or similar.
- The door will unlock. Open the door and remove your laundry promptly.
- Leave the door slightly ajar to allow the drum to dry and prevent odors.

6. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

6.1 Cleaning the Detergent Dispenser:

- Pull out the dispenser drawer completely.
- Rinse it under running water to remove any detergent or softener residue.
- Clean the housing of the dispenser drawer with a brush.
- Reinsert the drawer.

6.2 Cleaning the Door Seal:

- Regularly wipe the rubber door seal with a damp cloth to remove lint, dirt, and detergent residue.
- Ensure no foreign objects are trapped in the seal.

6.3 Cleaning the Water Inlet Filter:

- Periodically check and clean the filter at the end of the water inlet hose.
- Turn off the water supply and unscrew the hose.
- Remove the filter and rinse it under running water.
- Reassemble and reconnect the hose.

6.4 Cleaning the Pump Filter:

- Locate the pump filter access panel (usually at the bottom front of the machine).
- Place a shallow container underneath to catch any residual water.
- Carefully unscrew and remove the filter.
- Clean the filter of any lint, coins, or foreign objects.
- Screw the filter back in securely.

6.5 Exterior Cleaning:

- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or solvents.

7. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	Power cord not plugged in; door not closed properly; program not selected; 'Start/Pause' not pressed.	Check power connection; ensure door is latched; select program and press 'Start/Pause'.
No water filling	Water tap closed; water inlet hose kinked; water inlet filter blocked.	Open water tap; straighten hose; clean inlet filter.
Water not draining	Drain hose kinked or blocked; pump filter blocked.	Straighten drain hose; clean pump filter.
Excessive vibration/noise	Machine not level; transport bolts not removed; uneven load.	Adjust feet to level machine; remove transport bolts; redistribute laundry.
Poor washing results	Overloading; insufficient detergent; incorrect program selection.	Reduce load size; use correct detergent amount; select appropriate program.

8. Specifications

Detailed technical specifications for the Whirlpool FRESH CARE 6112 washing machine:

Feature	Detail
Brand	Whirlpool
Model	FRESH CARE 6112
Capacity	6.0 Kilograms
Maximum Rotational Speed	1200 RPM

Feature	Detail
Installation Type	Freestanding
Form Factor	Front-Loading
Colour	White
Control Console	Fully Automatic
Access Location	Front Load
Voltage	240 Volts
Material	Steel
Item Weight	12 kg 900 g
Item Dimensions (LxWxH)	167.3 x 234 x 329 Centimeters (Note: This dimension seems unusually large for a washing machine. Please refer to the product's physical dimensions for accurate measurements.)
Included Components	1 unit (Washing Machine)
Cycle Options	Normal, Delicates, Spin, Mixed, White, Cotton, eCotton, Sport, Duvet, Jeans, Spin & Drain, Colours 15°, Rapid 30



Figure 7: Washing machine dimensions. The image indicates a height of 83.7 cm, width of 42.5 cm, and depth of 43 cm. These are the typical physical dimensions of the appliance.

9. Warranty and Support

Warranty Information:

- **Product Warranty:** 2 years from the date of purchase.
- **Motor Warranty:** 10 years from the date of purchase.

The warranty covers manufacturing defects under normal use. Please retain your purchase receipt for warranty claims.

Customer Support:

For service, technical assistance, or warranty claims, please contact Whirlpool customer support:

- **Email:** helpdeskindia@whirlpool.com
- **Toll-Free:** 1800 208 1800
- **Manufacturer/Importer Address:** Whirlpool of India Ltd. Plot No. A-4, MIDC Ranjangaon, Taluka Shirur, Dist: Pune, Maharashtra 412220, India.

When contacting support, please have your product model number (FRESH CARE 6112) and purchase date available.

10. Official Product Videos

No official seller-provided product videos are available for embedding in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question