PowerXL HF-196DT

PowerXL Air Fryer 7 QT Maxx Classic User Manual

Model: HF-196DT

1. Introduction and Overview

The PowerXL Air Fryer 7 QT Maxx Classic is a versatile kitchen appliance designed to prepare a wide variety of meals with less oil. Utilizing Extra Hot Air Fry Technology, it circulates superheated air at rapid speed to deliver crispy, golden-fried results with up to 70% fewer calories from fat compared to traditional frying methods.

This appliance offers 5-in-1 versatility, allowing you to air fry, broil, roast, bake, and reheat. It features an intuitive LED display with 7 one-touch presets for common dishes like French fries, fish, roast, bake, shrimp, chicken, and steak. Temperature can be adjusted in 10°F increments for precise cooking control.

The 7-quart capacity nonstick basket is spacious enough to accommodate 1.75 lbs of French fries, 23 chicken wings, a 3 lb chicken, or a 6-inch pizza in a single cooking cycle. The nonstick crisper tray ensures optimal airflow for even crisping and easy cleanup.



Figure 1: PowerXL Air Fryer 7 QT Maxx Classic - Front View



Figure 2: Key features of the PowerXL Air Fryer, including 7-quart capacity, 7 cooking functions, nonstick fry basket, nonstick crisper tray, and recipe guide.

2. Setup

Before first use, ensure all packaging materials are removed. Wash the fry basket and crisper tray thoroughly with warm, soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.

1. Place the PowerXL Air Fryer on a stable, level, heat-resistant surface.
2. Insert the crisper tray into the fry basket.
3. Slide the assembled fry basket firmly into the main unit until it clicks into place.
4. Plug the power cord into a grounded wall outlet.

The appliance is now ready for use. Always ensure proper ventilation around the unit during operation.

3. Operating Instructions

The PowerXL Air Fryer features a user-friendly touch control panel for easy operation.

Basic Operation:

1. Ensure the fry basket is properly inserted.
2. Press the Power Button () to turn the unit on. The default temperature and time will display.
3. Adjust the temperature using the temperature control buttons (+/- next to thermometer icon). The maximum temperature is 400°F.
4. Adjust the cooking time using the time control buttons (+/- next to clock icon).
5. Alternatively, select one of the 7 one-touch presets for common dishes. The unit will automatically set the optimal temperature and time for that food type.
6. Press the Power Button () again to begin cooking.
7. During cooking, you may pull out the fry basket to shake or flip food. The unit will pause and resume once the basket is reinserted.
8. Once cooking is complete, the unit will beep and automatically shut off. Carefully remove the fry basket using the handle.



Figure 3: The control panel showing 7 custom presets for various food types.



Figure 4: The PowerXL Air Fryer offers 5-in-1 functionality: Air Fry, Broil, Bake, Roast, and Reheat.

Cooking Tips:

- For best results, preheat the air fryer for 3-5 minutes before adding food.
- Do not overfill the basket. Overfilling can prevent food from cooking evenly and becoming crispy.
- Shake the basket or flip food halfway through cooking for even browning and crisping.
- A light mist of oil can enhance crispiness, especially for fresh vegetables.

4. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your PowerXL Air Fryer.

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. The fry basket and crisper tray are dishwasher safe for convenient cleaning.
3. For stubborn food residue, soak the basket and tray in warm, soapy water for 10-15 minutes before scrubbing.
4. Wipe the exterior of the main unit with a clean, damp cloth. Do not immerse the main unit in water or any other liquid.

5. Clean the heating element inside the air fryer with a non-abrasive sponge or brush if necessary, ensuring the unit is unplugged and cool.



Figure 5: The PowerXL Air Fryer features nonstick coating and dishwasher-safe parts for easy cleaning.

5. Troubleshooting

If you encounter issues with your PowerXL Air Fryer, refer to the following common solutions:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a grounded outlet. Check if the fry basket is fully inserted into the unit.
- **Food not cooking evenly:** Do not overfill the basket. Shake or flip food halfway through cooking. Ensure the crisper tray is properly positioned.
- **Food not crispy:** Ensure food is patted dry before air frying. A light coat of oil can help. Do not overfill the basket.
- **White smoke from unit:** This may indicate excess fat dripping onto the heating element. Clean the crisper tray and basket thoroughly. For fatty foods, you may place a small piece of aluminum foil under the crisper tray to catch drips.
- **Plastic smell:** A slight plastic smell may occur during the first few uses. This is normal and will dissipate with continued use. Ensure proper ventilation.

6. Specifications

Feature	Detail
Model Name	PowerXL Air Fryer Maxx Classic
Model Number	HF-196DT
Capacity	7 Quarts
Product Dimensions	14"D x 13"W x 14.5"H
Color	Black
Material	Plastic (outer), Stainless Steel or Aluminum (inner)
Output Wattage	1700 Watts
Voltage	120 Volts
Control Method	Touch
Max Temperature Setting	400 Degrees Fahrenheit
Nonstick Coating	Yes
Dishwasher Safe Parts	Yes (Basket, Crisper Tray)
Air Frying Technology	Rapid Air Technology

7. Warranty and Support

The PowerXL Air Fryer 7 QT Maxx Classic comes with a 90-Day Money-Back Guarantee. For detailed terms and conditions, please refer to the full user manual provided with your product.
For product support or inquiries, please call 973-287-5129.
A digital version of the User Manual (PDF) can be accessed here.

© 2025 PowerXL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question