Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mega Construx GPH70

Mega Construx Masters of The Universe Heroes Faker GPH70 Instruction Manual

Model: GPH70

Introduction
Setup
Operating
Maintenance
Troubleshooting
Specifications
Warranty
Support

1. Introduction

This instruction manual provides essential information for the proper handling, setup, and care of your Mega Construx Masters of The Universe Heroes Faker GPH70 action figure. Please read this manual thoroughly before use to ensure optimal enjoyment and longevity of your product.

The Faker action figure is a detailed collectible from the Masters of the Universe Heroes series, designed for display and imaginative play. It features multiple points of articulation for dynamic posing.



Figure 1: Mega Construx Masters of The Universe Heroes Faker GPH70 in its original packaging.

2. Setup

The Mega Construx Masters of The Universe Heroes Faker GPH70 action figure comes pre-assembled and ready for display or play. No complex assembly is required.

1. **Unboxing:** Carefully remove the figure and any included accessories from its packaging. Retain packaging for future storage or reference if desired.
2. **Accessory Attachment:** The Faker figure typically includes a sword and shield. Gently attach these accessories to the figure's hands or back, if applicable, ensuring they fit securely without forcing. Refer to the packaging art for correct placement.
3. **Initial Inspection:** Before play, inspect the figure for any loose parts or manufacturing defects. If any issues are found, refer to the Troubleshooting section.

3. Operating (Posing and Play)

The Faker action figure features multiple points of articulation, allowing for various poses and dynamic play scenarios.

- **Articulation Points:** The figure typically has articulation at the neck, shoulders, elbows, wrists, waist, hips, knees, and ankles. Gently manipulate these joints to achieve desired poses.
- **Posing:** When posing, apply gentle, even pressure to the joints. Avoid excessive force, which can damage the figure or cause joints to become loose.
- **Accessory Use:** The included sword and shield are designed to be held by the figure. Ensure they are securely placed in the figure's hands during play or display to prevent loss.
- **Display:** For display purposes, ensure the figure is placed on a stable, flat surface to prevent it from falling and sustaining damage.

4. Maintenance and Care

Proper care will help maintain the condition and longevity of your Faker action figure.

- **Cleaning:** To clean the figure, gently wipe it with a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid harsh chemicals, abrasive cleaners, or excessive moisture.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity, which can cause discoloration or material degradation. Keep it in a dust-free environment.
- **Handling:** Handle the figure by its main body parts rather than delicate accessories or thin limbs to prevent breakage.

5. Troubleshooting

This section addresses common issues you might encounter with your action figure.

Issue	Possible Cause	Solution
Loose Joint: A joint feels too loose to hold a pose.	Normal wear and tear, or manufacturing variance.	Apply a small amount of clear nail polish or a specialized joint-tightening fluid to the joint. Allow to dry completely before manipulating. Repeat if necessary.
Stiff Joint: A joint is difficult to move.	Manufacturing variance, or cold temperature.	Gently warm the joint area with warm (not hot) water or a hairdryer on a low setting for a few seconds. Carefully attempt to move the joint. Do not force it.

Issue	Possible Cause	Solution
Accessory Does Not Fit: Sword or shield cannot be attached.	Incorrect orientation, or minor molding flash.	Ensure the accessory is oriented correctly. If there's a small plastic obstruction, carefully trim it with a hobby knife (adult supervision recommended). Do not force the accessory.
Figure Falls Over: Difficulty standing upright.	Improper posing, uneven surface, or loose ankle/hip joints.	Adjust the figure's stance to balance its weight. Ensure it is on a flat, stable surface. If joints are loose, refer to the "Loose Joint" solution.

6. Specifications

Key technical details for the Mega Construx Masters of The Universe Heroes Faker GPH70 action figure:

- **Brand:** Mega Construx
- **Model Name:** GPH70
- **Character:** Faker (Masters of the Universe)
- **Toy Figure Type:** Action Figure
- **Material Type:** Plastic
- **Item Weight:** 0.04 Pounds (approximately 18 grams)
- **Item Dimensions:** 8 x 12.06 x 6.06 inches (packaging dimensions, figure size will be smaller)
- **Number of Pieces:** 1 (figure itself, accessories may be separate)
- **Manufacturer Minimum Age:** 96 Months (8 years)
- **UPC:** 887961887068
- **ASIN:** B08FRSPJD6
- **Assembly Required:** No
- **Batteries Required:** No

7. Warranty Information

Mega Construx products are manufactured to high-quality standards. For specific warranty details regarding your Faker GPH70 action figure, please refer to the warranty information provided on the product packaging or visit the official Mega Construx website. Typically, warranties cover manufacturing defects for a limited period from the date of purchase. Please retain your proof of purchase for any warranty claims.

8. Customer Support

Should you require further assistance, have questions not covered in this manual, or need to report a defect, please contact Mega Construx customer support. Contact information can usually be found on the product packaging or on the official Mega Construx website.
Online Support: Visit the official Mega Construx website for FAQs and contact forms.www.megaconstrux.com
Manufacturer: Mattel

© 2024 Mega Construx. All rights reserved. Masters of the Universe and associated trademarks are owned by Mattel.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08FRSPJD6

More documents and user manuals: **https://manuals.plus/**